



User Guide

ORiNOCO AP-8000
User Guide



IMPORTANT!

Before installing and using this product, see the *Safety and Regulatory Compliance Guide* located at Answer ID 2814 at <http://support.proxim.com>.

Copyright

© 2008 Proxim Wireless Corporation. All rights reserved. Covered by one or more of the following U.S. patents: 5,231,634; 5,875,179; 6,006,090; 5,809,060; 6,075,812; 5,077,753. This User Guide and the software described in it are copyrighted with all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Proxim Wireless Corporation.

Trademarks

ORiNOCO and Proxim are registered trademarks, and the Proxim logo is a trademark, of Proxim Wireless Corporation.

Acrobat Reader is a registered trademark of Adobe Systems Incorporated.

HyperTerminal is a registered trademark of HilGraeve, Incorporated.

Microsoft and Windows are a registered trademarks of Microsoft Corporation.

Netscape is a registered trademark of Netscape Communications Corporation.

SolarWinds is a registered trademark of SolarWinds.net.

All other trademarks mentioned herein are the property of their respective owners.

GPL License Note

Proxim AP 800/8000 includes software code developed by third parties, including software code subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). Please see the GPL and LGPL Web sites to view the terms of each license.

To access to the GPL Code and LGPL Code used in Proxim AP 800/8000, extract the source version and explore opensrc directory. The GPL Code and LGPL Code used in this AP are distributed WITHOUT ANY WARRANTY and are subject to the copyrights of one or more authors. For details, see the GPL Code and LGPL Code of this AP and the terms of the GPL and LGPL.

OpenSSL License Note

This product contains software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>) and that is subject to the following copyright and conditions:

Copyright (c) 1998-2002 The OpenSSL Project. All rights reserved.

The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to refer to, endorse, or promote the products or for any other purpose related to the products without prior written permission. For written permission, please contact openssl-core@openssl.org.

This software is provided by the OpenSSL Project "as is" and any expressed or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose are disclaimed. In no event shall the OpenSSL Project or its contributors be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services; loss of use, data, or profits; or business interruption) however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of this software, even if advised of the possibility of such damage.

ORiNOCO AP-8000 User Guide

User Guide Ver1.0.0

P/N 75961, October 2008

Contents

1	Introduction	8
	Products Covered in this User Guide	8
	About AP-8000 Dual Radio Wireless Access Point	8
	Core Features of AP-8000	8
	Two Independent Multi-Band MIMO Radios	8
	802.11n Multiple Input and Multiple Output (MIMO)	9
	Security	9
	Quality of Service (QoS)	9
	Software Upgrade	9
	Compliant to Wireless Standards	9
2	Installation and Initialization	10
	Hardware Overview	10
	LED Indicators	10
	Antennas	11
	Power Socket	11
	Reset	11
	Reload	11
	Ethernet Port	11
	Serial Port	11
	Description of the AP-8000 Unit	12
	Prerequisites	12
	System Requirements	13
	Product Package	13
	Optional Accessories	14
	Hardware Installation	14
	Attach the Cables	14
	Using a Console Port	15
	Install the Cable Security Cover (Optional)	15
	Install the Antenna	15
	Mount the Unit	15
	Power on the Unit	16
	Initialization	17
	Using ScanTool	17
	Installing the Software	21
	Install Software Using TFTP Server	24
3	Managing the Access Point	26
	HTTP/HTTPS Interface	26
	Command Line Interface/Telnet	26

SNMP Management	27
SSH (Secure Shell) Management	27
HyperTerminal	27
ProximVision ES	28
4 Basic Configuration for an Enterprise	29
Configuring Basic Settings for the Access Point	29
Finding and Assigning the Access Point's IP Address	29
Configuring the System Name and the Country Code	29
Configuring the Wireless Information	30
Configuring the Operational Mode	30
Password Management	30
Configuring the Security Profile	31
5 Access Point Features	33
Configuring the Device	33
Wireless	33
Ethernet	35
Security	35
RADIUS	38
QoS	41
IP Configuration	42
VLAN	43
Filtering	44
Managing the Device	47
System Information	47
Upgrading the Firmware	48
Password Management	49
Management Access Control	49
Monitoring the Device	50
System Log	50
Event Log	50
SNTP	50
Interface Statistics	51
RADIUS	53
6 Using Web Interface to Manage the Access Point	55
Web Interface Overview	55
Error Message	55
Configuring the Device	56
Wireless	56

Ethernet	60
Security	61
QoS	65
IP Configuration	69
VLAN	70
Filtering	71
Managing the Device	78
System	79
System Inventory Management Component	80
Upgrading the Firmware	80
Password Management	84
Management Access Control	85
Monitoring the Device	86
System Log	87
Event Log	89
SNTP	90
Interface Statistics	91
Bridge	93
Network Layer	95
RADIUS	96
7 Using SNMP Interface to Manage the Access Point	98
Pre-requisites	98
Viewing the MIB Objects	98
Configuring the MIB Objects	99
To Configure the Scalar Objects :	99
To Configure the Tabular Objects:	99
To apply the changes to the flash memory:	99
8 Using CLI to Manage the Access Point	100
Global Configuration Mode	100
General Notes	100
Configuring the AP using CLI Commands	103
Log into the AP using HyperTerminal	103
Log into the AP using Telnet	103
Command Line Interface Mode Overview	103
User Exec Mode	103
Privileged Exec Mode	104
9 Troubleshooting	121
Troubleshooting Concepts	121
Symptoms and Solutions	122
Connectivity Issues	122

Basic Software Setup and Configuration Problems	122
Client Connection Problems	124
VLAN Operation Issues	124
Gigabit Ethernet PoE	125
Recovery Procedures	126
Soft Reset to Factory Defaults	126
Hard Reset to Factory Defaults	126
Forced Reload	126
Setting IP Address using Serial Port	129
Related Applications	130
RADIUS Authentication Server	130
TFTP Server	130
A ASCII Character Chart	131
B Bootloader CLI	132
c Specifications	134
Software Specifications	134
Number of Stations per BSS	134
Management Functions	134
Advanced Bridging Functions	135
Medium Access Control (MAC) Functions	135
Security Features	135
Network Features	136
Hardware Specifications	136
Available Channels	137
D Technical Services and Support	141
Obtaining Technical Service and Support	141
Support Options	142
Proxim eService Web Site Support	142
Telephone Support	142
ServPak Support	142
E Statement of Warranty	144
Warranty Coverage	144
Repair or Replacement	144
Limitations of Warranty	144
Support Procedures	144
Other Information	145
Search Knowledgebase	145
Ask a Question or Open an Issue	145

Other Adapter Cards 145

Introduction

This chapter contains information on the following:

- [Products Covered in this User Guide](#)
- [About AP-8000 Dual Radio Wireless Access Point](#)
- [Core Features of AP-8000](#)
 - [Two Independent Multi-Band MIMO Radios](#)
 - [802.11n Multiple Input and Multiple Output \(MIMO\)](#)
 - [Security](#)
 - [Quality of Service \(QoS\)](#)
 - [Software Upgrade](#)
 - [Compliant to Wireless Standards](#)

Products Covered in this User Guide

This User Guide details functionality of the following products:

Product	Description
AP-8000	An Access Point with: <ul style="list-style-type: none"> • two radios that support 2.4/5.0GHz • Gigabit Ethernet with PoE support

About AP-8000 Dual Radio Wireless Access Point

The AP-8000 is 802.11n dual radio wireless Access Point that provides connectivity between wired network and wireless systems and other devices. The AP-800 wireless Access Point is a Wi-Fi a/b/g/n certified that supports dual radio modes in 2.4 GHz and 5 GHz frequency band. You can configure the radios using different 2.4 GHz or 5 GHz settings.

With AP-8000, you can achieve higher throughput by increasing the channel width from 20 MHz to 40 MHz thereby doubling the data rate and by using the MIMO feature. The 802.11n products have incorporated multiple antennas. This Multiple-Input, Multiple-Output (MIMO) antenna technology provides spatial multiplexing, short Guard Interval(GI) for increased range and throughput.

Using the Channel Bonding technique, the Access Point uses two separate adjacent 20MHz bands to transmit data. This increases the amount of data that can be transmitted.

NOTE: Wherever “n” is mentioned, it refers to the Draft 802.11n Version 2.0.

Core Features of AP-8000

Two Independent Multi-Band MIMO Radios

Proxim’s Access Points have two independent multi-band MIMO radios (802.11a/b/g/n) that offer significant increase in capacity and performance within a given bandwidth and power.

The 802.11n Access Points operates on both 2.4 Ghz and 5 GHz radio bands and Proxim's Access Points provides you with the facility of selecting the band on which you would like to operate on.

Both these radios can be planned independently as per your network requirements. Using the single MAC protocol, it operates with multiple frequency layers and this improves the range, coverage, and throughput in both frequency bands.

802.11n Multiple Input and Multiple Output (MIMO)

The MIMO technology is used for multiple antennas at both the transmitter and receiver to improve communication performance. Using the MIMO technology, the Access Points can offer significant increase in data throughput and link range without additional band width or transmit power. This is achieved by high spectral efficiency and link reliability or diversity.

For the 802.11n Access Points, MIMO is the heart for the entire system because it uses a third, spatial dimension - beyond frequency and time as a carrier of information.

Security

Proxim's Access Points utilize robust industry-leading security protocols such as WPA and WPA2 to protect sensitive data that is transmitted over the wireless LAN. You can configure unique security settings for each BSSID according to your network requirements making it more secure.

Quality of Service (QoS)

The AP supports Wi-Fi Multimedia (WMM), which is a solution for QoS functionality based on the IEEE 802.11e specification. WMM defines enhancements to the MAC for wireless LAN applications with Quality of Service requirements, which include transport of voice and video traffic over IEEE 802.11 wireless LANs. Using this parameter you can configure the feature that affects the flow of traffic from AP to client station and vice-versa. And also prioritize the traffic according to your network requirements so that flow of traffic is eased out without losing any information.

Software Upgrade

You can upgrade the firmware easily as and when you want either through web-GUI, CLI using HTTP or TFTP.

Compliant to Wireless Standards

The AP-8000 adheres to the 802.11a, 802.11b/g/n draft 2.0 standards that enable you to get the best performance from your wireless network and support a wide range of compliant devices.

The device can be powered by a 5 VDC input and also by standard 802.3af compliant Gigabit Ethernet PoE device.

Installation and Initialization

In this chapter:

- [Hardware Overview](#)
 - [LED Indicators](#)
 - [Antennas](#)
 - [Power Socket](#)
 - [Reset](#)
 - [Reload](#)
 - [Description of the AP-8000 Unit](#)
- [Prerequisites](#)
- [System Requirements](#)
- [Product Package](#)
- [Optional Accessories](#)
- [Hardware Installation](#)
 - [Attach the Cables](#)
 - [Install the Cable Security Cover \(Optional\)](#)
 - [Install the Antenna](#)
 - [Mount the Unit](#)
 - [Power on the Unit](#)
- [Initialization](#)
 - [Using ScanTool](#)
- [Installing the Software](#)
 - [Install Software Using TFTP Server](#)

Hardware Overview

The Access Point supports dual radio operations using the 2.4 and 5 GHz, and has six antenna connectors. The 2.4 GHz radios support 802.11b/g and 802.11n/g modes of operation whereas 5 GHz radio supports 802.11n/a and the 802.11n.

LED Indicators

The top panel of the AP-8000 has the following LED indicators:

- The Power LED provides whether the device is switched on/off.
- The Ethernet LED signals Ethernet traffic on the wired Ethernet LAN
- The Wireless Interface (Radio) 1LED provides the status of the wireless radio.
- The Wireless Interface (r) LED is reserved for future reference.




Figure 2-1 LED Indicators

Antennas

The Access Point has been designed to operate with omni-directional antennas, having the maximum gain of 2.5 dBi. These antennas have standard connectors and can be installed easily. Proxim also provides an optional accessory - **Range Extender Antenna**, which has standard connectors and can be installed easily.

Power Socket

This socket connects to the 5VDC power adapter.s

Reset

If you need to powercycle the device, then press Reset button.

Reload

You can use the Reload feature of the device to reset the device configuration parameters to default factory settings. If you cannot access the unit or you have lost its password, you can reset the unit to the factory default settings.

Ethernet Port

The Ethernet port of the device allows you to connect to th LAN using CAT5 or CAT6 Ethernet cable.

Serial Port

The AP-8000 device has a serial port that enables the use of external modems that connect to PC or laptop via a serial cable.




Figure 2-2 Rear View of the AP-8000

Description of the AP-8000 Unit




Figure 2-3 Schematic Illustration of the Unit

Prerequisites

Before installing your unit, you need to gather certain network information. The following table identifies the information you need:

AP's IP Address	If you do not have a DHCP server on your network, then you need to assign the Access Point an IP address that is valid on your network.
Web Interface/Telnet/CLI User Name/Password	Each Access Point requires a read/write username and password to access the web interface, Telnet and CLI. The default username is "admin" and password is "public".
SNMP Read Password	Each Access Point requires a password to allow get requests from an SNMP manager. The default username is "admin" and password is "public".
SNMP Read-Write Password	Each Access Point requires a password to allow get and set requests from an SNMP manager. The default password is "public".
Security Settings	You need to determine what security features you will enable on the Access Point.
Gateway IP Address and Subnet Mask	The gateway IP address and subnet mask of the network environment where the Access Point is deployed.

System Requirements







To begin using an AP, you must have the following minimum requirements:

- Ethernet switch or cross-over Ethernet cable.
- One of the following IEEE 802.11- compliant devices:
 - An 802.11a/b/g or 802.11n client devices
- A computer that is connected to the same IP network as the AP and has one of the following installed:
 - web browser
 - Telnet
 - RS-232 Serial Port
 - MIB Browser
 - Ethernet NIC Card

Product Package

Each **AP-8000** shipment includes the items in the following table. Verify that you have received all parts of the shipment.

NOTE: Unless noted in this table, cables are not supplied with the unit.

AP-8000 Product Package Description	Images
AP-8000 unit with (1 Qty): <ul style="list-style-type: none"> – two radio (802.11a/b/g/n) support – Ethernet port with PoE support (10/100/1000) 	
CD-ROM containing software and documentation (1 Qty)	
Quick Install Guide (1 Qty)	
2.4 GHz/ 5GHz omni-directional antennas with reverse SMA connectors (6 Qty)	
Cable Security Cover (1 Qty)	
Wall/Ceiling mount plate (1 Qty)	

Optional Accessories

You can also use these optional accessories that Proxim recommends.

110-220V worldwide power adapter (1 Qty)	
Range Extender Antenna (REA)	
Gigabit Ethernet PoE	

Hardware Installation

IMPORTANT:

Before installing and using this product, see *Safety and Regulatory Compliance Guide* available with AP-8000 Answer ID 2814 at <http://support.proxim.com>.

Perform the following procedures to install the AP-8000 hardware:

- [Attach the Cables](#)
 - [Cabling with Power Adapter](#)
 - [Cabling with Gigabit Ethernet PoE](#)
- [Install the Cable Security Cover \(Optional\)](#)
- [Install the Antenna](#)
- [Mount the Unit](#)
- [Power on the Unit](#)

Attach the Cables

NOTE: Proxim recommends to use CAT6 cable for the length of 100 m or CAT5e cable for lower length. Though the AP-8000 can work with CAT5 cable, there is a possibility that you may experience a drop in Ethernet speed from 1000BaseT to 100BaseT or Ethernet interface may show errors.

Cabling with Power Adapter

1. Plug the barrel of the power cable from the power supply into the power jack.
2. Connect one end of an CAT 6 Ethernet cable (not supplied) to the unit's LAN port. The other end of the cable should not be connected to another device until installation is complete:
 - Use a straight-through CAT 6 Ethernet cable if you intend to connect the unit to a switch, hub, or patch panel.
 - Use a cross-over Ethernet cable CAT6) or adapter if you intend to connect the unit to a single computer.

Cabling with Gigabit Ethernet PoE

1. To power the device using Gigabit Ethernet PoE, you must use Gigabit PoE injector (ordered separately). Connect one end of a CAT6 Ethernet cable (not supplied) to the unit's LAN port. Connect the other end to the **Data and Power Out** port of the PoE Injector.
2. Connect one end of the second CAT6 Ethernet cable to the Data In port of the DC Injector. The other end of the cable should not be connected to another device until installation is complete:
 - Use a straight-through cable if you intend to connect the unit to a switch, hub or patch panel.
 - Use a cross-over Ethernet cable (CAT6) or adapter if you intend to connect the unit to a single computer.

Using a Console Port

You may connect your Access Point with a console port. Follow the steps provided below if you are using the Console port:

1. Connect a nine-pin, male-to-female serial cable to the COM port on a computer or laptop and to the DB9 connector of the Access Point.
2. Open the Microsoft's HyperTerminal to set up the AP-8000. For more information refer [Initialization](#).

Install the Cable Security Cover (Optional)

When the **RS-232 cable is not connected**, you may install a security cover to deter unauthorized access to the unit. The security cover is a plastic enclosure that prevents access to the power and LAN ports, and the **Reset** and **Reload** buttons.

1. Open the split end of the security cover just enough to slide the power cable (if you are not using Gigabit Ethernet PoE) and the CAT 6 Ethernet cable through the opening until they fit inside the straight clamping portion of the cover. Exercise care as you slide the cable (s) so you do not accidentally break the cover.
2. Slide the hinging end of the security cover into the hole on the rear panel of the unit to the left of connectors. Once in place, pivot the cover to bring it close to the rear panel of the unit.
3. Use two screws to fasten the security cover on to the rear panel of the unit.

Install the Antenna

The omni-directional antennas supplied with the product do not require any professional installation as they have non-standard connectors.

NOTE: *Optionally, you can use the Range extended Antenna (REA). This accessory also has non-standard connectors, and can install them easily.*

If the regular outdoor antennas are used, connected via a pigtail conversion cable that offers a standard connector type for antenna connection, then professional installation is required.

Follow these steps to assemble the antennas to AP-8000:

1. Hand-tighten the antennas clockwise, onto the outer connectors of AP-8000 until they are firmly attached.
2. Position the antennas as close to the horizontal surface (ceiling or wall), so as to get the maximum signal coverage of the omni-directional antenna.

NOTE: *Proxim recommends to aim the antenna horizontal, as the wireless coverage angle is wider with the antenna pointing up or down.*

Mount the Unit

Proxim recommends that you have site survey professionally conducted to determine the best location for the AP.

The following considerations must be kept in mind when the AP-8000 is mounted.

- The AP must be protected from exposure, and the environmental conditions must be within those specified in the product datasheet that can be found at <http://www.proxim.com/products/>
- The AP-8000 uses +5V/3.5A power adapter.
- Note that the AP-8000 has been certified under UL Standard 2043 and can be installed in the plenum. In an office building, plenum is the space between the structural ceiling and the tile ceiling that is provided to help air circulate. Many companies also use the plenum to house communication equipment and cables. These products and cables must comply with certain safety requirements, such as Underwriter Labs (UL) and Standard 2043: “Standards for Fire Test for Heat and Visible Smoke Release for Direct Products and Their Accessories installed in Air-Handling Spaces”.

NOTE: *When installed in a plenum, the AP must use PoE.*

Once you have chosen a final location for your unit, the following are the mounting options are available:

- [Wall Mounting](#)
- [Ceiling Mounting](#)

Wall Mounting

Follow these steps to mount the unit on a wall:

1. If the unit's power supply is plugged in, unplug it.
2. Put the mounting plate up to the wall so that the embossed letter “L” is on the top. If the plate is correctly oriented, the circular tab that is vertically aligned with the square hole should be on top.
3. Fasten the mounting plate with two screws through the circular holes of the plate. Depending on the type of wall, you may need to use the fasteners.
4. Holding the unit so that the connectors on the rear, align the holes on the bottom of the unit with the two tabs on the mounting plate. Press the unit down so it is flush with the plate.
5. Carefully slide the unit to the up until the tabs snap securely on to the narrow holes of the unit. if the unit is mounted correctly, no portion of the mounting plate should protrude from any of the sides of the unit.

Ceiling Mounting

Follow these steps to mount the unit to a ceiling:

1. If the unit's power supply is plugged in, unplug it.
2. Snap the rectangular tabs on the back of the mounting plate onto a ceiling T-bar. You may need to slightly rotate the plate until it securely snaps onto the T-bar.
3. Fasten the mounting plate to the ceiling tile with two screws through the circular holes of the plate.
4. Position so that the embossed letter “L” on the mounting plate is facing up. Hold the unit so that the connectors on the rear, align the two holes on the bottom of the unit with the two tabs on the mounting plate. Press the unit up so it is flush with the plate.
5. Carefully slide the unit to the “L” direction until the tabs snap securely onto the narrow holes of the unit. If the unit is mounted correctly, no portion of the mounting plate should protrude from any of the sides of the unit.

Power on the Unit

The AP can be powered by a power supply (just plug the power cord of the power supply into an AC power outlet), or by Gigabit Ethernet PoE.

When power is applied to the Access Point, you will observe that Power LED lights up Green.

Connect the AP-8000 LAN port to a stand-alone PC using Ethernet cable, or to a network hub or switch. You can monitor the Ethernet LEDs on the top of the Access Point. The color of the Ethernet LEDs will inform about the speed of the Ethernet traffic:

- GREEN: 1000 Mbps

Initialization

- RED: 100 Mbps
- BLANK: No link available or Ethernet is not connected

NOTE: When in operational status, the wireless LEDs will be steady Green. The wireless LEDs would blink Green when the wireless traffic is being transmitted or received.

Initialization

The following sections detail how to initialize the AP using the ScanTool, log in to the HTTP interface, perform an initial configuration if required (the Access Points are configured to a default settings) and download the required AP software.

Using ScanTool

ScanTool is a software utility that is included in the installation CD-ROM. It is an initial configuration tool that allows you to find the IP address of an Access Point by referencing the MAC address in a Scan List, or to assign an IP address if one has not been assigned.

The tool automatically detects the Access Points installed in your network, regardless of IP address, and lets you configure each unit's IP settings. In addition, you can use set initial device parameters that will allows the AP to retrieve new software to an AP that does not have a valid software image installed.

To access the HTTP interface and configure the AP, the AP must be assigned an IP address that is valid on its Ethernet network. By default, the AP is configured to obtain an IP address automatically from the network **Dynamic Host Configuration Protocol (DHCP)** server during the boot-up.

If your network contains a DHCP server, you can run the ScanTool to find out what IP address the AP has been assigned.

If your network does not contain a DHCP server, the Access Point's IP address defaults to 169.254.128.132 and the device starts with a dynamic IP address. By default, the IP address is Static.

ScanTool Instructions

Follow these steps to install ScanTool and initialize the AP:

1. Power up, reboot, or reset the AP.
2. Double-click the ScanTool icon on the Windows desktop to launch the program (if the program is not already running). If the icon is not on your desktop, click **Start > All Programs > ORiNOCO > AP-8000 > Xtras > ScanTool**.

NOTE: If your computer has more than one network adapter installed, you will be prompted to select the adapter that you want ScanTool to use before the Scan List appears. You can use either an Ethernet or wireless adaptor. If prompted, select an adapter and click OK. You can change your adapter setting at any time by clicking the Select Adapter button on the Scan List screen.

ScanTool scans the subnet and displays all detected Access Points. The ScanTool's Scan List screen appears, as shown




Figure 2-4 ScanTool

3. Locate the MAC address of the AP you want to initialize within the Scan List.

NOTE: If your Access Point does not appear in the Scan List, click the Rescan button to update the display. If the unit still does not appear in the list, see [Troubleshooting](#) for suggestions. Note that after rebooting an Access Point, it may take up to five minutes for the unit to appear in the Scan List.

4. Do one of the following:

- If the AP has been assigned an IP address by a DHCP server on the network:
 - a. Highlight the entry for the AP you want to configure.
 - b. Click the Change button. The Change screen appears.
 - c. Click on the Web Configuration button at the bottom of the change screen.
 - d. Proceed to the [Logging In](#) section for information on how to access the HTTP interface using the IP address.
- If the AP has not been assigned an IP address (in other words, the unit is using its default IP address, 169.254.128.132), follow these steps to assign it a static IP address that is valid on your network:
 - a. Highlighting the entry for the AP you want to configure.
 - b. Click the **Change** button. The **Change** screen appears.




Figure 2-5 Change Screen

- c. Set **IP Address Type** to **Static**.
- d. Enter a static IP Address for the AP in the field provided. You must assign the unit a unique address that is valid on your IP subnet. Contact your network administrator if you need assistance selecting an IP address for the unit.
- e. Enter your network's **Subnet Mask**.
- f. Enter your network's **Gateway IP Address**.
- g. Enter the SNMP Read/Write password in the **Read/Write Password** field (for new units, the default SNMP Read/Write password is **public**).

NOTE: The TFTP Server IP Address and Image File Name fields are only available if ScanTool detects that the AP does not have a valid software image installed.

- h. Click **OK** to save your changes.
- i. The Access Point will need reboot to apply any changes you made. When the reboot message appears, click **OK** to reboot the device and return to the **Scan List** screen.




Figure 2-6 Change Screen - Reboot

- j. After allowing sufficient time for the device to reboot, click **Rescan** to verify that your changes have been applied.
- k. Click the **Change** button to return to the Change screen.
- l. Click the **Web Configuration** button at the bottom of the Change screen.




Figure 2-7 Change Screen - Web Configuration

- m. Proceed to the Logging In section for information on how to access the HTTP interface using this IP address.

Logging In

Once the AP has a valid IP Address and an Ethernet connection, you may use your web browser to monitor and configure the AP. (To configure and monitor using the command line interface, see [Using CLI to Manage the Access Point](#) and To configure and monitor using the SNMP interface, see [Using SNMP Interface to Manage the Access Point](#).)

1. Open a Web browser on a network computer.
2. If necessary, disable the browser's Internet proxy settings. For Internet Explorer users, follow these steps:
 - Select **Tools > Internet Options**.
 - Click the **Connections** tab.
 - Click **LAN Settings**.
 - If necessary, remove the check mark from the **Use a proxy server** box.
 - Click **OK** twice to save your changes and return to Internet Explorer.
3. Enter the Access Point's IP address in the browser's **Address** field and press **Enter** or **Go**.

This is either the dynamic IP address assigned by a network DHCP server or the static IP address you manually configured. See [Using ScanTool](#) for information on how to determine the unit's IP address and manually configure a new IP address, if necessary.

The **Access Point Login** screen appears.




Figure 2-8 Login

4. Enter the HTTP **User Name** and **Password**. The default username and password are “**admin**” and “**public**”. The user name and password are case-sensitive fields.

NOTE: *The Home Page is automatically launched. By default, the Access Point is configured to the default settings and with those settings you can manage your access point. You can make changes/modify the default settings according to your network requirements.*

The links on the left of the screen provide access to the configuration, management and monitoring options for the AP.

The Command Line Interface (CLI) also provides a method for monitoring and configuring the AP using Telnet or a serial connection. For more information about monitoring and configuring the AP with the CLI, see [Using CLI to Manage the Access Point](#).

Using SNMP Interface you can configure and monitor the AP, see [Using SNMP Interface to Manage the Access Point](#)

Installing the Software

Proxim periodically releases updated software for the AP on its Web site, Check the Web site for the latest updates after you have installed and initialized the unit.

1. In your web browser, go to <http://support.proxim.com>
2. If prompted, create an account to gain access.

NOTE: *The Knowledgebase is available to all website visitors. First -time users will be asked to create an account to gain access.*

3. Click **Search Knowledgebase**.
4. In the Search Knowledgebase field, enter **2814** for **AP-8000**.
5. Click **Search**.
6. Click on the appropriate link to access the download page.
7. Use the instructions in the following sections to install the new software.

Use the **File Management** to upload or download the latest AP software files (images, config etc) from host device to the device or device to host device.

Update Device Using HTTP

Use the **HTTP Download** page to download config, image files to the device. In the HTTP Download page, perform the following procedure to download the specific file:

HTTP Update

Note: Please do not Navigate away from this page when the update is in progress.

File Type: Config

File Name: C:\Documents and Setting [Browse...]

[Update] [Clear]

Figure 2-9 Update Device using the HTTP Download Page

1. Select the **File Type** that needs to be updated from the drop-down box. Choices include:
 - Image for the AP Image (executable program).
 - Config for configuration, such as System Name, Contact Name and so on.
2. Use the **Browse** button or manually type in the name of the file to be downloaded (including the file extension in the **File Name** field. If typing the file name, you must include the full path and the file extension in the file name text box.
3. To initiate the HTTP Update operation, click **Update** button.

NOTE: *An HTTP file transfer using SSL may take extra time.*

- If the operation is completed successfully the device would provide the information about the successful update.

New config file updated in the device

[Back]

Figure 2-10 Update Device Using HTTP- Success Message

- If the operation is not completed successfully the following screen appears, and the reason for the failure is displayed.





Figure 2-11 Update Device Using HTTP- Failure Message

Update Device Using TFTP

Use the TFTP Download page to download config, image file to the device. A TFTP server must be running and configured to point to the directory containing the file.

If you do not have a TFTP server installed on your system, install the TFTP server from the installation CD. You can either install the TFTP server from the CD Wizard or run OEM-TFTP-Server.exe found in the CD's Xtras/SolarWinds sub-directory.

Using the **TFTP Download** page to enter the following information as described below:



TFTP Update

Note: When Operation is changed to "Update and Reboot", once Update is complete the system will reboot without any further notification.

Note: Please don't Navigate away from this page when the update in progress.

Server IP Address	172.18.18.175
File Name	image.bin
File Type	Image
Operation	None

Update

Figure 2-12 Update Device Using TFTP Server

- **Server IP Address:** Enter the TFTP server IP Address.
 - Double-click the TFTP server icon on your desktop and locate the IP address assigned to the TFTP server.

NOTE: This is the IP address that will be used to point the Access Point to the AP Image file.
- **File Name:** Enter the name of the file to be downloaded (including the file extension).
 - Copy the file to the TFTP server's root folder.
- **File Type:** Select the proper file type. Choices include:
 - Config: Configuration information, such as System name, contact name, and so on.
 - Image: AP image (executable program)
- **Operation:** Select either **Download** or **Download & Reboot**. You should reboot the AP after downloading files.

NOTE: If you select None as Operation, then no operation will be performed.

Click **OK** to initiate the process.

- If the operation is completed successfully the device would provide the information about the successful update.




Figure 2-13 Update Device Using TFTP- Success Message

- If the operation is not completed successfully the following screen appears, and the reason for the failure is displayed.



Figure 2-14 Update Device Using TFTP- Failure Message

Retrieve From Device Using HTTP

Use the **HTTP** Upload page to retrieve config files from device.

1. Select the type of file (config, event log) from the File Type drop-down box.
2. Click **Retrieve** button to initiate the process.




Figure 2-15 Retrieve File using HTTP

3. The **Download** page is displayed. Click **Download** to download the file.




Figure 2-16 Download Page

4. **File Download** window pops up. Click **Save** button to save the file.




Figure 2-17 File Download Page

5. Select an appropriate filename and location and click Save.

Retrieve From Device Using TFTP

Use the **TFTP Upload** to upload files from the AP to the TFTP server. The TFTP server must be running and configured to point to the directory to which you want to copy the uploaded file. We suggest you assign the file a meaningful name.

If you don't have a TFTP server installed on your system, install the TFTP server from the installation CD. You can either install the TFTP server from the CD Wizard or run OEM-TFTP-Server.exe found in the CD's Xtras/SolarWinds sub-directory.

In the TFTP Upload page enter the following TFTP information as described below:

TFTP Retrieve

Note: If the device is in default configuration there will be no config file present, the request for uploading will not take effect. Similarly if there is no eventlog created on the device, the request for uploading eventlog will not take effect.

Server IP Address	<input type="text" value="172.18.18.175"/>
File Name	<input type="text" value="flashcfg.cfg"/>
File Type	<input type="text" value="Config"/>

Figure 2-18 Retrieve From Device Using TFTP

- **Server IP Address:** Enter the TFTP server IP Address.
 - Double-click the TFTP server icon on your desktop and locate the IP address assigned to the TFTP server.
- **File Name:** Enter the name of the file to be uploaded.
- **File Type:** Select the type of the file to be uploaded: Config file or Event Log.

Click **Retrieve** to initiate the procedure.

Install Software Using TFTP Server

A Trivial File Transfer Protocol (TFTP) server allows you to transfer files across a network. You can upload files from the AP for backup or copying, and you can download the files for configuration and AP Image upgrades. The Solarwinds TFTP server software is located on the AP Installation CD-ROM. You can also download the latest TFTP software from Solarwind's Web site at <http://www.solarwinds.net>. The instructions that follow assume that you are using the Solarwinds TFTP server software; other TFTP servers may require different configurations.

NOTE: *If a TFTP server is not available in the network, you can perform similar file transfer operations using the HTTP interface.*

TFTP Server Setup

To download or upload a file, you must connect to the computer with the TFTP server through the unit's Ethernet port. This can be any computer in the network or a computer connected to the unit with a cross-over Ethernet cable.

Ensure that:

1. The Upload or download directory is correctly set (the default directory is **C:\TFTP-Root**).
2. The required image file is present in the directory.
3. The TFTP server is running. The TFTP server must be running only during file upload or download. You can check the connectivity between the unit and TFTP server by pinging the unit from the computer that hosts the TFTP server. The ping program should show replies from the unit.
4. The TFTP server is configured to both Transmit and Receive files, with no automatic shutdown or time-out.

Install Updates from your TFTP Server using the CLI

1. Download the latest software. See [Installing the Software](#) for instructions.
2. Copy the latest software updates to your TFTP server.
3. Open the CLI interface via Telnet or a serial connection.
4. Enter the CLI password when prompted.

Enter the command: `download (config-tftp)#operation type <operation type or corresponding number>`.

The download will begin, and the image will be downloaded to the Access Point.

5. When the download is complete, click REBOOT button.

Managing the Access Point

There are several management and monitoring interfaces available to the network administrator to configure and manage an AP on the network:

- [HTTP/HTTPS Interface](#)
- [Command Line Interface/Telnet](#)
- [SNMP Management](#)
- [SSH \(Secure Shell\) Management](#)
- [ProximVision ES](#)

HTTP/HTTPS Interface

The HTTP Interface (Web browser Interface) provides easy access to configuration settings and network statistics from any computer on the network. You can access the HTTP Interface over your LAN (switch, hub, etc.), over the Internet, or with a “crossover” Ethernet cable connected directly to your computer’s Ethernet Port.

HTTPS provides an HTTP connection over a Secure Socket Layer. HTTPS is one of the three available secure management options on the AP; the other secure management option is SSH. HTTPS allows the user to access the AP in a secure fashion using Secure Socket Layer (SSL) over port 443. The AP supports SSLv3 with a 128-bit encryption certificate maintained by the AP for secure communications between the AP and the HTTP client. All communications are encrypted using the server and the client-side certificate.

NOTE: *When the AP is powered on, it always comes up with the default IP Address 169.254.128.132 for the first time, unless otherwise it is configured to use a different IP, or send request to a dynamic server. In other words, the default ip address type is "static".*

- If the DHCP server is available, then AP-800 unit will be assigned an IP address automatically. You can find the IP address of the device either from the DHCP server or the ScanTool.
- If the DHCP server is not available, then you can use the default IP address (**169.254.128.132**) or change the IP address of your subnet using the ScanTool. You can log in to the device using the default **UserName (admin)** and **Password (public)**.

NOTE: *The UserName and Password are case-sensitive.*

The AP comes pre-installed with all required SSL files: default certificate, private key and SSL Certificate Pass-phrase installed.

Command Line Interface/Telnet

The Command Line Interface (CLI) is a text-based configuration utility that supports a set of keyboard commands and parameters to configure and manage an AP. To login to the CLI Interface, follow the procedure:

1. Confirm that your computer’s IP address is same as that of the IP subnet of the AP.
2. Go to the DOS Command prompt on your computer.
3. Type **telnet <IP address of the unit>**.
4. Enter the **User Name** and **Password**. The default username is “**admin**” and the default password is “**public**”. The username and password are case-sensitive.
5. From here proceed further to configure the device interface.

You can enter Command Statements, composed of CLI Commands and their associated parameters. Statements may be issued from the keyboard for real time control, or from scripts that automate configuration.

For example, when downloading a file, administrators enter the **download** CLI Command along with IP Address, file name, and file type parameters.

You can access the CLI over a HyperTerminal serial connection or via Telnet. During initial configuration, you can use the CLI over a serial port connection to configure an Access Point's IP address. When accessing the CLI via Telnet, you can communicate with the Access Point from over your LAN (switch, hub, etc.), from over the Internet, or with a "crossover" Ethernet cable connected directly to your computer's Ethernet Port. See [Using CLI to Manage the Access Point](#) for more information on the CLI and for a list of CLI commands and parameters.

SNMP Management

In addition to the HTTP and the CLI interfaces, you can also manage and configure an AP using the Simple Network Management Protocol (SNMP). Note that this requires an SNMP manager program. The AP supports following Management Information Base (MIB) files that describe the parameters that can be viewed and/or configured over SNMP:

- MIB-II (RFC 1213)
- Proxim Enterprise MIB

Proxim provides these MIB files on its support site <http://support.proxim.com>. You need to logon to the support site and use the Answer ID: 2814 to locate the MIB. You need to compile one or more of the above MIBs into your SNMP program's database before you can manage an Access Point using SNMP.

The Enterprise MIB defines the read and read-write objects that can be viewed or configured using SNMP. These objects correspond to most of the settings and statistics that are available with the other management interfaces. See the Enterprise MIB for more information; the MIB can be opened with any text editor, such as Microsoft Word, Notepad, or WordPad.

SSH (Secure Shell) Management

You may securely also manage the AP using SSH (Secure Shell). The AP supports SSH version 2, for secure remote CLI (Telnet) sessions. SSH provides strong authentication and encryption of session data.

The SSH server (AP) has host keys - a pair of asymmetric keys - a private key that resides on the AP and a public key that is distributed to clients that need to connect to the AP. As the client has knowledge of the server host keys, the client can verify that it is communicating with the correct SSH server.

HyperTerminal

HyperTerminal is a program that you can use to connect to other computers, Telnet sites, and bulletin board systems (BBSs), online services, and host computers, using either your modem or a null modem cable.

- If you are using RS-232 cable, verify the following information in the Hyper Terminal Serial Port Setup:

Port	COM1 (default)
Baud Rate	115200
Data	8-bit
Parity	None
Stop	1-bit
Flow Content	NONE

- Log in to the device using the default **User Name** as “**admin**” and **Password** as “**public**”. The username and password are case sensitive. The Home page displays.

NOTE: *The User Name and Password are case-sensitive*

ProximVision ES

Using ProximVision ES you can discover and manage your AP-800 device. For more information, refer to the PVES User Guide.

4

Basic Configuration for an Enterprise

This chapter describes the initial configuration of the Access Point using the web-browser. By default, the pre-configured Access Point can be accessed, but as an enterprise user, you can modify the default settings of the Access Point to provide a secure access for your enterprise.

In this chapter, following sections are included:

- [Configuring Basic Settings for the Access Point](#)
 - [Finding and Assigning the Access Point's IP Address](#)
- [Configuring the System Name and the Country Code](#)
- [Configuring the Wireless Information](#)
- [Configuring the Operational Mode](#)
- [Password Management](#)
- [Configuring the Security Profile](#)

Configuring Basic Settings for the Access Point

Follow these steps to access the Access Point's default settings:

1. Connect the Access Point as described in the Quick Install Guide (QIG) which is available along with the product package.
2. You will follow these steps to enter the access point's basic settings.
3. Once you have updated all the required information, ensure that you click **COMMIT** and then click **REBOOT** to update the changes.

Finding and Assigning the Access Point's IP Address

1. If your Access Point receives an IP address from the DHCP server on the network, then use the ScanTool to find its IP address.
2. Navigate **Configuration > Network IP Config** page to set IP address.
 - Select the **Address Type** either **Static** or **Dynamic**.
 - You must assign unique **IP Address** for your device that is valid on your IP subnet, this would be based on the Address Type that you have selected.

NOTE: Contact your network administrator if you need assistance in selecting an IP address for the unit.

- Ensure that you also provide your network's Subnet Mask, and Gateway IP address.
- Click **OK** to save your changes.

Configuring the System Name and the Country Code

1. Navigate **Management > System > Information** to configure the System information.
2. Enter the following parameters:
 - **System Name**
 - **System Location**

- Select the **Country Code** using the drop-down list. This field displays the country in which the AP will be used. Setting the country makes the AP automatically compliant with the rules of the regulatory domain in which it is used by configuring the allowed frequency bands, channels, Dynamic Frequency Selection Status, Transmit Power Control status, and power levels.
- Click **OK**.

Configuring the Wireless Information

1. Navigate to Configuration page to configure the Wireless information. Navigate to **Configuration > Wireless > Interface 1 > VAP**.

NOTE: By default both the interfaces are active. If you want, you can change the default values for a single interface.

2. Click on the radio button of the index for which you want to make the changes, click Edit.
3. Configure the following parameters:
 - Enter the **VAP SSID Name** (wireless network name).
 - Enter the **Security Profile Name**.
 - Enter **Radius Profile Name**.

4. Click **OK**.

NOTE: Follow the above mentioned steps if you want to configure VAP for Interface 2.

Configuring the Operational Mode

1. Click **Configuration > Wireless > Interface 1 > Properties**. Configure the following parameters:

- **Status:** Check the Status checkbox to enable the wireless interface properties.
- **Operational Mode:** Select the Operational Mode. This field indicates the operational mode of the unit.

NOTE: The most effective configuration for mixed mode is to install two radios in each Access Point. Place the 802.11b/g traffic on 2.4 GHz radio and 802.11n only on 5 GHz radio.

- **Current Channel Bandwidth:** Select the channel bandwidth. By default it is set to 40 MHz.
- **Auto Channel selection:** Enable or disable the auto channel selection for wireless interface.
- **Current Operating Channel:** This will display the current operating channel on which wireless interface is operating. If you have enabled the auto channel selection option, then this field will select the channel automatically and also list out the other channels that are available.
- Click **OK**.

NOTE: Follow the above mentioned steps to configure Properties for Interface 2.

Password Management

As soon as you login, ensure that you change the default passwords of the device. To change the password, navigate to **Management > Management Services**.

- **HTTP (Web) Password:** The password for the Web browser HTTP interface. Enter a password in the Password field and enter the Port number. The default password is **“public”**.
- **Telnet (CLI) Password:** The password for the CLI interface (via serial or Telnet). Enter a password between 6 and 32 characters in the Password field. The default password is **“public”**.
- **SNMP Read Community Password:** The password for read access to the AP using SNMP. Enter a password between 6 and 32 characters in both the Password field and the Confirm field. The default password is **“public”**.

- **SNMP Read/Write Community Password:** The password for read and write access to the AP using SNMP. Enter a password between 6 and 32 characters in both the Password field and the Confirm field. The default password is “public”.
- **SNMP Trap Host Table:** Enter the IP Address and password in the Password field. By default, an IP Address and IP Mask will be available, that you can change. The password available in the IP Mask is the same as the SNMP Read/Write Password.

NOTE: For security purposes Proxim recommends changing ALL PASSWORDS from the default “public” immediately, to restrict access to your network devices to authorized personnel.

Configuring the Security Profile

1. Click **Configuration > Security > Wireless Security**.
2. Click **Add** in the **Wireless Security CFG** table to create a new entry. The **Wireless Security Create Row** page displays.
3. Enter the **Profile Name**.
4. **Authentication Mode:** Configure one or more types of security modes that are allowed to access to the AP under the security profile. The WEP/PSK parameters are separately configurable for each authentication mode. To enable a security mode in the profile (Non Secure Station, WEP Station, 802.1x Station, WPA Station, WPA-PSK Station, 802.11i (WPA2) Station, 802.11i-PSK Station), select the option from the Entry status drop-down box.

If the authentication mode selected in a profile is WEP, WPA-PSK, or 802.11i-PSK, then you must configure the WEP or Pre-Shared Keys.

NOTE: If an 802.1x client that has already been authenticated attempts to switch to WEP, or if a WEP client that has already been connected attempts to switch to 802.1x, the AP will not allow the client to switch immediately. If this happens, either reboot the AP or disable the client/roam to a new AP for five minutes, and then attempt to reconnect to the AP. If the client is still unable to connect after waiting five minutes, reboot the AP.

NOTE: If you select WEP or TKIP, then the device will work on legacy rates not on 11n rates.

- **Authentication Mode: None**, the AP allows access to Stations without authentication.
- **Authentication Mode: WEP**
 - **Wep Key:** Enter the Wep Key. The Key Length can be 64 or 128 Bits.
 - For 64-bit encryption, an encryption key is 10 hexadecimal characters (0-9 and A-F) or 5 ASCII characters (see ASCII Character Chart).
 - For 128-bit encryption, an encryption key is 26 hexadecimal characters or 13 ASCII characters.
 - **Encryption Type:** Select the Encryption type as **WEP**.
 - Enter the **Status**.
- **Authentication Mode: Psk**
 - **Encryption Type:** WPA-TKIP, WPA2-AES, WPA-TKIP + WPA2-AES
 - **PSK :** Enter the password. The limit for the passphrase is between 8 and 63 characters
 - Enter **Status**.

NOTE: When you select the encryption type as WPA-TKIP+WPA2-EAS, then the AP is considered to be in Auto-Encryption mode, and the client will support both encryption type.

- **Authentication Mode: 802.1x**
 - **Encryption Type:** WPA-TKIP, WPA2-AES, WPA-TKIP + WPA2-AES
 - Enter **Status**.

NOTE: When you select the encryption type as WPA-TKIP+WPA2-EAS, then the AP is considered to be in Auto-Encryption mode, and the client will support both encryption type.

5. When finished configuring all parameters, click **Add**.
6. If you have selected a security profile of 802.1x, then you must configure a RADIUS 802.1x/EAP server. See. RADIUS profile.

NOTE: *Ensure that you assign the newly configured Security profiles to VAP.*

7. Click **COMMIT** and **REBOOT** to update the changes.

Access Point Features

This chapter provides you information about the features of the Access Point:

- [Configuring the Device](#)
- [Managing the Device](#)
- [Monitoring the Device](#)

Configuring the Device

Following features are available under Device Configuration:

Wireless

The wireless feature of the Access Point enables you to use the new technology called **Multiple Input Multiple Output (MIMO)**, that uses several antennas to transfer multiple data streams. In this way more data can be transferred in the same period of time. The wireless architecture is based on the cellular architecture where the systems are divided into cells, and each cell is called the BSS, that Base Station called Access Point (AP) controls.

The Wireless LAN (WLAN) can be formed of a single cell or of many cells . Each of the WLAN has an entry point which is called Virtual Access Point (VAP), which has a unique BSSID and other relevant protocols that make these VAP as independent entity. Each of the BSSID can be configured independly so that the user can provide unique authentication and security feature.

VAP Features

- **VAP(Virtual Access Point):** This is a logical entity that exists within the physical WLAN access device. The VAP enables a single device to be divided into layers and each layer gets assigned to different users with their usage rights.
- **VAP SSID (Service Set Identifier):** An SSID is referred as a network name which is unique and a wireless network is identified by this SSID which is assigned to it. In other words, this specifies which wireless network to access and this enables communication between users and the Access Point.
- **VAP BSSID:** This parameter represents the MAC address for the VAP BSSID.
- **VAP Broadcast SSID:** The continuous announcement by an Access Point that it is running and is available is called the Broadcast SSID. The SSID is broadcasted in beacons and probe response frames. Broadcasting the SSID also depends on the type of network that is the AP is running on. You can disable the SSID broadcast in then AP and change the default SSID to an obscure one.
- **Fragmentation Threshold:** The process of dividing a MAC Service Data Unit (MSDU) into smaller MAC level frames for transmission over the wireless network is called fragmentation. This technique reduces both the probability and adverse effects of wireless packet corruption, and thereby improving the overall wireless network performance. You can fragment the Unicast receiver address, whereas Broadcast/Multicast frames cannot be fragmented, even though they exceed a fragmentation threshold. You can configure fragmentation threshold up to 2346 bytes.
- **Security Profile Name:** This parameter allows you to configure the Security profile name for Wireless VAP. It has to be a valid security profile configured under Wireless Security.
- **RADIUS Profile Name:** This parameter allows you to configure the RADIUS profile name for Wireless VAP. It has to be a valid Radius profile configured under Security.
- **VLAN ID:** This parameter is used to represent the VLAN ID for the wireless VAP. Select any value between 1 - 4094 to tag the VLAN ids and -1 to untag the VLAN ids. From VLAN perspective this port acts as a Access Port.

- **VLAN Priority:** This parameter is used to configure the VLAN priority for Wireless VAP. By default the value is set to 0.
- **QoS Profile Name:** This parameter is used to configure the profile name for the Wireless VAP QoS.
- **Local MAC Authentication:** This parameter is used to enable or disable the local MAC access control list.
- **RADIUS MAC Authentication:** This parameter is used to enable or disable the MAC ACL for RADIUS Profiles.
- **RADIUS Accounting:** This parameter is used to enable or disable the RADIUS Accounting Status.

Properties Features

- **Operational Mode:** This parameter is used to set the wireless NIC Operational mode. Depending on the wireless NIC in the device different wireless operational modes can be configured.
- **Current Bandwidth:** This parameter represents the current bandwidth that Wireless is currently operating on. It is represented in MHz"
- **Auto Channel Selection:** This parameter of the AP allows the device to select the channel on its own that is least congested.
- **Current Operating Channel:** This will display the current operating channel on which wireless interface is operating.
- **Auto Rate Selection:** This parameter is used to configure the value for Auto Rate Selection for the wireless interface. For an Access Point this value is always "Auto".
- **RTS Threshold (Request to Send Threshold).** This parameter affects message flow control and should not be changed under normal circumstances. The range for this field is between 0 to 2346. When set to a value between 0 and 2346, the Access Point uses the RTS mechanism for packets that are the specified size or greater. When set to **2346 (the default setting)**, RTS is disabled.
- **Beacon Interval:** The Beacon interval specifies the interval time between two successive beacons transmission. You can set the value for Beacon interval between 100 ms and 1000ms for each beacon transmission.
- **TPC:** The unit transmits the maximum output power for the country or regulatory domain and frequency selected. However, with Transmit Power Control (TPC), you can adjust the output power of the unit to a lower level in order to reduce interference to neighboring devices or to use a higher gain antenna without violating the maximum radiated output power allowed for your country.
- **Cell Size:** The cell size setting is a valuable feature for achieving maximum bandwidth in a wireless network. It is in dBm.
- **DTIM:** The Delivery Traffic Indicator Map (DTIM) timer determines how frequently the station must leave power save mode and determine if the traffic is lining up for it. You can set the DTIM interval based on the applications that are being used on the network.

11n Properties Features

- **11n AMPDU (Aggregated MAC Protocol Data Unit) Status:** AMPDU (Aggregated MAC Protocol Data Unit) specifies the aggregation of several MAC frames into a single large frame to achieve higher throughput.
- **AMPDU Max Num Frames:** This field represents the AMPDU frames that are transmitted as a single PSDU by the PHY. It can be configured up to 64 frames.
- **AMPDU Max FrameSize:** This parameter is used to configure the maximum AMPDU frame size (in bytes) that can be transmitted.
- **11n AMSDU (Aggregated MAC Service Data Unit) Status:** This parameter is used define the AMSDU status for wireless 11n interface.
- **Frequency Extension:** This parameter is used to configure the frequency extension for the wireless interface.
- **Guard Interval:** Guard Interval ensures that distinct transmissions do not interfere with one another. This feature provides immunity to users. Each user is allotted a time slot to transmit their data and this time slot ends with the guard interval. This parameter is used to configure the guard interval for the wireless interface.
- **Tx Antennas:** This parameter enables the transmission antennas. This is configured as bit-mask. Eg: 3 - 011 (binary value) - first and second antennas are enabled. 7 - 111 (binary value) - all three are enabled.

- **Rx Antennas:** This parameter enables the receiving antennas. This is configured as bit-mask. Eg: 3 - 011 (binary value) - first and second antennas are enabled. 7 - 111 (binary value) - all three are enabled.

Decimal	Binary	Active Antennas
1	001	First Antenna
2	010	Second Antenna
3	011	First and Second Antenna
4	100	Third Antenna
5	101	Third and First Antenna
6	110	Third and Second Antenna
7	111	First, Second and Third Antenna

Ethernet

The Ethernet feature is the most popular physical layer LAN technology is popular because it strikes a good balance between speed, cost and ease of installation. Because of these benefits it is an ideal networking technology for the computer users. Using this feature you can view the properties of the Ethernet of your network.

Ethernet Features

- **MAC Address:** This parameter represents the MAC address of the Ethernet interface.
- **Speed:** This parameter is used for configuring the speed of the Ethernet interface.
- **Transmit:** This parameter is used for configuring the transmit mode of the Ethernet interface.

Security

The AP supports the following security features:

- **WEP Encryptions**

The IEEE 802.11 standards specify an optional encryption feature, known as Wired Equivalent Privacy or WEP, that is designed to provide a wireless LAN with a security level equal to what is found on a wired Ethernet network. WEP encrypts the data portion of each packet exchanged on an 802.11 network using an Encryption Key (also known as a WEP Key).

When Encryption is enabled, two 802.11 devices must have the same Encryption Keys and both devices must be configured to use Encryption in order to communicate. If one device is configured to use Encryption but a second device is not, then the two devices will not communicate, even if both devices have the same Encryption Keys.

- **802.1x Authentication**

IEEE 802.1x is a standard that provides a means to authenticate and authorize network devices attached to a LAN port. A port in the context of IEEE 802.1x is a point of attachment to the LAN, either a physical Ethernet connection or a wireless link to an Access Point. 802.1x requires a RADIUS server and uses the Extensible Authentication Protocol (EAP) as a standards-based authentication framework, and supports automatic key distribution for enhanced security. The EAP-based authentication framework can easily be upgraded to keep pace with future EAP types.

Popular EAP types include:

- EAP-Message Digest 5 (MD5): Username/Password-based authentication; does not support automatic key distribution
- EAP-Transport Layer Security (TLS): Certificate-based authentication (a certificate is required on the server and each client); supports automatic key distribution

- EAP-Tunneled Transport Layer Security (TTLS): Certificate-based authentication (a certificate is required on the server; a client's username/password is tunneled to the server over a secure connection); supports automatic key distribution
- PEAP - Protected EAP with MS-CHAP: Secure username/password-based authentication; supports automatic key distribution

Different servers support different EAP types and each EAP type provides different features. See the documentation that came with your RADIUS server to determine which EAP types it supports.

NOTE: *The AP supports the following EAP types when Security Mode is set to 802.1x, WPA, or 802.11i (WPA2): EAP-TLS, PEAP, EAP-TTLS, EAP-MD5, and EAP-SIM.*

Authentication Process

There are three main components in the authentication process. The standard refers to them as:

1. Supplicant (client PC)
2. Authenticator (Access Point)
3. Authentication server (RADIUS server)

When the Security Mode is set to 802.1x Station, WPA Station, or 802.11i Station you need to configure your RADIUS server for authentication purposes.

Prior to successful authentication, an unauthenticated client PC cannot send any data traffic through the AP device to other systems on the LAN. The AP inhibits all data traffic from a particular client PC until the client PC is authenticated. Regardless of its authentication status, a client PC can always exchange 802.1x messages in the clear with the AP (the client begins encrypting data after it has been authenticated).

The AP acts as a pass-through device to facilitate communications between the client PC and the RADIUS server. The AP (2) and the client (1) exchange 802.1x messages using an EAPOL (EAP Over LAN) protocol (A). Messages sent from the client station are encapsulated by the AP and transmitted to the RADIUS (3) server using EAP extensions (B).

Upon receiving a reply EAP packet from the RADIUS, the message is typically forwarded to the client, after translating it back to the EAPOL format. Negotiations take place between the client and the RADIUS server. After the client has been successfully authenticated, the client receives an Encryption Key from the AP (if the EAP type supports automatic key distribution). The client uses this key to encrypt data after it has been authenticated.

For 802.11b/g clients that communicate with an AP, each client receives its own unique encryption key; this is known as Per User Per Session Encryption Keys.

- **Wi-Fi Protected Access (WPA/802.11i [WPA2])**

Wi-Fi Protected Access (WPA) is a security standard designed by the Wi-Fi Alliance in conjunction with the Institute of Electrical and Electronics Engineers (IEEE). The AP supports 802.11i (WPA2), based on the IEEE 802.11i security standard.

WPA is a replacement for Wired Equivalent Privacy (WEP), the encryption technique specified by the original 802.11 standard. WEP has several vulnerabilities that have been widely publicized. WPA addresses these weaknesses and provides a stronger security system to protect wireless networks.

WPA provides the following new security measures not available with WEP:

- Improved packet encryption using the Temporal Key Integrity Protocol (TKIP) and the Michael Message Integrity Check (MIC).
- Per-user, per-session dynamic encryption keys:
 - Each client uses a different key to encrypt and decrypt unicast packets exchanged with the AP
 - A client's key is different for every session; it changes each time the client associates with an AP
 - The AP uses a single global key to encrypt broadcast packets that are sent to all clients simultaneously
 - Encryption keys change periodically based on the Re-keying Interval parameter

- WPA uses 128-bit encryption keys
- Dynamic Key distribution
 - The AP generates and maintains the keys for its clients
 - The AP securely delivers the appropriate keys to its clients
- Client/server mutual authentication
 - 802.1x
 - Pre-shared key (for networks that do not have an 802.1x solution implemented)

The AP supports the following WPA security modes:

- **WPA:** The AP uses 802.1x to authenticate clients and TKIP for encryption. You should only use an EAP that supports mutual authentication and session key generation, such as EAP-TLS, EAP-TTLS, and PEAP. See [802.1x Authentication](#) for details.
- **WPA-PSK (Pre-Shared Key):** For networks that do not have 802.1x implemented, you can configure the AP to authenticate clients based on a Pre-Shared Key. This is a shared secret that is manually configured on the AP and each of its clients. The Pre-Shared Key must be 256 bits long, which is either 64 hexadecimal digits or 32 alphanumeric characters. The AP also supports a PSK Pass Phrase option to facilitate the creation of the TKIP Pre-Shared Key (so a user can enter an easy-to-remember phrase rather than a string of characters).
- **802.11i (also known as WPA2):** The AP provides security to clients according to the 802.11i standard, using 802.1x authentication, a CCMP cipher based on AES, and re-keying.
- **802.11i-PSK (also known as WPA2 PSK):** The AP uses a CCMP cipher based on AES, and encrypts frames to clients based on a Pre-Shared Key. The Pre-Shared Key must be 256 bits long, which is either 64 hexadecimal digits or 32 alphanumeric characters. The AP also supports a PSK Pass Phrase option to facilitate the creation of the Pre-Shared Key (so a user can enter an easy-to-remember phrase rather than a string of characters).

NOTE: For more information on WPA, see the Wi-Fi Alliance Web site at <http://www.wi-fi.org>.

Recommended Security Profiles

Proxim recommends to configure following combination of the security profiles:

- MAC-ACL + WEP/WPA-PSK

If you have enabled the MAC-ACL as Local MAC Authentication, then you need to ensure that you have the combination of WEP/WPA-PSK security profile. Once you enable the MAC-ACL authentication then based on the MAC-ACL policy the client will get connected.

- Radius-MAC + WEP/WPA-PSK

If you have enabled RADIUS-MAC as RADIUS-MAC Authentication, then you need to ensure that you have the combination of WEP/WPA-PSK security profile. If you enable RADIUS-MAC, then ensure that RADIUS Authentication server is configured.

- WPA2/WPA

CAUTION: Proxim recommends not to enable both Local MAC Authentication and RADIUS-MAC Authentication.

Configuring Security Profiles

Security policies can be configured and applied on the AP as a whole, or on a per SSID basis. When VLAN is disabled on the AP, the user can configure a security profile for each interface of the AP. You can configure a security profile for each VLAN.

The user defines a security policy by specifying one or more values for the following parameters:

- Wireless STA types (WPA station, 802.11i (WPA2) station, WPA-PSK, and 802.11i-PSK) that can associate to the AP.
- Authentication mechanisms (802.1x) that are used to authenticate clients for each type of station.
- Cipher Suites (AES, TKIP, WEP, None) used for encapsulating the wireless data for each type of station.

NOTE: If you select WEP or TKIP, then the device will work on legacy rates not on 11n rates.

AP-8000 supports up to 16 security profiles and can be mapped to any of the VAPs. You can apply unique security profiles to VAPs without enabling the VLAN.

Wireless Security Features

- **Profile Name:** This parameter represents the name of the security profile name.
- **Authentication Mode:** This parameter is used to configure the security authentication mode for wireless.
- **WEP Key:** This parameter is used to configure the Wep key for wireless security.
- **Encryption Type:** This parameter is used to configure the type of encryption for the wireless security.
- **PSK:** This is the read parameter and used to display the security key in asterisk.
- **Rekeying Interval:** This parameter represents the time interval within which the number of times the key is changed.

RADIUS

Configuring Radius Profiles on the AP allows the administrator to define a profile for RADIUS Servers used by the system or by a VLAN.

The network administrator can configure default RADIUS authentication servers to be used on a system-wide basis, or in networks with VLANs enabled the administrator can also configure separate authentication servers to be used for MAC authentication, 802.1x authentication, or RADIUS based accounting. If the back-up server are configured, then the AP will communicate with the back-up server till the primary server is offline.

The AP communicates with the RADIUS server defined in a profile to provide the following features:

MAC Access Control Via RADIUS Authentication

If you want to control wireless access to the network and if your network includes a RADIUS Server, you can store the list of MAC addresses on the RADIUS server rather than configure each AP individually. you can define a RADIUS profile that specifies the IP Address of the server that contains a central list of MAC Address values identifying the authorized stations that may access the wireless network. You must specify information for the least primary RADIUS server. The back-up server is optional.

NOTE: Each VLAN can be configured to use a separate RADIUS server (and backup server) for MAC authentication. MAC access control can be separately enabled for each VLAN.

802.1x Authentication using RADIUS

You must configure a primary EAP/802.1x Authentication server to use 802.1x security. A back-up server is optional.

NOTE: Each VLAN can be configured to use a separate RADIUS server (and back-up server) for 802.1x authentication. 802.1x authentication ("EAP authentication") can be separately enabled for each VLAN.

RADIUS Accounting

Using an external RADIUS server, the AP can track and record the length of client sessions on the access point by sending the RADIUS accounting messages per RFC2866. When a wireless client is successfully authenticated, RADIUS accounting is initiated by sending an "Accounting Start" request to the RADIUS server. When the wireless client session ends, an "Accounting Stop" request is sent to the RADIUS server.

NOTE: Each VLAN can be configured to use a separate RADIUS accounting server (and backup accounting server).

Session Length

Accounting sessions continue when a client reauthenticates to the same AP. Sessions are terminated when:

- A client disassociates
- Idle-Timeout or Session-Timeout attributes are configured in the Radius server.

If the client roams from one AP to another, one session is terminated and a new session begins.

NOTE: *This feature requires RADIUS authentication using MAC Access Control or 802.1x. Wireless clients configured in the Access Point's static MAC Access Control list are not tracked.*

Authentication Attributes

- User-Name

This Attribute indicates the name of the user that needs to be authenticated. It must be sent in Access-Request packets if available.

- User-Password

This Attribute indicates the password of the user to be authenticated, or the user's input following an Access-Challenge. It is only used in Access-Request packets.

- NAS-IP-Address

This Attribute indicates the identifying IP Address of the NAS which is requesting authentication of the user, and should be unique to the NAS within the scope of the RADIUS server. NAS-IP-Address is only used in Access-Request packets.

- State

This Attribute is available to be sent by the server to the client in an Access-Challenge and must be sent unmodified from the client to the server in the new Access-Request reply to that challenge, if any.

- Class

This Attribute is available to be sent by the server to the client in an Access-Accept and should be sent unmodified by the client to the accounting server as part of the Accounting-Request packet if accounting is supported.

- Session-Timeout

This Attribute sets the maximum number of seconds of service to be provided to the user before termination of the session or prompt. This Attribute is available to be sent by the server to the client in an Access-Accept or Access-Challenge.

- Termination-Action

This Attribute indicates what action the NAS should take when the specified service is completed. It is only used in Access-Accept packets.

- Called-Station-Id

This Attribute allows the NAS to send in the Access-Request packet the phone number that the user called, using Dialed Number Identification (DNIS) or similar technology. It is only used in Access-Request packets.

- Calling-Station-Id

This Attribute allows the NAS to send in the Access-Request packet the phone number that the call came from, using Automatic Number Identification (ANI) or similar technology. It is only used in Access-Request packets.

- Acct-Interim-Interval

Obtained during the Authentication process and used for determining the time interval for sending Accounting Update messages. If this attribute is not obtained from the Radius Server, the AP uses default value of 300 seconds for updating the accounting messages.

Accounting Attributes

- Acct-Status-Type

This attribute indicates whether this Accounting-Request marks the beginning of the user service (Start) or the end (Stop).

- **Acct-Input-Octets**

This attribute indicates how many octets have been received from the port over the course of this service being provided, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

- **Acct-Output-Octets**

This attribute indicates how many octets have been sent to the port in the course of delivering this service, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

- **Acct-Session-Id**

This attribute is a unique Accounting ID to make it easy to match start and stop records in a log file. The start and stop records for a given session will have the same Acct-Session-Id.

- **Acct-Authentic**

This attribute is included in an Accounting-Request to indicate how the user was authenticated, whether by RADIUS, the NAS itself, or another remote authentication protocol.

- **Acct-Session-Time**

This attribute indicates how many seconds the user has received service for, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

- **Acct-Input-Packets**

This attribute indicates how many packets have been received from the port over the course of this service being provided to a Framed User, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

- **Acct-Output-Packets**

This attribute indicates how many packets have been sent to the port in the course of delivering this service to a Framed User, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

- **Acct-Terminate-Cause**

This attribute indicates how the session was terminated, and can only be present in Accounting-Request records where the Acct-Status-Type is set to Stop.

RADIUS Features

The parameters that can be configured:

- **Profile Name:** This parameter provides the RADIUS profile name.
- **Max ReTransmissions:** This parameter represents the maximum number of RADIUS Access requests messages transmitted from the client to server since the client startup.
- **Message Response Time:** This parameter represents the response time in seconds that the AP should wait for the RADIUS server to respond to a request. The range is between 1-10 seconds.
- **ReAuthentication Period:** This parameter represents the number of authentication requests transmitted from the client to server since the client setup.

You have four radius profiles available for configurations:

- **Server Type:** There are four radius profiles available for configurations: Primary Authentication Server, Secondary Authentication Server, Primary Accounting Server, and Secondary Accounting Server.
- **IP Address:** The parameter represents the IP address of the Radius servers.
- **Server Port:** This parameter represents the port number which the AP and the server will use to communicate.
- **Shared Secret:** This parameter represents the password shared by the RADIUS server and the AP. It must be the same password that is configured on the RADIUS server.

MAC ACL Features

- **Operation Type:** This parameter is used for configuring the type the MAC ACL profile that can be allowed or denied.

While adding the MAC ACL row, following are the parameters:

- **MAC Address:** This parameter represents the valid MAC address of the MAC ACL.
- **Comment:** This parameter is an optional and is used for entering a comment.

QoS

Wi-Fi Multimedia (WMM)/Quality of Service (QoS) Introduction

The AP supports Wi-Fi Multimedia (WMM), which is a solution for QoS functionality based on the IEEE 802.11e specification. WMM defines enhancements to the MAC for wireless LAN applications with Quality of Service requirements, which include transport of voice and video traffic over IEEE 802.11 wireless LANs.

The enhancement are in the form of changes in protocol frame formats (addition of new fields and information elements) addition of new messages, definition of new protocol actions, channel access mechanisms (differentiated control of access to medium) and network elements (QoS/WME aware APs, STAs), and configuration management.

WME supports Enhanced Distributed Channel Access (EDCA) for prioritized QoS services. The WME/QoS feature can be enabled or disabled per VAP.

Enhanced Distributed Channel Access (EDCA)

WME uses Enhanced Distributed Channel Access, a prioritized CSMA/CA access mechanism used by WME-enabled clients/AP in a WME enabled BSS to realize different classes of differentiated Channel Access.

A wireless Entity is defined as all wireless clients and APs in the wireless medium contending for the common wireless medium. EDCA uses a separate channel access function for each of the Access Categories (Index) within a wireless entity. Each channel access function in a wireless entity that contends for the wireless medium as if it were a separate client contending for the wireless medium. Different channel access functions in a given Wireless Entity contend among themselves for access to the wireless medium in addition to contending with other clients.

STA EDCA Table and AP EDCA Table

This page is used to configure the client (STA) and AP Enhanced Distributed Channel Access (EDCA) parameters. You can modify the EDCA values for Wireless.

The EDCA parameter set provides information needed by the client stations for proper QoS operation during the wireless contention period. These parameters are used by the QoS enabled AP to establish policy, to change policies when accepting new stations or new traffic, or to adapt to changes in the offered load. The EDCA parameters assign priorities to traffic types where higher priority packets gain access to the wireless medium more frequently than lower priority packets.

NOTE: *Default recommended values for EDCA parameters have been defined; Proxim recommends not to modify EDCA parameters unless strictly necessary.*

QoS EDCA Features

- **Profile Name:** This parameter is used to displays the name for the Wireless QoS EDCA profile.
- **STA CW Min:** This parameter is used to configure the minimum value for CW for the wireless QoS EDCA profile.
- **STA CW Max:** This parameter is used to configure the maximum value for CW for the wireless QoS EDCA profile.
- **STA AI FSN:** This parameter is used for configure the AIFSN value for the wireless QoS EDCA profile.
- **STA TXOP:** The parameter is used to configure TXOP value for wireless QoS EDCA profile.
- **STA ACM:** This parameter is used to configure the status for ACM.
- **AP CW Min:** This parameter is used to configure the minimum value for CW for the AP.

- **AP CW Max:** This parameter is used to configure the maximum value for CW for the AP.
- **AP TXOP:** This parameter is used to configure the TXOP value for the AP.
- **AP ACM:** This parameter is used to configure the status of the APACM for the QoS EDCA profile.

802.1D to IP DSCP Mapping Table Features

- **801.1D to IPDSCP index:** This parameter is used to specify the 802.1
- **Lower Limit:** This parameter is used to specify IP DSCP lower limit.
- **Upper Limit:** This parameter is used to specify IP DSCP upper limit.

802.1D to 802.1p Mapping Table Features

- **801.1D Priority:** This parameter is used to specify the 802.1d priority and is used as the secondary index to the 802.1D to 802.1p mapping table.
- **802.1p Priority:** The parameter is used to specify the 802.1D to be mapped to a 802.1p priority.

QoS Profile Features

- **QoS Profile Name:** This parameter displays the name of the QoS profile name that been assigned.
- **Policy Name:** This parameter displays the QoS Policy profile name.
- **EDCA Profile Name:** This parameter displays the name of the QoS EDCA profile name.
- **QoS NACK Status:** This parameter is used to configure the status of the QoS profile ACK status.

QoS Policy Features

- **Policy Name:** This parameter displays the policy name.
- **Policy Type:** This parameter is used to configure the QoS type. Policy type can be configured for the following; Inbound Layer2, Inbound Layer3, Outbound Layer2, and Outbound Layer3.
- **Priority Mapping:** This parameter is used for configuring the primary index to the QoS 802.1D to 802.1p mapping table.
- **Marking Status:** This parameter is used to enable or disable the QoS marking.

IP Configuration

The network (internet (TCP/IP)) settings for the Access Point can be either entered manually (static IP address, subnet mask, and gateway IP address) or obtained automatically (dynamic).

- **Address Type:** Set this parameter to **Dynamic** to configure the Access Point as a Dynamic Host Configuration Protocol (DHCP) client; the Access Point will obtain IP settings from a network DHCP server automatically during the boot-up. If you do not have a DHCP server or if you want to manually configure the Access Point's IP settings, set this parameter to **Static**.
- **IP Address:** This parameter represents the IP Address of the Access Point. When IP Address Assignment Type is set to Dynamic, this field is read-only and reports the unit's current IP address. The Access Point will default to 169.254.128.132, if it cannot obtain an address from a DHCP server.
- **Subnet Mask:** The Access Point's subnet mask. When Address Type is set to Dynamic, this field is read-only and reports the unit's current subnet mask. The subnet mask will default to 255.255.0.0 if the unit cannot obtain one from a DHCP server.
- **Gateway IP Address:** The IP address of the Access Point's gateway. When Address Type is set to Dynamic, this field is read-only and reports the IP address of the unit's gateway. The gateway IP address will default to 169.254.128.133 if the unit cannot obtain an address from a DHCP server.

VLAN

Virtual Local Area Networks (VLANs) are logical groupings of network hosts. Defined by software settings, other VLAN members or resources appear (to clients) to be on the same physical segment, no matter where they are attached on the logical LAN or WAN segment. They simplify traffic flow between clients and their frequently-used or restricted resources.

VLANs now extend as far as the reach of the Access Point signal. Clients can be segmented into wireless sub-networks via SSID and VLAN assignment. A Client can access the network by connecting to an AP configured to support its assigned SSID/VLAN.

AP devices are fully VLAN-ready; however, by default VLAN support is disabled. Before enabling VLAN support, certain network settings should be configured, and network resources such as a VLAN-aware switch, a RADIUS server, and possibly a DHCP server should be available.

Once enabled, VLANs are used to conveniently, efficiently, and easily manage your network in the following ways:

- Manage adds, moves, and changes from a single point of contact
- Define and monitor groups
- Reduce broadcast and multicast traffic to unnecessary destinations
 - Improve network performance and reduce latency
- Increase security
 - Secure network restricts members to resources on their own VLAN
 - Clients roam without compromising security

VLAN tagged data is collected and distributed through an AP's wireless interface(s) based on Network Name (SSID). An Ethernet port on the Access Point connects a wireless cell or network to a wired backbone. The Access Points communicate across a VLAN-capable switch that analyzes VLAN-tagged packet headers and directs traffic to the appropriate ports. On the wired network, a RADIUS server authenticates traffic and a DHCP server manages IP addresses for the VLAN(s). Resources like servers and printers may be present, and a hub may include multiple APs, extending the network over a larger area.

Access Points that are not VLAN-capable typically transmit broadcast and multicast traffic to all wireless Network Interface Cards (NICs). This process wastes wireless bandwidth and degrades throughput performance. In comparison, a VLAN-capable AP is designed to efficiently manage delivery of broadcast, multicast, and unicast traffic to wireless clients.

The AP assigns clients to a VLAN based on a Network Name (SSID). The AP can support up to 4 SSIDs per radio, and multiple SSIDs can have same VLAN Id.

NOTE: *It is not required that each VLAN ID should have unique VAP ID.*

The AP matches packets transmitted or received to a network name with the associated VLAN. Traffic received by a VLAN is only sent on the wireless interface associated with that same VLAN. This eliminates unnecessary traffic on the wireless LAN, conserving bandwidth and maximizing throughput.

Typical User VLAN Configurations

VLANs segment network traffic into workgroups, which enable you to limit broadcast and multicast traffic. Workgroups enable clients from different VLANs to access different resources using the same network infrastructure. Clients using the same physical network are limited to those resources available to their workgroup.

The AP can segment users into a maximum of 4 different workgroups per radio, based on an SSID/VLAN grouping.

The VLANs are very useful to segment the LAN into different broadcast domains. This helps in reducing the broadcast domain by separating the logical segments of a LAN. VLANs can operate in different modes based on the incoming traffic.

VLAN on Ethernet port of AP is configured in the **Transparent** mode. When the VLAN status is disabled, then the bridge will forward the frames received on wireless interface as it is. If you enable the VLAN feature, then the frames will be tagged and these tagged frames will be forwarded via bridge called Transparent mode.

Once the VLAN tagged is enabled, all the VAP\SSID are configured with a valid VLAN ID (1 to 4094). All the BSS ports will act like an access port of a VLAN switch. Any untagged packet received from clients will be tagged by the BSS port and then forwarded to its destination port.

The VLAN has a 16-bits frame format as mentioned below:



- TPID - Tag Protocol Identifier
- CFI - Canonical Format Identifier
- Priority - 0 to 7 (value)
- VID - VLAN ID (1 to 4094)

When the VLAN is enabled, then a tag is added to the existing incoming packet. Based on the VLAN ID that is present the frames are forwarded to their respective destination port.

VLAN Features

- **VLAN Status:** This parameter is used to configure the VLAN status of the device.
- **Management VLAN ID:** This parameter is used to configure the Management VLAN ID. The management stations must tag the management frames they send to the device with the management VLAN ID.

Filtering

The Access Point's Packet Filtering features help control the amount of traffic exchanged between the wired and wireless networks. The Filtering feature supports the filtering for following protocol layers:

Ethernet Layer Filtering

Static MAC Filtering

The Static MAC Address filter optimizes the performance of a wireless (and wired) network. When this feature is properly configured, the AP can block traffic between wired devices and wireless devices based on MAC address.

For example, you can set up a Static MAC filter to prevent wireless clients from communicating with a specific server on the Ethernet network. You can also use this filter to block unnecessary multicast packets from being forwarded to the wireless network.

NOTE: *The Static MAC Filter is an advanced feature. You may find it easier to control wireless traffic via other filtering options, such as Ethernet Protocol Filtering.*

Each static MAC entry contains the following fields:

- Wired MAC Address
- Wired MAC Mask
- Wireless MAC Address
- Wireless MAC mask
- Comment
- Status

Each MAC Address or Mask is comprised of 12 hexadecimal digits (0-9, A-F) that correspond to a 48-bit identifier. (Each hexadecimal digit represents 4 bits (0 or 1)).

Taken together, a MAC Address/Mask pair specifies an address or a range of MAC addresses that the AP will look for when examining packets. The AP uses Boolean logic to perform an "AND" operation between the MAC Address and the

Mask at the bit level. However, for most users, you do not need to think in terms of bits. It should be sufficient to create a filter using only the hexadecimal digits 0 and F in the Mask (where 0 is any value and F is the value specified in the MAC address). A Mask of 00:00:00:00:00:00 corresponds to all MAC addresses, and a Mask of FF:FF:FF:FF:FF:FF applies only to the specified MAC Address.

For example, if the MAC Address is 00:20:A6:12:54:C3 and the Mask is FF:FF:FF:00:00:00, the AP will examine the source and destination addresses of each packet looking for any MAC address starting with 00:20:A6. If the Mask is FF:FF:FF:FF:FF:FF, the AP will only look for the specific MAC address (in this case, 00:20:A6:12:54:C3).

When creating a filter, you can configure the Wired parameters only, the Wireless parameters only, or both sets of parameters. Which parameters to configure depends upon the traffic that you want to block:

- To prevent all traffic from a specific wired MAC address from being forwarded to the wireless network, configure only the Wired MAC Address and Wired Mask (leave the Wireless MAC Address and Wireless Mask set to all zeros).
- To prevent all traffic from a specific wireless MAC address from being forwarded to the wired network, configure only the Wireless MAC address and Wireless Mask (leave the Wired MAC Address and Wired Mask set to all zeros).
- To block traffic between a specific wired MAC address and a specific wireless MAC address, configure all four parameters.
- To prevent all traffic from a specific wired Group MAC address from being forwarded to the wireless network, configure only the Wired MAC Address and Wired Mask (leave the Wireless MAC Address and Wireless Mask set to all zeros).
- To prevent all traffic from a specific wireless Group MAC address from being forwarded to the wired network, configure only the Wireless MAC address and Wireless Mask (leave the Wired MAC Address and Wired Mask set to all zeros).
- To block traffic between a specific wired Group MAC address and a specific wireless Group MAC address, configure all four parameters.
- To prevent the traffic between wired and wireless MAC and Group MAC address pair, configure any combination four.

A maximum of 200 entries can be created in the Static MAC filter table. To create an entry, click Add and enter the appropriate MAC addresses and Masks to setup a filter. The entry is enabled automatically when saved.

NOTE: You can specify the MAC addresses and their Masks and also add or delete the entries. Wired and Wireless MAC Address cannot have broadcast and multicast MAC address.

Ethernet Protocol Filtering

The Ethernet Protocol Filtering blocks or forwards packets based on the Ethernet protocols. The default table along with the list of Ethernet protocols is made available. You can add, modify or delete the entries that you have created, but the default values cannot be deleted. You have two options to set the filter status based on the protocol type:

- Passthru: This filter status will allow the packets to pass through.
- Block: This filter status will block the packets.

You can enter a maximum number of 64 entries for a table.

Intra BSS Filtering

The wireless clients that associate with a certain AP from the Basic Service Set (BSS) of a network infrastructure. By default, wireless subscribers in the same BSS can communicate with each other. However, some administrators may wish to block traffic between wireless subscribers that are associated with the same AP to prevent unauthorized communication and to conserve bandwidth. This feature enables you to prevent wireless subscribers within a BSS from exchanging traffic.

Although this feature is generally enabled in public access environments, Enterprise LAN administrators use it conserve wireless bandwidth by limiting communication between wireless clients. For example, this feature prevents peer-to-peer file sharing or gaming over the wireless network.

- If you select to block the traffic, then the wireless traffic between the clients associated with the same or different BSS (Basic Service Set) will not be able to communicate with each other.
- If you select to passthru, then the wireless traffic between the clients associated with the same or different BSS will be able to communicate with each other.

IP Layer

IP Protocol Filtering

This filtering type is also known as Advanced Filtering. The device is provided with some known protocol entries. Using this filter type you can block the specific IP Protocol traffic. You can enable or disable the entries as well the change the direction of the traffic.

TCP/UDP Layer

Port-based filtering enables you to control wireless user access to network services by selectively blocking TCP/UDP protocols through the AP. A user specifies a Protocol Name, Port Number, Port Type (TCP, UDP, or TCP/UDP), and filtering interfaces (only Wireless, only Ethernet or Both) in order to block access to services, such as Telnet and FTP, and traffic, such as NETBIOS and HTTP. You can enter up to maximum 64 entries for a table.

For example, an AP with the following configuration would discard frames received on its Ethernet interface with a UDP destination port number of 137, effectively blocking NETBIOS Name Service packets.

Protocol Name	Port Number	Port Type	Filter Interface	Entry Status (Enable/Disable)
NETBIOS Name Service	137	UDP	Ethernet	Enable

Filtering Features

- **Global Filter Flag:** This parameter is used to enable or disable the filtering tag. If you disable this filtering tag, then the no filtering feature will be applicable.
- **Intra BSS Filtering:** This parameter is used configure wireless to wireless communication.

Protocol Filter

- **Filtering Control:** This parameter is used to enable the interface either for Ethernet, Wireless or both.
- **Filtering Type:** This parameter is used to configure the filtering type. If the specific protocol is not available on the specified interface, then the filtering type would be performed on the packet that is being transmitted.
- **Protocol Name:** This parameter represents the Ethernet protocol filtering name.
- **Protocol Number:** This parameter represents the Ethernet protocol filtering number.
- **Filter Status:** This parameter is used for configuring the status of the Ethernet protocol filtering.

Static MAC Address Filter

- **Wired MAC Address:** This parameter represents the MAC address for the filter wired address.
- **Wired MAC Mask:** This parameter represents the MAC address for the filter wired Mask.
- **Wireless MAC Address:** This parameter represents the MAC address for the filter wireless address.
- **Wireless MAC Mask:** This parameter represents the MAC address for the filter wireless Mask.
- **Comment:** This parameter is used for entering the comment for the Static MAC filter table and this ia an optional parameter.

Advanced Filtering

- **Protocol Name:** This parameter is used to represent the protocol name that is to be filtered.
- **Direction:** This parameter represents the direction of the individual entry in the advanced filter table. The direction can be enabled either for Ethernet to Wireless, Wireless to Ethernet or both ways.

TCP/UDP Port Filter

- **Filter Control:** This parameter is used for configuring the status for the TCP/UDP port filter.
- **Protocol Name:** This parameter is used to configure the protocol name.
- **Port Number:** This parameter represents the TCP/UDP port filter number.
- **Port Type:** This parameter represents the port type for this TcpUdp Port filter table entry. The object can be either TCP or UDP or TCP/UDP.
- **Filter Interface:** This parameter is used to configure the interface. By default, the object is set to All Interfaces. The filter can be enabled either for Ethernet, Wireless or All Interface.

For more information on how to configure the above mentioned features, refer the following chapters:

- Using Web Interface: [Using Web Interface to Manage the Access Point](#)
- Using SNMP Interface: [Using SNMP Interface to Manage the Access Point](#)
- CLI Interface: [Using CLI to Manage the Access Point](#)

Managing the Device

Following features are available under Device Management:

System Information

This feature of the Access Point provides system specific information such as system name and contact information. It also provides the inventory management information such as Access Point's hardware, software, version and other information about the AP's installed components.

System Information Features

- **System Up-Time:** This is a read-only field that displays how long the Access Point has been running since its last reboot.
- **System Description:** This parameter provides the description of the system. This is a read-only field that reports the Access Point's name, serial number, current image software version, and current bootloader software version.
- **System Name:** This parameter provides the system name that is assigned. By default this displays the complete domain name.
- **Email:** The email address of the person responsible for the AP.
- **Phone Number:** The phone number of the person responsible for the AP.
- **Location:** The location where the AP is installed.
- **GPS Longitude:** The longitude at which the AP is installed. Enter the value in the format required by your network management system.
- **GPS Latitude:** The latitude at which the AP is installed. Enter the value in the format required by your network management system.
- **GPS Altitude:** The altitude at which the AP is installed. Enter the value in the format required by your network management system.
- **Country Code:** The country in which the AP will be used. Setting the country makes the AP automatically compliant with the rules of the regulatory domain in which it is used by configuring the allowed frequency bands, channels, Dynamic Frequency Selection Status, Transmit Power Control status, and power levels.

System Inventory Management Table Features

- **Serial Number:** This parameter identifies the system component serial number
- **Name:** This parameter identifies the system component name.
- **Component ID:** This parameter identifies the system component identification.
- **Variant:** This parameter identifies the system component variant number.
- **Release Version:** This parameter identifies the system component release version number.
- **Major Version:** This parameter identifies the system component major version number.
- **Minor Version:** This parameters identifies the system component minor version number.

Upgrading the Firmware

Using the File Management option you can manage your files through HTTP and TFTP.

The HTTP Interface (Web browser Interface) provides easy access to configuration settings and network statistics from any computer on the network. You can access the HTTP Interface over your LAN (switch, hub etc) over the Internet, or with a “cross-over” Ethernet cable connected directly to your computer.

Using the TFTP server you can transfer files across a network. You can upload files from the AP for backup or copying, you can download the files for configuration and AP image upgrades.

Introduction to File Management

Using the File Management category you can upgrade your device firmware:

- Downloading files (Config, image) to the AP using one of the two methods is called **Update Device**.
- Uploading files (Config, Event Log) from the AP is called **Retrieve From Device**.

TFTP File Transfer Guidelines

A TFTP server must be running and configured to point to the directory containing the file. If you do not have a TFTP server on your system, install the TFTP server from the installation CD.

HTTP File Transfer Guidelines

HTTP file transfer can be performed either with or without SSL enabled. HTTP file transfers with SSL require enabling Secure Management and Secure Management and Secure Socket Layer. HTTP transfers that use SSL may take additional time.

Image Error Checking during File Transfer

The Access Point performs checks to verify that an image downloaded through HTTP or TFTP is valid. The following checks are performed on the downloaded image:

- Zero image size
- Large image size
- AP image
- Digital signature verification

If any of the above checks fails on the download image, the Access Point deletes the download image and retains the old image. Otherwise, if all checks pass successfully, the AP detects the old image and retains the download image.

These checks are to ensure that the AP does not enter an invalid image state. The storage of the two images is only temporary to ensure the proper verification; the two images will not be stored in the AP permanently.

Update Device Using HTTP - Features

- **File Type:** This parameter represents the type of file being downloaded to the device.

- **File Name:** This parameter represents the filename to be downloaded.

Update Device Using TFTP - Features

- **Server IP Address:** This parameter represents the IP address for the TFTP server.
- **File Name:** This parameter represents the filename to upload or download to the TFTP server.
- **File Type:** This parameter represents the type of file being downloaded to the device.
- **Operation:** This parameter represents the type of operation that has to be completed. The options that are provided are: None, Update, and Update and Reboot.

Retrieve From Device Using HTTP - Features

- **File Type:** This parameter represents the type of file being uploaded to the device.

Retrieve From Device Using TFTP - Features

- **Server IP Address:** This parameter represents the IP address for the TFTP server.
- **File Name:** This parameter represents the filename to upload or download to the TFTP server.
- **File Type:** This parameter represents the type of file being uploaded to the device.

Password Management

The Management Services feature provides a consolidated page where you can configure all the required passwords for the Access Point.

Services Features

HTTP Password: This parameter is used to set the HTTP login password. This password should be in alphanumeric with minimum of 8 and maximum of 32 characters.

HTTP: This parameter represents the TCP/IP port by which the HTTP server will be accessible.

HTTPS: This parameter is used to enable or disable the HTTPS access to the device from any host.

Telnet/SSH Password: This parameter is used to set the Telnet/SSH login password. This password should be in alphanumeric with minimum of 8 and maximum of 32 characters.

Telnet: This parameter is used to enable or disable the Telnet access to the device from any host.

SSH: This parameter is used to enable or disable the SSH access to the device from any host.

SNMP: This parameter allows to enable or disable the SNMP access.

SNMP Password: This parameter represents the read-only community name used in the SNMP protocol. It is sent along with each SNMP Get-Request to allow or deny access to device. This password should be same as read password set at the NMS or mib browser). This password should be in alphanumeric with minimum of 8 and maximum of 32 characters.

Trap Host IP Address: This parameter represents the IP address of the management station that will receive SNMP traps from the device.

Management Access Control

The Management Access Control feature provides you an option of controlling the interface.

Management Access Control Feature Table Features:

- **Access Table Status:** This parameter is used to enable or disable the Access Control Table. By default it is disabled. Please check to enable and uncheck to disable. If this parameter is enabled the device can be managed only with configured IP Address list.
- **IP Address:** This parameter represents the IPv4 IP Address for which the traffic need to be passed.

For more information on how to configure the above mentioned features, refer the following chapters:

- Using Web Interface: [Using Web Interface to Manage the Access Point](#)
- Using SNMP Interface: [Using SNMP Interface to Manage the Access Point](#)
- CLI Interface: [Using CLI to Manage the Access Point](#)

Monitoring the Device

Following features are available under Device Monitor:

System Log

The Syslog messaging system enables the AP to transmit event messages to a central server for monitoring and troubleshooting. Syslog Events are logged according to the level of detail specified by the administrator. Logging only urgent system messages will create a far smaller, more easily read log than a log of every event the system encounters. If the SysLog server is configured, then System Log messages can be sent to other hosts.

System Log Features

- **Log Status:** This parameter is used to configure the status for the SysLog. Select enable to enable the Syslog status or disable to disable the syslog status.
- **Log Priority:** This parameter is used to configure the priority for the syslog. Select 1 for emergency, 2 for alert, 3 for critical, 4 for error, 5 for warning, 6 for notice, info for 7 and 8 for debug.

System Log Host Table Features

- **IP Address:** This parameter is used to represent the IP address of the Sys Log table.
- **Port:** This parameter is used to represents the host port for the Sys Log table.
- **Host Comment:** This parameter is used to configure the status of the Syslog host entry table.

Event Log

The Event Log keeps track of events that occur during the operation of the device. The Event Log displays messages that may not be captured by System Traps, such as the Transmit Power for the Frequency Channel selected.

Event Log Features

- **Log Priority:** This parameter is used to configure the priority for the event log table. The options are: Emergency, Alert, Critical, Error, Warning, Notice, Info, and Debug.

SNTP

SNTP allows a network entity to communicate with time servers in the network/internet to retrieve and synchronize time of day information. When this feature is enabled, the AP will attempt to retrieve the time of day information from the configured time servers (primary or secondary), and, if successful, will update the relevant time objects in the AP. Requests are sent every 10 seconds. If the AP fails to retrieve the information after three attempts, the AP will use the system uptime and update the relevant time objects. If this feature is disabled, the user cannot configure the date and time parameters.

SNTP Features

- **SNTP Status:** This parameter is used to enable or disable the SNTP functionality.
- **Primary Server Name Or IP Address:** This parameter is used for the primary SNTP server IP address name.
- **Secondary Server Name Or IPAddress:** This parameter is used for the secondary SNTP server IP address name.
- **Time Zone:** This parameter is used to specify the appropriate time zone.

Day Light Saving Time: This parameter is used to indicate the number of hours to adjust for Daylight Saving Time.

Interface Statistics

Statistics feature provides you the information about the various interfaces that are available for the Access Points. The sub-features that are available are described below:

Station Statistics

Station Statistics display information on wireless clients attached to the AP.

- **VAP Number:** The VAP number on which the client is connected with the AP.
- **MAC Address:** The MAC address of the wireless client for which the statistics are gathered.
- **Rx Data Frames:** The number of data frames that are received.
- **Tx Data Frames:** The number of data frames that are transmitted.
- **RSSI:** This represents the Received Signal Strength of the Station.
- **Tx Rate:** This parameter represents the transmission rate of the station.
- **State:** This parameter represents the present status of the station.

Wireless Statistics

Wireless Statistics display information on the wireless interface.

- **Description:** Information about the interface (e.g., the name of the manufacturer, the product name and the version of the hardware interface).
- **Type:** This displays the type of interface.
- **MTU:** Maximum Transfer Unit is the largest size of IP datagram which may be transferred using a specific data link connection. The size of MTU may vary greatly between different links.
- **Physical Address:** The wireless interface's address at the protocol layer immediately below the network layer in the protocol stack.
- **Operational Status:** The current state of the interface: Up (ready to pass packets), Down (not ready to pass packets, or Testing (testing and unable to pass packets).
- **Last Change:** The value of the sysUpTime object at the time the interface entered its current operational state.
- **In Octets:** The total number of octets received on the interface, including framing characters.
- **In Ucast Packets:** The number of subnetwork unicast packets delivered to a higher-layer protocol.
- **In Nucast Packets:** The number of non-unicast (i.e., subnetwork-broadcast or subnetwork-multicast) packets delivered to a higher-layer protocol.
- **In Errors:** The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
- **Out Octets (bytes):** The total number of octets transmitted out of the interface, including framing characters.
- **Out Ucast Packets:** The total number of packets that higher-level protocols requested to be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.
- **Out Discards:** The number of error-free outbound packets chosen to be discarded to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
- **Out Errors:** The number of outbound packets that could not be transmitted because of errors.

Ethernet Statistics

Ethernet Statistics display information on the Ethernet interface.

- **Description:** Information about the interface (e.g., the name of the manufacturer, the product name and the version of the hardware interface).

- **Type:** This displays the type of interface.
- **MTU:** Maximum Transfer Unit is the largest size of IP datagram which may be transferred using a specific data link connection. The size of MTU may vary greatly between different links.
- **Physical Address:** The wireless interface's address at the protocol layer immediately below the network layer in the protocol stack.
- **Operational Status:** The current state of the interface: Up (ready to pass packets), Down (not ready to pass packets), or Testing (testing and unable to pass packets).
- **Last Change:** The value of the sysUpTime object at the time the interface entered its current operational state.
- **In Octets:** The total number of octets received on the interface, including framing characters.
- **In Ucast Packets:** The number of subnetwork unicast packets delivered to a higher-layer protocol.
- **In Nucast Packets:** The number of non-unicast (i.e., subnetwork-broadcast or subnetwork-multicast) packets delivered to a higher-layer protocol.
- **In Errors:** The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
- **Out Octets (bytes):** The total number of octets transmitted out of the interface, including framing characters.
- **Out Ucast Packets:** The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.
- **Out Discards:** The number of error-free outbound packets chosen to be discarded to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.
- **Out Errors:** The number of outbound packets that could not be transmitted because of errors.

Bridge Statistics

The AP is a bridge between the wired and the wireless networking devices. Bridge Statistics display information that is available on the Bridge.

Bridge Statistics

- **Description:** Information about the interface (e.g., the name of the manufacturer, the product name and the version of the hardware interface).
- **Type:** This displays the type of interface.
- **Mtu:** Maximum Transfer Unit is the largest size of IP datagram which may be transferred using a specific data link connection. The size of MTU may vary greatly between different links.
- **Physical Address:** The wireless interface's address at the protocol layer immediately below the network layer in the protocol stack.
- **Operational Status:** The current state of the interface: Up (ready to pass packets), Down (not ready to pass packets), or Testing (testing and unable to pass packets).
- **Last Change:** The value of the sysUpTime object at the time the interface entered its current operational state.
- **In Octets:** The total number of octets received on the interface, including framing characters.
- **In Ucast Packets:** The number of subnetwork unicast packets delivered to a higher-layer protocol.
- **In Nucast Packets:** The number of non-unicast (i.e., subnetwork-broadcast or subnetwork-multicast) packets delivered to a higher-layer protocol.
- **In Errors:** The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
- **Out Octets (bytes):** The total number of octets transmitted out of the interface, including framing characters.
- **Out Ucast Packets:** The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.
- **Out Discards:** The number of error-free outbound packets chosen to be discarded to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.

- **Out Errors:** The number of outbound packets that could not be transmitted because of errors.

Network Layer

This page provides information of the IP ARP and for the received and transmitted messages.

RADIUS

Authentication Statistics

The feature description are:

- **Round Trip Time:** This parameter represents the round trip time for messages exchanged between radius client and authentication server since client startup.
- **Stats Requests:** This parameter represents the number of RADIUS Access Requests messages transmitted from the client to the server since client startup.
- **Retransmissions:** This parameter represents the number of RADIUS Access Requests messages transmitted from the client to the server since client startup.
- **Access Accepts:** This parameter indicates the number of RADIUS Access Accept messages received since system startup.
- **Access Rejects:** This parameter represents the number of RADIUS Access Rejects messages received since the system startup.
- **Access Challenges:** This parameter represents the number of RADIUS Access Challenges messages received since the system startup.
- **Stats Responses:** This parameter represents the total number of RADIUS Access messages received from the authentication server since system startup.
- **Malformed Responses:** This parameter represents the number of malformed RADIUS Access Response messages received since system startup.
- **Bad Authenticators:** This parameter represents the number of malformed RADIUS Access response messages containing invalid authenticators received since system startup.
- **Timeouts:** This parameter represents the total number of timeouts for RADIUS Access Request messages since system startup.
- **Unknown Types:** This parameter represents the number of messages with unknown Radius Message Code since system startup.
- **Packets Dropped:** This parameter represents the number of Radius message which do not contain any EAP payloads or EAP State machine do not have any valid EAP state data since system startup.

Accounting Statistics

The feature description are:

- **Round Trip Time:** This parameter represents the round trip time for messages exchanged between radius client and accounting server since client startup.
- **Stats Requests:** This parameter represents the number of RADIUS Access Requests messages transmitted from the client to the server since client startup.
- **Retransmissions:** This parameter represents the number of RADIUS Access Requests messages transmitted from the client to the server since client startup.
- **Stats Responses:** This parameter represents the total number of RADIUS Access messages received from the accounting server since system startup.
- **Malformed Responses:** This parameter represents the number of malformed RADIUS Access Response messages received since system startup.

- **Stats Timeouts:** This parameter represents the total number of timeouts for RADIUS Access Request messages since system startup.
- **Unknown Types:** This parameter represents the number of messages with unknown Radius Message Code since system startup.
- **Packets Dropped:** This parameter represents the number of Radius message which do not contain any EAP payloads or EAP State machine do not have any valid EAP state data since system startup.

For more information on how to configure the above mentioned features, refer to the following chapters:

- Using Web Interface: [Using Web Interface to Manage the Access Point](#)
- Using SNMP Interface: [Using SNMP Interface to Manage the Access Point](#)
- CLI Interface: [Using CLI to Manage the Access Point](#)

6

Using Web Interface to Manage the Access Point

This chapter contains information on configuring and managing settings for the various features that are available for the Access Point using the Web Interface. The Web Interface is categorized in three sections and each section provides you information on how to configure and manage your Access Points:

- [Web Interface Overview](#)
- [Error Message](#)
- [Configuring the Device](#)
- [Managing the Device](#)
- [Monitoring the Device](#)

To configure the AP using the Web interface, you must first log in to a web browser. See [Logging In](#) for instructions.

Web Interface Overview

There are four important buttons in the graphical interface of the software. They are described below.

- **Commit:** **Commit** button affects the changes in the configuraion of different parameters of the software.
- **Reboot:** **Reboot** button reboots the device after changing the configuration of parameters.
- **Home:** **Home** button takes you to the Home page of the software.
- **Help:** **Help** button shows you the context sensitive help for each and every new interface.




Figure 6-1 Commit (1), Reboot (2), Home (3) and Help (4) Buttons

Error Message

This error message, shown below, pops up when you try to configure a non-configurable parameter. This error message asks you to verify your data to configure that particular parameter or warns you to a correct pathway.



Figure 6-2 Error Message

Configuring the Device

Using the web interface, you can configure the following features that are available for device:

Wireless: Configure the Access point's wireless features, such as SSID, wireless properties and 11n properties. Configure the blacklisted channel table.

Ethernet: Configure the Ethernet's settings of the Access Point.

Security: Configure security features such as MAC Access Control, WPA, WPA2, WEP Encryption. Configure RADIUS features such as RADIUS Access Control, Authorization and Accounting.

QoS: Configure Wireless Multimedia Enhancement/Quality of Service parameters QoS policies.

IP Configuration: Configure the IP, DNS client, DHCP server, DHCP Relay Agent, DHCP Relay Servers, Link Integrity and SNTP settings.

VLAN: Configure VLAN for each interface.

Filtering: Configure Ethernet protocol filters, Static MAC address filters, advanced filters and Port filters.

1. Navigate in the left-hand side pane and click **Configuration**.




Figure 6-3 Configuration Main Page

2. Navigate and click the link that corresponds to the parameter you want to configure. For example, click Network to configure the Access Point's TCP/IP settings.

Each Configuration link is described in the remainder of this chapter.

Wireless

You can configure the following parameters within the **Wireless Configuration** page:

Interface 1

NOTE: By default both the Interfaces are active. If you want, you can change the default values for one Interface.

You can view and configure the following parameters for the Interface 1 and Interface 2:

VAP

1. Click **Configuration > Interface 1 > VAP**. The **Wireless Interface - 1 VAP** page will display as shown in the Figure




Figure 6-4 VAP Page

2. Click the radio button of the Index for which you want to make the changes, click **Edit**.
3. The **Wireless Interface - 1** page is displayed. Using this page you can modify the Wireless VAP parameters.



Figure 6-5 Wireless VAP Parameters - Edit

4. Configure the following parameters:
 - Select the **VAP Type**. By default, the VAP Type is AP.
NOTE: You can configure up to 4 VAP.
 - Enter the **SSID name** (wireless network name).
 - The **BSSID** field is read-only parameter and it displays the MAC address of the device.

- Enable the status of the **Close Systems** to broadcast the beacons.
- Enter the **Fragmentation Threshold**. The Fragmentation Threshold value range is between 256 to 2346. By default the Fragmentation Threshold is 2346, when the Fragmentation Threshold is disabled.

NOTE: If you configure the Fragmentation Threshold value between the said range, then only the fragmentation of the packets takes place.

- Enter the **Security Profile Name**.
- Enter **Radius Profile Name**.
- Enter the **VAP VLAN ID**.

NOTE: The valid range for VLAN ID is between 1 to 4094. If you select a value as -1, then this will disable the VLAN Tagging.

- Enter the **VAP VLAN Priority**. (You can enter the priority value between 0-7).
- Enter the **QoS Profile Name**. Ensure that you select the name that you used for creating the QoS Profile. See [QoS Profile](#).

NOTE: If the QoS Profile Name is defined as NONE, then the QoS feature will be disabled by default.

- Select the **Local MAC Authentication** status.

NOTE: If you have enabled this field, then do not enable the Radius MAC Authentication field.

- Select the **Radius MAC Authentication** status.
- Select the **Radius Accounting** status.
- Enable the **Entry Status** for the radio. If you disable the radio, then you cannot configure the Wireless VAP for the disabled radio.

5. Click **OK**.

NOTE: Follow the above mentioned steps to configure the VAP for the Interface 2.

Properties

Using this page, you can configure the properties of wireless interface.

1. Navigate to **Configuration > Wireless > Interface 1 > Properties**. The **Wireless Interface - 1 Properties** page will display.
2. Configure the following parameters:

Figure 6-6 Wireless Properties Page

- **Status:** Check the Status checkbox to enable the wireless interface properties.
- **Operational Mode:** Select the Operational Mode. This field indicates the operational mode of the unit.
- **Current Channel Bandwidth:** Select the channel bandwidth. By default it is set to 40 MHz.
- **Auto Channel selection:** Enable or disable the auto channel selection for wireless interface.
- **Current Operating Channel:** If you have enabled the auto channel selection option, then this field will select the channel automatically and also list out the other channels that are available.
- **Auto Rate Selection:** Enable or disable the auto rate selection. If you set it to enable, then it will automatically select the rate at which the wireless interface will transmit.
- **Transmitted Rate:** Use the drop-down menu to select a specific transmit rate for the AP. This field is valid only when **Auto Rate selection** is set to **Disable**. If you select the **Auto Rate Selection** as **Enable**, then the **Transmitted Rate** will always show **0**.
- **RTS Threshold:** Set RTS Threshold value to **2346 (the default setting)**. You set this value when RTS is disabled.
- **Beacon Interval:** By default the value is set to 100ms. You can modify this value.

NOTE: If you increase the beacon interval value, then this will reduce the number of beacons transmitted. Due to this the roaming and the associated clients may experience a delay in rate of beacons transmitted. Whereas if you decrease the beacon interval value, then this will increase the rate of beacons transmitted.

- **TPC:** By default, the unit lets you transmit at the maximum output power for the country or regulatory domain and frequency selected.
- **Cell Size:** Select the Cell Size.
- **DTIM:** Set the DTIM value.

NOTE: If you set the DTIM for longer intervals, then this allows mobile station to sleep for longer hours thus maximizing battery life. Whereas if shorter DTIM interval is set then frequent frame delivery takes place reducing the power save efficiency of battery.

- Click **OK**.

NOTE: Follow the above mentioned steps to configure the Properties for the Interface 2.

11n Properties

Using this page, you can configure 11n properties for wireless interface.

1. Navigate to **Configuration > Wireless > Interface 1 > 11n Properties**. This will display **11n Properties Table** page.

Figure 6-7 11n Properties Page

2. Configure the following parameters:

- **11n AMPDU Status:** Set this to Enable.
- **AMPDU Max Num Frames:** Enter a value. This field represents the AMPDU frames that are transmitted. It can be configured up to 64 frames.
- **AMPDU Max FrameSize:** Enter a value for the AMPDU frame size that can be transmitted. It is defined in bytes. It can be configured up to 65535.
- **11n AMSDU Status:** AMSDU (Aggregated MAC Service Data Unit) Enable this feature. When you enable this feature, the device does aggregation at link layer which will help to increase the throughput. The entire AMSDU frame is considered as one MPDU. It supports two values:
 - 4K or 4096
 - 8K or 8192

NOTE: Currently, our devices do not support AMSDU on the transmit side. The Access Point can receive only 4K length of AMSDU.

- **Frequency Extension:** Select the frequency extension for the wireless interface.
- **Guard Interval:** Set the Guard Interval. The supported values for this field are: 400nsec and 800nsec. By default the value set to 400nsec.
- **Tx Antennas and Rx Antennas:** Select the Tx Antennas and Rx Antennas' value.
- Click **OK**.

NOTE: Follow the above mentioned steps to configure the 11n Properties for the Interface 2.

Ethernet

Perform the following procedure to configure the Ethernet Port:

1. Navigate to **Configuration > Ethernet**.




Figure 6-8 Ethernet Page

- **MAC Address:** Defaults to the MAC ID of the device.
- **Speed:** You can set the speed either One Gigabit, 10 Mbps, 100Mbps or Auto.
- **Transmit Mode:** You can set the Transmit mode either to half Duplex, Full Duplex or Auto.

Security

Wireless Security

1. Navigate to **Configuration > Security > Wireless Security**.



Figure 6-9 Wireless Security Page

2. Click **Add** in the **Wireless Security CFG** table to create a new entry. The **Wireless Security Create Row** page displays.



Figure 6-10 Wireless Security Create Row Page

3. Enter the **Profile Name**.

- **Authentication Mode:** The WEP/PSK parameters are separately configurable for each authentication mode. To enable a security mode in the profile (Non Secure Station, WEP Station, 802.1x Station, WPA Station, WPA-PSK Station, 802.11i (WPA2) Station, 802.11i-PSK Station).

If the authentication mode selected in a profile is WEP, WPA-PSK, or 802.11i-PSK, then you must configure the WEP or Pre-Shared Keys.

NOTE: If an 802.1x client that has already been authenticated attempts to switch to WEP, or if a WEP client that has already been connected attempts to switch to 802.1x, the AP will not allow the client to switch immediately. If this happens, either reboot the AP or disable the client/roam to a new AP for five minutes, and then attempt to reconnect to the AP. If the client is still unable to connect after waiting five minutes, reboot the AP.

If you select WEP or TKIP, then the device will work on legacy rates not on 11n rates.

Configure one or more types of security modes that are allowed to access to the AP under the security profile. Select the option from the Entry status drop-down box.

- **Authentication Mode: None**, then the security will be disabled for that VAP.




Figure 6-11 Security - Authentication Mode - None

- **Authentication Mode: WEP**
 - **WEP Key:** Enter the Wep Key. The Key Length can be 64 or 128 Bits.
 - For 64-bit encryption, an encryption key is 10 hexadecimal characters (0-9 and A-F) or 5 ASCII characters see ASCII Character Chart).
 - For 128-bit encryption, an encryption key is 26 hexadecimal characters or 13 ASCII characters.
 - **Encryption Type:** Select the Encryption type as **WEP**.
 - Enter the **Status**.




Figure 6-12 Security - Authentication Mode - WEP

- **Authentication Mode: Psk**

- **Encryption Type:** WPA-TKIP, WPA2-AES, WPA-TKIP + WPA2-AES
- **PSK :** Enter the password. The limit for the passphrase is between 8 and 63 characters.
- **Rekeying Interval:** Enter the rekeying interval value. Re-key value is the interval at which AP will send Group keys for all associated clients. by default the Rekeying Interval value is set to 900.
- Enter **Status**.

NOTE: When you select the encryption type as WPA-TKIP+WPA2-EAS, then the AP is considered to be in Auto-Encryption mode, and the client will support both encryption type.

The screenshot shows the web interface configuration page. On the left is a navigation menu with categories: CONFIGURATION, MANAGEMENT, and MONITOR. Under CONFIGURATION, the 'Security' section is expanded to show 'Wireless Security', 'RADIUS', and 'MAC ACL'. The main content area is titled 'Wireless Security Create Row' and contains a form with the following fields:

Profile Name	Default
Authentication Mode	Psk
Encryption Type	WPA-TKIP
PSK	dgadadj (Values 8-64 chars)
Rekeying Interval	900 (Values 900-65535)
Entry Status	Enable

An 'Add' button is located at the bottom of the form.

Figure 6-13 Security - Authentication Mode - Psk

- **Authentication Mode: 802.1x**
 - **Encryption Type:** WEP, WPA-TKIP, WPA2-AES, WPA-TKIP + WPA2-AES
 - **Rekeying Interval:** Enter the rekeying interval value.
 - Enter **Status**.

NOTE: When you select the encryption type as WPA-TKIP+WPA2-EAS, then the AP is considered to be in Auto-Encryption mode, and the client will support both encryption type. This type of security is called Dynamic WEP.

The screenshot shows the web interface configuration page. On the left is a navigation menu with categories: CONFIGURATION, MANAGEMENT, and MONITOR. Under CONFIGURATION, the 'Security' section is expanded to show 'Wireless Security', 'RADIUS', and 'MAC ACL'. The main content area is titled 'Wireless Security Create Row' and contains a form with the following fields:

Profile Name	Default
Authentication Mode	Dot1x
Encryption Type	WPA-TKIP
Rekeying Interval	900 (Values 900-65535)
Entry Status	Enable

An 'Add' button is located at the bottom of the form.

Figure 6-14 Security - Authentication Mode - Dot1x

4. When finished configuring all parameters, click **Add**.
5. If you have selected a security profile of 802.1x, then you must configure a RADIUS 802.1x/EAP server. See. [RADIUS](#).

RADIUS

A RADIUS server profile consists of a Primary and a Secondary RADIUS server that get assigned to act either as MAC Authentication servers, 802.1x/EAP Authentication servers, or Accounting Servers in the VLAN configuration.

NOTE: You can configure only single RADIUS profile containing four server profiles viz. primary authentication server, secondary authentication server, accounting server and secondary accounting server. The profile name is common for all the four entries.

This page configures only the Primary RADIUS server associated with the profile.

1. Navigate to **Configuration > Security > RADIUS**.
2. Configure the following parameters for the RADIUS Server profile:

The screenshot shows the RADIUS configuration interface. On the left is a navigation tree with 'RADIUS' selected. The main area is titled 'RADIUS Server Profile' and contains two tables. The first table shows profile-level settings for 'Default Radius' with Max Re Transmissions: 3, Message Response Time: 3, and Re Authentication Period: 0. The second table lists four server entries: Primary Auth Server (1812), Secondary Auth Server (1812), Primary Acc Server (1813), and Secondary Acc Server (1813).

INDEX	Profile Name	Max Re Transmissions	Message Response Time	Re Authentication Period	Entry Status
1	Default Radius	3	3	0	Enable

INDEX	Server Type	IP Address	Server Port	Shared Secret	Entry Status
1	Primary Auth Server	169.254.128.133	1812	*****	Enable
2	Secondary Auth Server	169.254.128.134	1812	*****	Disable
3	Primary Acc Server	169.254.128.133	1813	*****	Disable
4	Secondary Acc Server	169.254.128.134	1813	*****	Disable

Figure 6-15

- **Profile Name:** Enter the profile name. This profile name is mapped to a VAP.
- **Max ReTransmissions:** Enter the Retransmission value.
- **Message Response Time:** Enter the Message Response time.
- **ReAuthentication Period:** Enter the ReAuthentication Period.
- **Entry Status:** Select the entry status for the profile.

Configure the following parameters for the radius servers:

- **Server Type:** This is read only parameter and it displays the server type.
- **IP Address:** Enter the server's IP address.
- **Server Port:** Enter the port number which the AP and the server will use to communicate. By default, RADIUS Authentication/Accounting servers communicate on ports 1812/1813.
- **Shared Secret:** Enter the password shared by the RADIUS server and the AP. The default password is "public."
- **Status:** Select Enable from the drop-down box to enable RADIUS server, if required.

3. Click **OK**.

MAC Access Control

MAC Access Control page allows you to build a list of authorized wireless stations that can register at the unit and access the network. MAC Authentication is supported on the wireless interface and only wireless MAC addresses should be entered in the list.

1. Click **Configuration > Security > MAC Access Control**.
2. Select the **Operation Type**.

NOTE: Based on the Operation type, you can allow/deny the association of the MAC ACL profile to an SSID.

3. Click **OK**.




Figure 6-16 MAC Access Control Page

4. To add entries, click **Add**, the **MAC ACL Add Row** page is displayed.




Figure 6-17 MAC ACL Add Row Page

5. Enter the **MAC Address**, **Comment** if you have any, and **Entry Status** of the MAC Address, then click **Add**. The maximum number of MAC addresses that can be added is 64.

QoS

Perform the following procedure to configure the Station and AP EDCA tables:

EDCA

1. Navigate to **Configuration > QoS > EDCA**.




Figure 6-18 QoS EDCA Tables

2. Click **Edit** and configure the following parameters in each table:

- **Access Category:** It is a read-only parameter and indicates the Access Category being defined:
 - Background
 - Best Effort
 - Video
 - Voice

Class of Service	Default EDCA Parameters for Station				Default EDCA Parameters for AP			
	CWMin	CWmax	AIFS	TXOP(unsigned integer)	CWMin	CWmax	AIFS	TXOP(unsigned integer)
Back Ground	15	1023	7	0	15	1023	7	0
Best Effort	15	1023	3	0	15	63	3	0
Video	7	15	2	3.008 ms	7	15	1	3.008 ms
Voice	3	7	2	1.504 ms	3	7	1	1.504 ms

Figure 6-19 Default EDCA Parameters for Station and AP

- **CWMin:** Minimum Contention Window.
 - Configurable range for Station is between 0 to 32767
 - Configurable range for AP is between 0 to 32767

- **CWMax:** Maximum Contention Window.
 - Configurable range for Station is between 0 to 32767
 - Configurable range for AP is between 0 to 32767
- **AIFSN:** Arbitration IFS number per access category.
 - Configurable range for Station is between 2 to 15
 - Configurable range for AP is between 1 to 15
- **Tx OP:** The Transmission Opportunity Limit (Tx OP) is an interval of the time during which particular QoS enhanced client has the right to initiate a frame exchange sequence onto the wireless medium. The Tx OP Limit defines the upper limit placed on the value of Tx OP a wireless entity can obtain for a particular access category.
 - Configurable range for Station is between 0 to 8160
 - Configurable range for AP is between 0 to 8160
- **ACM:** The Admission Control Mandatory (ACM) defines if an Access Point accepts or rejects a request traffic stream with certain QoS specifications, based on available channel capacity and link conditions. ACM can be configured for each Access Category. Possible values are Enable or Disable.

802.1D to IPDSCP Map Tbl

Use this page to configure QoS 802.1D to IPDSCP priority mapping (for layer 3 policies). Custom entries can be added to each table with different priority mapping:

1. Navigate to **Configuration > QoS > Dot1D to IPDSCP Map Tbl**
2. In the **Dot1D To IPDSCP Mapping Table** page, enter the IPDSCP Range (lower and Upper limit) for each 802.1D priority row. Specify the DSCP value range between 0-63.
3. Click **OK**.

TEST ONLY

COMMIT
REBOOT
HOME

CONFIGURATION

- Wireless
- Ethernet
- Security
- QoS
 - EDCA
 - 802.1D to IP DSCP MapTbl
 - 802.1D to 802.1p MapTbl
 - QoS Profile
 - QoS Policy
- IP Configuration
- VLAN
- Filtering

MANAGEMENT

MONITOR

802.1D to IP DSCP Mapping Table

Index	801.1D to IP DSCP Index	Lower Limit	Upper Limit
1	0	<input type="text" value="0"/>	<input type="text" value="7"/>
1	1	<input type="text" value="8"/>	<input type="text" value="15"/>
1	2	<input type="text" value="16"/>	<input type="text" value="23"/>
1	3	<input type="text" value="24"/>	<input type="text" value="31"/>
1	4	<input type="text" value="32"/>	<input type="text" value="39"/>
1	5	<input type="text" value="40"/>	<input type="text" value="47"/>
1	6	<input type="text" value="48"/>	<input type="text" value="55"/>
1	7	<input type="text" value="56"/>	<input type="text" value="63"/>

Figure 6-20 802.1D To IP DSCP Mapping Table Page

802.1D to 802.1p Map Tbl

Use this page to configure QoS 802.1D to 802.1p priority mapping (for layer 2 policies).

1. Navigate to **Configuration > QoS > Dot1D to Dot1p Map Tbl**
2. In the **Dot1D to Dot1p Mapping Table** page, enter the 802.1p Priority (from 0-7) for 802.1d Priorities 0-7.
3. Click **OK**.




Figure 6-21 802.1D to 802.1p Mapping Table Page

QoS Profile

Perform the following procedure to configure QoS Profile.




Figure 6-22 QoS Profile Page

1. Enter the **QoS Profile Name**.
2. Enter the **Policy Name** that you have defined in the QoS Policy Table.
3. Enter the **EDCA Profile Name** that you have defined in the EDCA Table.
4. Select the **QoS NO ACK Status** for the QoS Profile table.
5. Click **Ok**.

QoS Policy

Perform the following procedure to enable QoS and QoS Policies:

Index	Policy Name	Policy Type	Priority Mapping	Marking Status	Entry Status
1	Default	Inbound Layer2	1	Enable	Disable
2	Default	Inbound Layer3	1	Enable	Disable
3	Default	Outbound Layer2	1	Enable	Disable
4	Default	Outbound Layer3	1	Enable	Disable

Figure 6-23 QoS Policy page

1. Navigate to **Configuration > QoS > Policy**
2. Enter the **Policy Name**. By default, the policy name is provided.
3. By default the **Policy Type** is displayed. Following Policy Types are available:
 - Inbound Layer 2: inbound traffic direction, Layer 2 traffic type
 - Outbound Layer 2: Outbound traffic direction, Layer 2 traffic type
 - Inbound Layer 3: Inbound traffic direction, Layer 3 traffic type
 - Outbound Layer 3: Outbound traffic direction, Layer 3 traffic type
4. Enter the **Priority Mapping**. For layer 2 policies, an index from the **DOT1D to DOT1P** mapping table should be specified. For layer 3 policies, an index from the **DOT1D to IP DSCP** mapping table should be specified.
5. Select the **QoS Marking Status**.
6. Select the **Entry Status** for QoS table. This represents the entry status for the corresponding row in the table.

NOTE: If you want to customize a particular Policy Type, then the Entry Status for that Policy Type should be Enabled.

7. Click **OK**.

IP Configuration

The Network IP Config is used to configure the internet (TCP/IP) settings for the Access Point.

These settings can be either entered manually static IP address, subnet mask, and gateway IP address or obtained automatically (dynamic).

Network IP Config

You can configure and view the following parameters within the **Network IP Config** page:

NOTE: You must reboot AP in order for any changes to the IP parameters to take effect.

1. Navigate to **Configuration > Network > Network IP Config**. The **Network IP Configuration** page displays. Configure the following parameters:




Figure 6-24 Network IP Config

- **Address Type:** Select the Address Type Static or Dynamic from the drop-down list.
 - If you select the Address Type as Static, then you need to configure the following parameters and click OK:
 - IP Address
 - Subnet Mask
 - Gateway IP Address
 - If you select the Address Type as Dynamic, then the following parameters will remain as read only:
 - IP Address
 - Subnet Mask
 - Gateway IP Address

VLAN

VLANs segment network traffic into workgroups, which enable you to limit broadcast and multicast traffic. Workgroups enable clients from different VLANs to access different resources using the same network infrastructure. Clients using the same physical network are limited to those resources available to their workgroup.

The AP can segment users into a maximum of 4 different workgroups per radio. Therefore total of 8 different workgroups/VLANs for dual radio.




Figure 6-25 VLAN Page

Management access to the AP can easily be secured by making management stations and hosts and the AP itself members of a common VLAN. Simply configure a non-zero management VLAN ID and enable VLAN to restrict management of the AP to members of the same VLAN.

CAUTION: If a non-zero management VLAN ID is configured then management access to the AP is restricted to wired or wireless hosts that are members of the same VLAN. Ensure your management platform or host is a member of the same VLAN before attempting to manage the AP.

NOTE: When VLAN is enabled ensure that all devices in the network share the same VLAN ID as this will ensure that the all the Access Points are managed easily.

NOTE: In the case of Radius server authentication or EAP authentication, if the radius server is present on any VLAN, then the Radius server should be the member of management VLAN ID of an AP.

1. Navigate to **Configuration > VLAN**.
2. Place a check mark in the **Status** box. This will enable the VLAN feature for the device.

NOTE: To Disable the VLAN, uncheck the Status checkbox and click COMMIT button to update the changes.

3. Set the **VLAN Management Identifier** to a value of between 1 and 4094. (A Value of -1 disables the VLAN Tagging).
4. Click **OK**.
5. Click **COMMIT**.

CAUTION: You need to click **Commit** button to update/reflect the changes. If you do not click Commit, then the device will not be able tag the incoming wireless packets.

Filtering

The Access Point's Packet Filtering features help control the amount of traffic exchanged between the wired and wireless networks. If the global flag for Filtering is not enabled on the device, then none of the filtering configuration can be applied.

There are four sub-headings under the Filtering heading:

- [Intra BSS Filtering](#)
- [Protocol Filtering](#)
- [Static MAC Address Filtering](#)
- [Advanced Filtering](#)
- [TCP/UDP Port Filtering](#)

Intra BSS Filtering

Using the Filtering parameters available in the Filtering page, you can configure the Intra BSS Filtering Status:

1. Navigate to **Configuration > Filtering**.




Figure 6-26 Intra BSS Filtering Page

2. Select the status of the **Global Filter Flag** from the drop-down box. You need to Enable the Status for Filtering.

WARNING: If you Disable the Status for Filtering, then the configuration for Filtering parameter will not be applicable.

3. Select the **Intra BSS Filtering**. The Intra BSS Filtering parameter controls the wireless to wireless communication.
 - If set to **Enable**, then there will be no wireless to wireless communication.
 - If set to **Disable**, then wireless to wireless communication is possible.
4. Click **OK**.

Protocol Filtering

Follow these steps to configure the Protocol Filtering.

1. Navigate to **Configuration > Filtering > Protocol Filter**.
2. In the **Protocol Filter** page, configure the following fields:
 - **Filtering Control**: Select the interface or interfaces that will implement the filter from the **Filtering Control** drop-down list:
 - **Ethernet**: Packets are examined at the Ethernet interface.
 - **Wireless**: Packets are examined at the Wireless interface.
 - **All interfaces**: Packets are examined at both interfaces.
 - **Disabled**: The filter is not used.
 - **Filtering Type**: By default the Filtering type is set to Passthru. If you want to, then select the Filtering Type as Block.
 - In the Filtering Table, if the Entry Status of a particular entry is **Enable**, and the device will verify the Filter Status of the particular entry and then perform the filtering process.
 - If the Filter Status is Enable, then the packets will be allowed to pass through.
 - If the Filter Status is Block, then the packets will be blocked.
 - In the Filtering table, if the Entry Status of a particular entry is Disable or non-existing, then it will depend on the Filtering Type that is selected.

COMMIT **REBOOT** **HOME**

CONFIGURATION

- [-] Wireless
- [-] Ethernet
- [-] Security
- [-] QoS
- [-] IP Configuration
- [-] VLAN
- [-] Filtering
 - [-] Protocol Filter
 - [-] Static MAC Address Filter
 - [-] Advanced Filtering
 - [-] TCP/UDP Port Filter

MANAGEMENT

MONITOR

Protocol Filter

Filtering Control: All Interfaces

Filtering Type: Passthru

OK

INDEX	Protocol Name	Protocol Number	Filter Status	Entry Status
1	Apollo Domain	80:19	Block	Disable
2	Apple Talk 1 an	80:9b	Block	Disable
3	Apple Talk ARP	80:f3	Passthru	Disable
4	Banyan VINES	0b:ad	Block	Disable
5	Banyan VINES	0b:af	Block	Disable
6	Decnet Phase IV	80:03	Block	Disable
7	DEC Diagnostic	80:05	Block	Disable
8	DEC LAT	80:04	Block	Disable
9	DEC MOP Dump	80:01	Block	Disable
10	DEC MOP Rem	80:02	Block	Disable
11	DEC NetBIOS	80:40	Passthru	Disable
12	HP Probe Contr	80:05	Block	Disable
13	IBM SNA Servic	80:d5	Block	Disable
14	IP-ARP	08:06	Block	Disable
15	Novell(ECONFI	81:37	Block	Disable
16	RARP Reverse A	80:35	Block	Disable
17	SNMP Over Eth	81:4c	Passthru	Disable
18	Xyplex	08:88	Block	Disable
19	EAPOL ether ty	88:8e	Block	Disable

OK **Add**

Figure 6-27 Protocol Filter Page

3. Configure the Protocol Filter table. This table is pre-populated with existing Protocol Filters, however, you may enter additional filters by specifying the appropriate parameters.

- To add an entry, click Add, and then specify the following:
 - **Protocol Name:** Enter the protocol name.
 - **Protocol Number:** Enter the protocol number.
 - **Filter Status:** Select the filter status, select either Block or Passthru from drop-down box.

NOTE: An entry's status must be block in order for the protocol to be subject to the filter.

- **Table Status:** Select the Table Status

4. Click **Add**.




Figure 6-28 Protocol Filter - Add Entries

Static MAC Address Filtering

1. Navigate to **Configuration > Filtering > Static MAC Address Filter**.




Figure 6-29 Static MAC Address Filter Page

2. To add an entry, click **Add**. Enter the information as mentioned below as examples.




Figure 6-30 Static MAC Address Filter - Add Entries

Static MAC Filter Examples

Consider a network that contains a wired interface and three wireless clients. The MAC address for each unit is as follows:

- Wired Interface: 00:40:F4:1C:DB:6A

- Wireless Client 1: 00:02:2D:51:94:E4
- Wireless Client 2: 00:02:2D:51:32:12
- Wireless Client 3: 00:20:A6:12:4E:38

Prevent Two Specific Devices from Communicating

Configure the following settings to prevent the Wired Interface and Wireless Client 1 from communicating:

- Wired MAC Address: 00:40:F4:1C:DB:6A
- Wired Mask: FF:FF:FF:FF:FF:FF
- Wireless MAC Address: 00:02:2D:51:94:E4
- Wireless Mask: FF:FF:FF:FF:FF:FF

Result: Traffic between the Wired Interface and Wireless Client 1 is blocked. Wireless Clients 2 and 3 can still communicate with the Wired Interface.

Prevent Multiple Wireless Devices from Communicating with a Single Wired Device

Configure the following settings to prevent Wireless Clients 1 and 2 from communicating with the Wired Interface:

- Wired MAC Address: 00:40:F4:1C:DB:6A
- Wired Mask: FF:FF:FF:FF:FF:FF
- Wireless MAC Address: 00:02:2D:51:94:E4
- Wireless Mask: FF:FF:FF:00:00:00

Result: When a bitwise “AND” is performed on the Wireless MAC Address and Wireless Mask, the result corresponds to any MAC address beginning with the 00:20:2D prefix. Since Wireless Client 1 and Wireless Client 2 share the same prefix (00:02:2D), traffic between the Wired Interface and Wireless Clients 1 and 2 is blocked. Wireless Client 3 can still communicate with the Wired Interface since it has a different prefix (00:20:A6).

Prevent All Wireless Devices from Communicating with a Single Wired Device

Configure the following settings to prevent all three Wireless Clients from communicating with Wired Interface 1:

- Wired MAC Address: 00:40:F4:1C:DB:6A
- Wired Mask: FF:FF:FF:FF:FF:FF
- Wireless MAC Address: 00:00:00:00:00:00
- Wireless Mask: 00:00:00:00:00:00

Result: The Access Point blocks all traffic between Wired Interface 1 and all wireless clients.

Prevent a Wireless Device from Communicating with the Wired Network

Configure the following settings to prevent Wireless Client 3 from communicating with any device on the Ethernet:

- Wired MAC Address: 00:00:00:00:00:00
- Wired Mask: 00:00:00:00:00:00
- Wireless MAC Address: 00:20:A6:12:4E:38
- Wireless Mask: FF:FF:FF:FF:FF:FF

Result: The Access Point blocks all traffic between Wireless Client 3 and the Ethernet network.

3. Select the Status of Static MAC Address Filter row.

Advanced Filtering

1. Navigate to **Configuration > Filtering > Advanced Filtering**.
2. The following protocols are listed in the Advanced Filtering table:
 - Deny IPX RIP

- Deny IPX SAP
- Deny IPX LSP
- Deny IP Broadcasts
- Deny IP Multicasts




Figure 6-31 Advanced Filtering Page

NOTE: The AP can filter these protocols in the wireless-to-Ethernet direction, the Ethernet-to-wireless direction, or in both directions.

3. Click **Edit** and use:
 - **Status** field to Enable or Disable the filter status
 - **Direction** field to set the direction




Figure 6-32 Advanced Filter Table - Edit Entries

TCP/UDP Port Filtering

1. Navigate to **Configuration > Filtering > TCPUDP Filtering**.
2. In the **TCPUDP Port Filter** page, select the **Filter Control** as Enable in the **TCP/UDP Filter** page.




Figure 6-33 TCP/UDP Filter Page

3. Click **Add** under the TCP/UDP Filter table.
4. In the **TCP/UDP Port Filter Add Row** page, enter the Protocol Name to filter.
5. Set the destination **Port Number** (a value between 0 and 65535) to filter. See the IANA web site at <http://www.iana.org/assignments/port-numbers> for a list of assigned port numbers and their descriptions.
6. Set the **Port Type** for the protocol: **TCP, UDP, or both (TCP/UDP)**.
7. Set the **Interface** to filter:
 - Only Ethernet
 - Only Wireless
 - Both
8. Set the **Table Status**:
 - Enable
 - Disable

9. Click **Add**.

The screenshot shows the 'TCP/UDP Port Filter Add Row' form. On the left, the 'CONFIGURATION' menu is expanded to 'Filtering' > 'TCP/UDP Port Filter'. The main form contains the following fields:

Protocol Name	NET BIOS Name Services
Port Number	141
Port Type	Both
Filter Interface	Only Wireless
Table Status	Enable

An 'Add' button is located at the bottom of the form.

Figure 6-34 TCP/UDP Port Filter Table - Add Entries

Managing the Device

Using the web interface you can manage the following features of the device:

System: Configure specific system information parameters, such as system name and contact details etc.

Upgrading the Firmware: Using the File Management option you can manage your files through HTTP and TFTP.

Password Management: Configure a system specific access password for the different interface through which you manage your device.

Management Access Control: Using this option you can enable or disable various interfaces.

The screenshot shows the 'Device Management' page. The left sidebar has 'MANAGEMENT' expanded to 'System'. The main content area is titled 'Device Management' and contains the following sections:

- System:** Configure system specific information such as Country Code(only for world mode devices), System Name, and Contact Information.
- Inventory Management:** Use the Inventory Management to identify various components of your device.
- File Management (HTTP / TFTP):** Use this section to update the device to the latest Firmware, apply a configuration, retrieve configuration, or eventlogs using HTTP / TFTP.
- Management Services:** Use the Management Services to configure passwords, enable/disable Management Interfaces, Trap Host IP Address and Reset to Factory Defaults.
- Management Access Control:** Use this option to allow Management Access to this system only for configured list of IP Addresses.

Figure 6-35 Device Management Page

System

System Information

You can configure and view the following parameters within the **System Information** page:

- The following parameters are read-only and are displayed:
 - System Up-Time
 - System description
 - System Name
- Email: Enter the email address of the person responsible for the AP.
- Phone Number: Enter the contact number of the person responsible for the AP.
- Location: Enter the location of the AP.
- GPS Longitude: Enter the value in the format required by your network management system.
- GPS Latitude: Enter the value in the format required by your network management system.
- GPS Altitude: Enter the value in the format required by your network management system.
- Country Code: The country in which the AP will be used.

NOTE: You must reboot the AP in order for country selection to take effect.

NOTE: Country selection is available only on APs with model numbers ending in **-WD**. If country selection is available, however, it must be set before any interface parameters can be configured.

CAUTION: Romania is not supported in the 20 and 40 MHz band whereas UK is not supported in 40 MHz band. The table below specifies the details:

Country	allow 11g	allow11a turbo	allow11gturbo	allow11ng20	allow11ng40	allow11na20	allowna40
Romania	Yes	No	Yes	Yes	Yes	No	No
UK	Yes	No	Yes	Yes	Yes	Yes	No

Click **OK**.





Figure 6-36 System Information Page

System Inventory Management Component

This page provides information about the device hardware, firmware, and software version information. For more information, See [Using CLI to Manage the Access Point](#).

INDEX	Number	Name	Comp ID	Variant ID	Release Version	Major Version	Minor Version
1	BUILD-360	Wireless Card 1 - NIC (0x60)	2300	1	7	0	0
2	AP-B00	AP Software Image	2100	1	1	0	0
3	01	Hardware Inventory	2000	1	1	0	0
4	-NA-	BSP-Bootloader	2102	1	0	0	0
5	-NA-	Enterprise MIB	2200	1	1	0	0
6	-NA-	Config File	2201	1	0	0	0
7	-NA-	License File	0	0	0	0	0

Figure 6-37 System Inventory Management Page

Upgrading the Firmware

Update Device Using HTTP

Use the **HTTP Download** page to download config, image files to the device. In the HTTP Download page, perform the following procedure to download the specific file:

Figure 6-38 Update Device using the HTTP Download Page

1. Select the **File Type** that needs to be updated from the drop-down box. Choices include:
 - Image for the AP Image (executable program).
 - Config for configuration, such as System Name, Contact Name and so on.
2. Use the **Browse** button or manually type in the name of the file to be downloaded (including the file extension in the **File Name** field. If typing the file name, you must include the full path and the file extension in the file name text box.
3. To initiate the HTTP Update operation, click **Update** button.

NOTE: An HTTP file transfer using SSL may take extra time.

- If the operation is completed successfully the device would provide the information about the successful update.

New config file updated in the device

Back

Figure 6-39 Update Device Using HTTP- Success Message

- If the operation is not completed successfully the following screen appears, and the reason for the failure is displayed.

New config file provided is not valid

Back

Figure 6-40 Update Device Using HTTP- Failure Message

Update Device Using TFTP

Use the TFTP Download page to download config, image file to the device. A TFTP server must be running and configured to point to the directory containing the file.

If you do not have a TFTP server installed on your system, install the TFTP server from the installation CD. You can either install the TFTP server from the CD Wizard or run OEM-TFTP-Server.exe found in the CD's Xtras/SolarWinds sub-directory.

Using the **TFTP Download** page to enter the following information as described below:

TFTP Update

Note: When Operation is changed to "Update and Reboot", once Update is complete the system will reboot without any further notification.

Note: Please don't Navigate away from this page when the update in progress.

Server IP Address	<input type="text" value="172.18.18.175"/>
File Name	<input type="text" value="image.bin"/>
File Type	<input type="text" value="Image"/>
Operation	<input type="text" value="None"/>

Update

Figure 6-41 Update Device Using TFTP Server

- **Server IP Address:** Enter the TFTP server IP Address.
 - Double-click the TFTP server icon on your desktop and locate the IP address assigned to the TFTP server.

NOTE: This is the IP address that will be used to point the Access Point to the AP Image file.
- **File Name:** Enter the name of the file to be downloaded (including the file extension).
 - Copy the file to the TFTP server's root folder.
- **File Type:** Select the proper file type. Choices include:
 - Config: Configuration information, such as System name, contact name, and so on.
 - Image: AP image (executable program)
- **Operation:** Select either **Download** or **Download & Reboot**. You should reboot the AP after downloading files.

NOTE: If you select None as Operation, then no operation will be performed.

Click **OK** to initiate the process.

- If the operation is completed successfully the device would provide the information about the successful update.



Figure 6-42 Update Device Using TFTP- Success Message

- If the operation is not completed successfully the following screen appears, and the reason for the failure is displayed.



Figure 6-43 Update Device Using TFTP- Failure Message

Retrieve From Device Using HTTP

Use the **HTTP** Upload page to retrieve config files from device.

1. Select the type of file (config, event log) from the File Type drop-down box.
2. Click **Retrieve** button to initiate the process.




Figure 6-44 Retrieve File using HTTP

3. The **Download** page is displayed. Click **Download** to download the file.




Figure 6-45 Download Page

4. **File Download** window pops up. Click **Save** button to save the file.




Figure 6-46 File Download Page

5. Select an appropriate filename and location and click Save.

Retrieve From Device Using TFTP

Use the **TFTP Upload** to upload files from the AP to the TFTP server. The TFTP server must be running and configured to point to the directory to which you want to copy the uploaded file. We suggest you assign the file a meaningful name.

If you don't have a TFTP server installed on your system, install the TFTP server from the installation CD. You can either install the TFTP server from the CD Wizard or run OEM-TFTP-Server.exe found in the CD's Xtras/SolarWinds sub-directory.

In the TFTP Upload page enter the following TFTP information as described below:

TFTP Retrieve

Note: If the device is in default configuration there will be no config file present, the request for uploading will not take effect. Similarly if there is no eventlog created on the device, the request for uploading eventlog will not take effect.

Server IP Address	<input type="text" value="172.18.18.175"/>
File Name	<input type="text" value="flashcfg.cfg"/>
File Type	<input type="button" value="Config"/>

Figure 6-47 Retrieve From Device Using TFTP

- **Server IP Address:** Enter the TFTP server IP Address.
 - Double-click the TFTP server icon on your desktop and locate the IP address assigned to the TFTP server.
- **File Name:** Enter the name of the file to be uploaded.
- **File Type:** Select the type of the file to be uploaded: Config file or Event Log.

Click **Retrieve** to initiate the procedure.

Password Management

Use the **Services** link to configure passwords and other service parameters. You can configure the following parameters and click REBOOT to update the changes:

- **HTTP/HTTPS:** The password for the Web browser HTTP interface. Enter a password in the Password field and enter the Port number. The default password is **“public”**.
- **Telnet/SSH:** The password for the CLI interface (via serial or Telnet). Enter a password between 6 and 32 characters in the Password field. The default password is **“public”**.
- **SNMP:** The password for Read/Write access to the AP using SNMP interface. Enter a password between 6 and 32 characters in the Password field. The default password is **“public”**.

NOTE: This password “public” is SNMP Read/Write Community string and is also applicable to SNMP Read Community.

- **Trap Host IP Address:** Enter the IP Address for which the traps needs to be delivered. By default, an IP Address will be available, that you can change.

NOTE: For security purposes Proxim recommends changing ALL PASSWORDS from the default “public” immediately, to restrict access to your network devices to authorized personnel.

- **Reset To Factory:** Click on the Reset To Factory button to reset the unit to the factory settings.

CAUTION: Resetting the AP to its factory default configuration will permanently overwrite all changes that have made to the unit. The AP will reboot automatically after this selection has been issued.




Figure 6-48 Management Services Page

Management Access Control

The Management Access Control provides option to control the interfaces as well as users who can access the device. The users are controlled using the IP address, i.e., the traffic is allowed to the device from the IP addresses configured in the access table.

If the Management Access Control is unchecked, the access control is not applied. You need to reboot the unit to update the changes that you have made.

Navigate **Management > Access Control**. This displays the Access Control Table page.




Figure 6-49 Management Access Control Page

1. Place a check mark in the **Management Access Control** check-box. This will enable the Management Access Control.

NOTE: You can disable this feature by unchecking the Management Access Control.

2. Click **Add**. This will display **Management Access Table Add Row** page.
3. Enter the **IP Address** of the device.
4. Select the **Entry Status**.
5. Click **Add**.



Figure 6-50 Management Access Control - Add Row Page

Monitoring the Device

Using the web interface you can monitor the following features:

System Log: The Syslog messaging system enables the AP to transmit event messages to a central server for monitoring and troubleshooting.

Event Log: The event log messaging system enables the AP to transmit messages for event tracing and logging.

SNTP: SNTP allows a network entity to communicate with time servers in the network/internet to retrieve and synchronize time of day information.

Interface Statistics: Using the Statistics page you can view information about the Ethernet and Wireless interface.

Bridge: Using this page, you can view bridge statistics information, such as packets sent, received etc and also about all the available nodes that are available in the network.

Network Layer: This page provides information about the ARP and all the statistical information that are transmitted and received.

RADIUS: This page provides information about the Radius client authentication and various retransmission and malfunctions for the radius clients.

Navigate to **Monitor** link located on the left-hand side pane. The **Device Monitor** page will be displayed.




Figure 6-51 Monitor Page

System Log

You can configure the following System Log settings from the web interface:

- **Log Status:** Enable the Status from the drop-down box, this will enable the system logging.
- **Log Priority:** The AP will send event messages to the System Log server that correspond to the selected priority.




Figure 6-52 System Log Page

Click **Show System Log** button to display the System Log for a selected log priority.

NOTE: Click **Clear System Log** if you want to clear the log.




Figure 6-53 System Log Information

System Log Host

Using the **System Log Host Table** you can configure Syslog event Notifications. Configure the following information:

1. Navigate to **Monitor > System Log > System Log Host**. This displays the **System Log Host Table** page.
2. Click **Add** button.



Figure 6-54 System Log Host Table Page

- **IP Address:** Enter the IP Address for the management host.
- **Host Port:** This field is for host port number and it displays the port number (514) assigned for system logging.
- **Comment:** Enter an optional comment such as the host name.

- **Entry Status:** Select **Create and Go** to enable the system log table. You can also disable entries by changing this field's value.

Click **Add**. This will add the table to the System Log Host Table page.

NOTE: Click **COMMIT** button after deleting the table entries, before you add any new entries.

IP Address	168.254.124.132
Host Port	141
Comment	system log

Add

Figure 6-55 System Log Host Table Add Row Page

Event Log

1. Navigate to **Monitor > Event Log**. The **Event Log** page is displayed.

Log Priority: Critical

Clear Event Log Show Event Log OK

Figure 6-56 Event Log Page

2. Select the **Log Priority** from the drop-down box and click on **Show Event Log** button.

NOTE: Select **Clear Event Log**, if you want to clear the event log table.




Figure 6-57 Event Log Details

SNTP

You can configure and view the following parameters within the SNTP page:

- **Enable SNTP Status:** Check the Enable SNTP status check-box. The selected status will determine which of the parameters on the SNTP page are configurable.
- **Primary Server IP Address/Domain Name:** If SNTP is enabled, enter the host name or IP address of the primary SNTP server.
- **Secondary Server IP Address/Domain Name:** If SNTP is enabled, enter the host name or IP address of the secondary SNTP server.
- **Time Zone:** Select the appropriate time zone from the drop-down box.
- **Day Light Saving Time:** When SNTP is disabled, the following time-relevant objects are manually configurable. When SNTP is enables, these objects are grayed out.

Click **Ok**.

Figure 6-58 SNTP Configuration

Interface Statistics

Using this page you can view information on wireless clients attached to the AP.

Ethernet

1. Navigate to **Monitor > Interface Statistics > Ethernet**. This displays the **Ethernet Statistics** page.
2. The following statistics are displayed for the wireless interface only. For more information refer [Ethernet Statistics](#)

Description	eth0
Type	ethernetcsmacd
MTU	1500
Physical Address	00:20:a6:0b:a7:65
Operational Status	UP
In Octets	1492117
In Ucast Packets	9669
In NUcast Packets	0
In Errors	0
Out Octets	4538297
Out Ucast Packets	10784
Out Discards	0
Out Errors	0

Figure 6-59 Ethernet Statistics Page

Wireless

Station Statistics

This page displays information on wireless clients attached to the AP. If the clients are connected to the device, then the statistics will be shown on the screen. Click on the **Refresh** button to view the latest statistics. If any new clients associate to the AP, then you can see the statistics of the new clients after you click the refresh button.

1. Navigate to **Monitor > Interface Statistics > Wireless > Station Statistics**. This displays the **Station Statistics** page.




Figure 6-60 Station Statistics Page

2. The following statistics are displayed for the Station. For more information refer [Station Statistics](#)




Figure 6-61 Station Statistics Page

Interface Statistics

1. Navigate to **Interface Statistics > Wireless > Interface 1**.
2. Click the radio button against the index number that you want to view. Click **Show** button.



Figure 6-62 Wireless Interface Page

3. The following statistics are displayed for the wireless interface 1 or 2. For more information on features, refer [Wireless Statistics](#)

NOTE: Navigate to **Monitor > Interface Statistics > Wireless > Interface 1** page to view the details.




Figure 6-63 Wireless Statistics

Bridge

Bridge Statistics

1. Navigate to **Monitor > Bridge > Bridge Statistics**. This displays the **Bridge Statistics** page.
2. The following statistics are displayed for the wireless interface only. For more information, refer [Bridge Statistics](#)

Bridge Statistics	
Description	br0
Type	ethernetcsmacd
MTU	1500
Physical Address	00:20:a6:00:a7:62
Operational Status	UP
In Octets	123233
In Ucast Packets	528
In NUCast Packets	545
In Errors	0
Out Octets	369829
Out Ucast Packets	661
Out Discards	0
Out Errors	0

Figure 6-64 Bridge Statistics

Learn Table

This page displays information relating to network bridging. It reports the MAC address for each node that the device has learned is on the network and the interface on which the node was detected. There can be up to 10,000 entries in the Learn Table.

port no	mac addr	is local?	ageing timer
1	00:01:6c:92:0a:dc	no	7.87
1	00:03:47:eb:dc:77	no	15.81
1	00:03:47:eb:de:d9	no	3.48
1	00:05:1a:79:81:4c	no	0.16
1	00:05:4e:4d:67:dd	no	58.31
1	00:0d:56:69:13:24	no	75.36
1	00:10:dc:a2:f9:28	no	44.88
1	00:10:f3:0d:be:8c	no	35.02
1	00:11:11:13:d0:f5	no	8.60
1	00:11:11:4c:39:59	no	10.76
1	00:11:11:4c:f0:0c	no	125.21
1	00:11:11:6c:d7:74	no	30.30
1	00:11:11:e0:98:17	no	63.63
1	00:14:85:65:fa:99	no	110.73
1	00:15:17:16:ba:20	no	9.50
1	00:15:17:48:94:7e	no	9.02
1	00:15:17:4a:74:5e	no	48.83
1	00:16:36:f0:22:fa	no	118.27
1	00:17:08:81:dc:0b	no	70.91
1	00:19:5b:6b:5c:6e	no	71.95
1	00:19:5b:7d:8a:3d	no	31.62

Figure 6-65 Learn Table

Network Layer

IP ARP

This page provides information based on the Address Resolution Protocol (ARP), which relates Physical Address (MAC Address) and Net Access (IP Addresses).

The screenshot displays the 'IP ARP Table' section of a web interface. On the left, there is a sidebar menu with the following items: System Log, Event Log, SNMP, Interface Statistics, Bridge, Network Layer (expanded), IP ARP (expanded), ICMP Statistics, and RADIUS. The main content area features a table with the following data:

Index	Physical Address	Net Access	Media Type
3	00:10:f3:0d:be:8c	172.18.18.2	Dynamic
3	00:15:17:16:ba:20	172.18.18.20	Dynamic
3	00:50:fc:a5:2c:8c	172.18.18.61	Dynamic
3	00:1d:09:75:79:18	172.18.18.108	Dynamic

Below the table, there are two buttons: 'Refresh' and 'OK'.

Figure 6-66 IP ARP Statistics Page

ICMP Statistics

This page provides statistical information for both received and transmitted messages directed to the AP. Not all ICMP traffic on the network is counted in the ICMP (Internet Control Message Protocol) statistics.

1. Navigate **Monitor > Network Layer > ICMP Statistics**.

ICMP Statistics	
In Msgs	0
In Errors	0
In Dest Unreachs	0
In Time Excds	0
In Parm Probs	0
In Src Quenchs	0
In Redirects	0
In Echos	0
In EchoReps	0
InTimestamps	0
In Timestamp Reps	0
In Addr Masks	0
In Addr Mask Reps	0
Out Msgs	3
Out Errors	0
Out Dest Unreachs	3
Out Time Excds	0
Out Parm Probs	0
Out Src Quenchs	0
Out Redirects	0
Out Echos	0
Out EchoReps	0
Out Timestamps	0
Out Timestamp Reps	0
Out Addr Masks	0
Out Addr Mask Reps	0

Figure 6-67 ICMP Statistics Page

RADIUS

This page provides information about Radius.

Authentication Statistics

This page provides information about RADIUS Authentication for both the Primary and backup servers for each RADIUS server profile.

1. Navigate **Monitor > Radius > Authentication Statistics**.
2. The following descriptions are displayed for the Radius Client Authentication Status page. For more information on features, refer [Authentication Statistics](#)




Figure 6-68 RADIUS Client Authentication Statistics

Accounting Statistics

This page provides information about RADIUS Accounting for both the Primary and backup servers for each RADIUS server profile.

1. Navigate **Monitor > Radius > Accounting Statistics**.
2. The following descriptions are displayed for the Radius Client Accounting Status page. For more information on features, refer [Accounting Statistics](#)




Figure 6-69 RADIUS Client Accounting Stats Page

7

Using SNMP Interface to Manage the Access Point

The Simple Network Management Protocol (SNMP) is an application-layer protocol designed to facilitate the exchange of management information between network devices. It is a part of TCP/IP protocol and most of the network administrators use it.

SNMP MIB (Management Information Base) is a collection of information that is organized hierarchically and it comprises of managed objects which have one or more object instances which are variable. MIBs can be accessed using a network-management protocol such as SNMP.

There are two types of managed objects:

- **Scalar Object:** These are single object instance.
- **Tabular Object:** These are multiple related objects that are grouped in MIB table.

SNMP is a client-server network management architecture. A server requests information from a client's MIB. A particular MIB defines some number of Object Identifiers (OIDs). These OIDs are what is used to request information from a client.

NOTE: Refer to the supplemental document for MIB description to configure the AP-8000.

Pre-requisites

Before you proceed with configuration, you need to confirm following information:

- Proxim provides the MIB along with the CD. You need to ensure that you have configured the IP address in the MIB browser.

NOTE: Proxim recommends using NuDesign to make the modifications in the object identifiers, if required.

- IP address
- Version of SNMP: Select the V2c version of SNMP.
- Port Number: By default the port number is set to 161.
- Read Community Password
- Read/Write Community Password

NOTE: To receive traps, *MgmtSnmptTrapHostTablePassword* should be same as *MgmtSNMPTeadPassword*.

Viewing the MIB Objects

1. Once you have configured the required information, open the MIB in the MIB browser. To open the MIB, you need to provide a specific path and click **Enter**.
2. Navigate to the Proxim in private node.
 - To view all the objects that are available, right-click and select **Walk**. This will display all the default and configured objects.
 - To view a particular object, select the object, right-click and click **Get**. This will display the selected configured object.

Configuring the MIB Objects

To Configure the Scalar Objects :

1. Select the object, right-click and click **Set**. This will display the existing value that is configured.
2. If you want to make modifications for the existing value, double-click the object.
3. This displays the list of values that can be used for configuration, select the required value and click **Ok**.
4. Click **Execute**, this will store the changes in the temporary buffer. Proceed to the **SysMgmtCfgCommit** table to Commit the changes.

To Configure the Tabular Objects:

1. Select the object, right-click and click **Get Table**. This displays the **Table List**.
2. From the menu, click **Set** and drag the table entry for which you want to make the changes to the **Set window**.
NOTE: You can configure object by configuring each entry that is available for the table or update the entire table as single entry.
3. Select the table, right-click, and click **Set**.
4. In the **Set window**, to add a row for a table, enter "0" and this will automatically create a row for a particular table.
5. Add the required parameters and configure those parameters.
6. Click **Execute** and proceed to **SysMgmtCfgCommit** table to Commit the changes.

To apply the changes to the flash memory:

1. Navigate to **deviceMgmt > SysMgmtCfgCommit**, right-click and click **Set**.
2. Set the value as **1** and click **OK**.
3. Click **Execute**, this would configure the new value to the flash memory.

8

Using CLI to Manage the Access Point

The Command Line Interface (CLI) is a primary interface that allows you to configure, manage and monitor the Access Points. You can directly execute the CLI commands to manage the device.

- CLI commands may be entered in real time through a keyboard or submitted with CLI scripts.
- The CLI is available through both the Serial Port interface and over the Ethernet interface using Telnet.

NOTE: All CLI commands and parameters are case-sensitive.

This chapter describes the basic features of CLI and how to use them.

- [Global Configuration Mode](#)
- [Command Line Interface Mode Overview](#)

Global Configuration Mode

Using this mode, you can configure your device globally. Use the configure privileged Exec mode command to enter global configuration mode.

```
[Device-Name] # configure (this command allows to you to move from privileged mode to configure mode) .
```

Press **Enter**.

```
(configure)#
```

The above command indicates that you are now in the global configuration mode. The prompt for global configuration mode consists of Config and the pound sign (#).

Use the following command to view the possible completions that you have access to under this mode:

```
(configure)# ?
Possible completions:
dev-configure: Device Configuration
dev-management: Device Management
dev-monitor: Device Monitor
enable: Exit from configuration mode
exit: Exit from configuration mode
```

From this mode proceed to configure each feature that is available in your device.

General Notes

Prerequisite Skills and Knowledge

To use this document effectively, you should have a working knowledge of Local Area Networking (LAN) concepts, network access infrastructures, and client-server relationships. In addition, you should be familiar with software setup procedures for typical network operating systems and servers.

Notation Conventions

- Computer prompts are shown as constant width type. For example: [Device-Name]>
- Information that you input as shown is displayed in bold constant width type.
- The names of keyboard keys, software buttons, and field names are displayed in bold type. For example: Click the **Configure** button.
- Screen names are displayed in bold italics.

Important Terminology

- Configuration Files - Database files containing the current Access Point configuration. Configuration items include the IP Address and other network-specific values. Config files may be downloaded to the Access Point or uploaded for backup or troubleshooting.
- Download vs. Upload - Downloads transfer files to the Access Point. Uploads transfer files from the Access Point. The TFTP client performs file transfers in both directions.
- Group - A logical collection of network parameter information. For example, the System Group is composed of several related parameters. Groups can also contain Tables. All items for a given Group can be displayed with a **show <Group>** CLI Command.
- Image File - The Access Point software executed from RAM. To update an Access Point you typically download a new Image File. This file is often referred to as the "AP Image".
- Parameter - A fundamental network value that can be displayed and may be changeable. For example, the Access Point must have a unique IP Address and the Wireless interface must be assigned an SSID. Change parameters with the CLI Command Name and Parameter, and view them with the CLI **show** Command.
- Table - Tables hold parameters for several related items. For example, you can add several potential managers to the SNMP Table. All items for a given Table can be displayed with a **show <Table>** CLI Command.
- TFTP - Refers to the both TFTP Server and clients, used for file transfers.

Navigation and Special Keys

This CLI supports the following navigation and special key functions to move the cursor along the prompt line.

Key Combination	Operation
Delete or Backspace	Delete previous character
Ctrl-A	Move cursor to beginning of line
Ctrl-E	Move cursor to end of line
Ctrl-F	Move cursor forward one character
Ctrl-B	Move cursor back one character
Ctrl-D	Delete the character the cursor is on
Ctrl-U	Delete all text to left of cursor
Tab	Complete the command line
?	List available commands

CLI Error Messages

The following table describes the error messages associated with improper inputs or expected CLI behavior.

Error Message	Description
Unknown Command	A non-existent command has been entered at the command prompt.
Invalid Value	An invalid value has been entered at the command prompt.
Error Message	An error message is displayed when a wrong parameter is configured

Reboot Messages

For certain commands, the command prompt would ask for reboot of the device.

Help Message

When you type the command at the command prompt and then press Enter, this will list the value that you can use.

Rules for Table Objects

- To create a Table

- The table index is required.
- Entry status is required
- Modification
 - The table index is required.
 - Entry status is required
- Deletion
 - The table index is required.
 - Entry status is required

For example: (index 1 entry - status destroy or 6). Using this command you can delete a particular row.

Command Line Listing

Using this feature, you can view a list of commands or arguments when you type ? at the command prompt. When you enter a particular character followed with ?, then the command prompt will display all the related commands or arguments that match the character that you have typed. For example:

```
> enable
#show m?
monitor
management
```

Command Line Completion

When you enter a command and then press TAB, this will prompt the complete the command name that you were typing. For example:

```
>enable
#con
```

NOTE: Press the TAB key. This will list the following:

```
#configure
```

Configuring the AP using CLI Commands

Log into the AP using HyperTerminal

1. Open your terminal emulation program (like HyperTerminal) and set the following connection properties:
 - Com Port: <COM1, COM2, etc., depending on your computer>
 - Baud rate: 115200
 - Data Bits: 8
 - Stop bits: 1
 - Flow Control: None
 - Parity: None
2. Under **File > Properties > Settings > ASCII Setup**, enable the **Send line ends with line feeds** option. HyperTerminal sends a line return at the end of each line of code.
3. Enter the CLI password (default username is **admin** and password is **public**).

NOTE: *Proxim recommends changing your default passwords immediately. To perform this operation using CLI commands.*

Log into the AP using Telnet

The CLI commands can be used to access, configure, and manage the AP using Telnet. Follow these steps:

1. Confirm that your computer's IP address is in the same IP subnet as the AP.

NOTE: *If you have not previously configured the Access Point's IP address and do not have a DHCP server on the network, the Access Point will default to an IP address of 169.254.128.132.*

2. Go to the DOS command prompt on your computer.
3. Type **telnet <IP Address of the unit>**.
4. Enter the CLI password default username is **admin** and password is **public**).

Proxim recommends changing your default passwords immediately. To perform this operation using CLI commands.

Command Line Interface Mode Overview

The Command Line Interface (CLI) is divided into different command modes. Each command mode has its own set of commands that manage the network operations. The commands that you use also depends on the mode that you are in.

CLI command prompt allows you to navigate from one command mode to another using certain specific commands. They are:

User Exec Mode

You are in this mode when you start a session and you have limited access to commands that can be executed. The moment you log into device, you are in the EXEC mode as you typically you login with Username and Password. Using this mode you can access your device.

```
Username: admin
Password: public
```

User name and Password Command

```
Username: admin
Password:
SystemName> ?
Possible completions:
disable      Turn off privileged commands
enable      Turn on privileged commands
exit        Exit from EXEC
show        Show
SystemName> enable
SystemName# ?
Possible completions:
configure   Enter configuration mode
disable     Turn off privileged commands
enable     Turn on privileged commands
exit       Exit from EXEC
show       Show
SystemName# _
```

NOTE: The username and password are case-sensitive. If you enter incorrect Password, then a message is displayed stating that the password is incorrect.

In this mode, you can use the following command to view the list of possible completions:

```
[Device-Name]>?
Possible completions:
disable: Turn off the privileged mode
enable: Turn on the privileged mode
exit: Exit from EXEC
show: Show
```

Privileged Exec Mode

Using this mode you can configure the required parameters for your device. The Privileged EXEC mode consists of the device name followed with a pound sign (#).

```
[Device-Name]#
```

Use the following command to access the privileged Exec mode:

```
[Device-Name]>enable (this command enables the privileged Exec mode).
```

To list the commands in the privileged Exec mode, enter ?. This lists the following:

```
[Device-Name]#?
```

Possible completions:

```
configure: Enter configuration mode
disable: Turn off the privileged mode
enable: Turn on the privileged mode
exit: Exit from EXEC
show: Show
```

When you enter “Show” command at the CLI Command prompt, this will list the following features that you can configure or view:

Show Command Tree Structure Command

```
SystemName#  
SystemName# show ?  
Possible completions:  
configure          Device Configuration  
management         Device Management  
monitor            Device Monitor  
SystemName# show configure ?  
Possible completions:  
filtering  
interface  
network  
qos  
security  
vlan  
SystemName# show configure interface ?  
Possible completions:  
ethernet  
wireless  
SystemName# show configure interface wireless ?  
Possible completions:  
properties-11n-table  
properties-table  
vap-table  
SystemName# show configure interface wireless properties-table
```

VLAN Command

```
SystemName# show configure vlan  
// RUNNING-CONFIGURATION //  
// VLAN Configuration //  
vlan <  
status: disable  
vlan-id: -1  
>  
SystemName# _
```

MAC ACL Command

```
SystemName# show configure security mac-acl address-table  
// RUNNING-CONFIGURATION //  
// MAC ACL Address Table //  
SystemName# show configure security mac-acl profiletable  
// RUNNING-CONFIGURATION //  
// MAC ACL Profile Table //  
index 1 <  
name: Default  
operation-type: allow  
status: active  
>  
SystemName#
```

RADIUS Server Table Command

```
SystemName# show configure security radius-server-profiletable
// RUNNING-CONFIGURATION //
// Radius Server Profile Table //
  index 1.1 <
    profile-type: primaryAuthenticationServer
    ipaddress: 169.254.128.133
    port: 1812
    sharedsecret: *****
    status: active
  >
  index 1.2 <
    profile-type: secondaryAuthenticationServer
    ipaddress: 169.254.128.134
    port: 1812
    sharedsecret: *****
    status: notInService
  >
  index 1.3 <
    profile-type: primaryAccountingServer
    ipaddress: 169.254.128.133
    port: 1813
    sharedsecret: *****
    status: active
  >
  index 1.4 <
    profile-type: secondaryAccountingServer
    ipaddress: 169.254.128.134
    port: 1813
    sharedsecret: *****
    status: notInService
  >
SystemName#
```

RADIUS Supported Profile Table Command

```
SystemName# show configure security radius-supported-table
// RUNNING-CONFIGURATION //
// Security Radius Supported Table //
  index 1 <
    profilename: Default Radius
    max-retransmissions: 3
    message-response-time: 3
    re-authentication-period: 0
    entry-status: active
  >
SystemName#
```

Security Wireless Config Table Command

```
SystemName# show configure security wireless-config-table
// RUNNING-CONFIGURATION //
// Security Configuration Table //
  index 1 <
    profile-name: Default Security
    authentication-mode: dot1x
    wep-key-index: 0
    wepkey: *****
    wepkeylength: 0
    encryption-type: wpa-tkip
    psk: *****
    rekeyinterval: 900
    entry-status: active
  >
SystemName#
```

QoS Profile and Policy Command

```
SystemName# show configure qos profile-table
// RUNNING-CONFIGURATION //
// Qos Profile Table //
  index 1 <
    profile-name: Default
    policy-name: Default
    edca-profile-name: Default
    nack-status: disable
  >
SystemName# show configure qos policy-table
// RUNNING-CONFIGURATION //
// QoS Policy Table //
  index 1.1 <
    policy-name: Default
    policy-type: inboundLayer2
    priority-mapping: 1
    marking-status: enable
    entry-status: notInService
  >
  index 1.2 <
    policy-name: Default
    policy-type: inboundLayer3
    priority-mapping: 1
    marking-status: enable
    entry-status: notInService
  >
  index 1.3 <
    policy-name: Default
    policy-type: outboundLayer2
    priority-mapping: 1
    marking-status: enable
    entry-status: notInService
  >
  index 1.4 <
    policy-name: Default
    policy-type: outboundLayer3
    priority-mapping: 1
    marking-status: enable
    entry-status: notInService
  >
SystemName#
```

QoS EDCA Command

```
SystemName# show configure qos wireless-qos-edca
// RUNNING-CONFIGURATION //
// QoS EDCA Table Table //
index 1.1 <
  profile-name: Default
  sta-cwmin: 15
  sta-cwmax: 1023
  sta-aifsn: 7
  sta-txop: 0.0000
  sta-acm: disable
  ap-cwmin: 15
  ap-cwmax: 1023
  ap-aifsn: 7
  aptxop: 0.0000
  ap-acm: disable
}
index 1.2 <
  profile-name: Default
  sta-cwmin: 15
  sta-cwmax: 1023
  sta-aifsn: 3
  sta-txop: 0.0000
  sta-acm: disable
  ap-cwmin: 15
  ap-cwmax: 63
  ap-aifsn: 3
  aptxop: 0.0000
  ap-acm: disable
}
index 1.3 <
  profile-name: Default
  sta-cwmin: 7
  sta-cwmax: 15
  sta-aifsn: 2
  sta-txop: 3.0000
  sta-acm: disable
  ap-cwmin: 7
  ap-cwmax: 15
  ap-aifsn: 1
  aptxop: 3.0000
  ap-acm: disable
}
index 1.4 <
  profile-name: Default
  sta-cwmin: 3
  sta-cwmax: 7
  sta-aifsn: 2
  sta-txop: 1.5040
  sta-acm: disable
  ap-cwmin: 3
  ap-cwmax: 7
  ap-aifsn: 1
```

Wireless Properties Command

```
System Name# show configure interface wireless properties-table
// RUNNING-CONFIGURATION //
// Wireless Properties Table //
radio 1 <
  radio-status: enable
  operational-mode: DOT11G
  supported-operational-mode: DOT11G,DOT11NG,DOT11A,DOT11NA
  current-channel-bandwidth: 20
  supported-channel-bandwidth: 20,40
  auto-channel-selection: disable
  current-operating-channel: 6
  supportedchannel: 1,2,3,4,5,6,7,8,9,10,11
  auto-rate-selection: enable
  transmit-rate: 0
  supported-rate: 1,2,5,6,9,11,12,18,24,36,48,54
  vap-rts-threshold: 2346
  vap-beacon-interval: 100
  transmit-power-control: 0
  cellsize: large
  dtim: 3
>
radio 2 <
  radio-status: enable
  operational-mode: DOT11G
  supported-operational-mode: DOT11G,DOT11NG,DOT11A,DOT11NA
  current-channel-bandwidth: 20
  supported-channel-bandwidth: 20,40
  auto-channel-selection: disable
  current-operating-channel: 6
  supportedchannel: 1,2,3,4,5,6,7,8,9,10,11
  auto-rate-selection: enable
  transmit-rate: 0
  supported-rate: 1,2,5,6,9,11,12,18,24,36,48,54
  vap-rts-threshold: 2346
  vap-beacon-interval: 100
  transmit-power-control: 0
  cellsize: large
  dtim: 3
>
```

11n Wireless Properties Command

```
System Name# show configure interface wireless properties-11n-table
// RUNNING-CONFIGURATION //
// Wireless Properties 11n Table //
radio 1 <
  ampdu-status: enable
  ampdu-max-numberframes: 64
  ampdu-max-frame-size: 65535
  amsdu-status: disable
  amsdu-max-frame-size: 4096
  frequency-extension: upperExtensionChannel
  guard-interval: enable-400nSec
  tx-antennas: seven
  rx-antennas: seven
>
radio 2 <
  ampdu-status: enable
  ampdu-max-numberframes: 64
  ampdu-max-frame-size: 65535
  amsdu-status: disable
  amsdu-max-frame-size: 4096
  frequency-extension: upperExtensionChannel
  guard-interval: enable-400nSec
  tx-antennas: seven
  rx-antennas: seven
>
System Name#
```

Wireless VAP Command

```
System Name# show configure interface wireless vap-table
// RUNNING-CONFIGURATION //
// Wireless VAP Table //
index 1.1 <
  vaptype: ap
  vapssid: My Wireless Network 1_1
  vapbssid: 00:21:86:51:e4:d2
  broadcast-ssid: enable
  fragmentation-threshold: 2346
  security-profile-name: Default Security
  radius-profile-name: Default Radius
  vlan-id: -1
  vlan-priority: 0
  qos-profile-name: Default
  macacl-status: disable
  radius-macacl-status: disable
  radius-accounting-status: enable
  status: enable
  >
index 1.2 <
  vaptype: ap
  vapssid: My Wireless Network 1_2
  vapbssid:
  broadcast-ssid: enable
  fragmentation-threshold: 2346
  security-profile-name: Default Security
  radius-profile-name: Default Radius
  vlan-id: -1
  vlan-priority: 0
  qos-profile-name: Default
  macacl-status: disable
  radius-macacl-status: disable
  radius-accounting-status: disable
  status: disable
  >
```

Ethernet Interface Command

```
System Name# show configure interface ethernet
// RUNNING-CONFIGURATION //
// Ethernet Interface //
ethernet <
  mac-address: 00:20:a6:0b:a7:65
  speed: 4
  transmit-mode: fullDuplex
  >
```

Network Configuration Command

```
System Name# show configure network
// RUNNING-CONFIGURATION //
// Network Configuration //
network <
  ipaddress: 172.18.18.197
  mask: 255.255.255.0
  gateway: 172.18.18.2
  address-type: static
  >
System Name# _
```

Advanced Filter and Global Filter Command

```
System Name# show configure filtering advanced-filter-table
// RUNNING-CONFIGURATION //
// Advanced Filter Table //
  index 1 <
    protocol-name: Deny IP% RIP
    direction: both
    row-status: notInService
  >
  index 2 <
    protocol-name: Deny IP% SAP
    direction: both
    row-status: notInService
  >
  index 3 <
    protocol-name: Deny IP% LSP
    direction: both
    row-status: notInService
  >
  index 4 <
    protocol-name: Deny IP Broadcasts
    direction: both
    row-status: notInService
  >
  index 5 <
    protocol-name: Deny IP Multicasts
    direction: both
    row-status: notInService
  >
System Name# show configure filtering global-filter-flag
// RUNNING-CONFIGURATION //
// Filter Control Configuration //
  filtering <
    global filter flag: disable
  >
System Name# show configure filtering intra-bss
// RUNNING-CONFIGURATION //
// Filter Intra BSS Configuration //
  filtering <
    intra-bss: disable
  >
```

TCP-UDP and Static MAC Address Table Commands

```
System Name# show configure filtering static-mac-addr-filter
// RUNNING-CONFIGURATION //
// Static MAC Address Filter Table //
System Name# show configure filtering tcp-udp-filter table
// RUNNING-CONFIGURATION //
// TCP UDP Port Filter Table //
  index 1 <
    protocol-name: NetBios Name Service
    port-number: 137
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
  index 2 <
    protocol-name: NetBios Datagram Service
    port-number: 138
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
  index 3 <
    protocol-name: NetBios Session Service
    port-number: 139
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
  index 4 <
    protocol-name: SNMP service
    port-number: 161
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
  index 5 <
    protocol-name: IPSEC/ISAKMP
    port-number: 500
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
  index 6 <
    protocol-name: L2TP
    port-number: 1701
    port-type: both
    interface: allInterfaces
    row-status: notInService
  >
```


Protocol Filter, Filter Type and Filter Control Table Command

```
System Name# show configure filtering protocol-filter filter-control
// RUNNING-CONFIGURATION //
// Protocol Filtering Configuration //
    filtering <
        filter-control disable
    >
System Name# show configure filtering protocol-filter filter-type
// RUNNING-CONFIGURATION //
// Protocol Filtering Configuration //
    protocol-filter <
        filter-type passthru
    >
System Name# show configure filtering protocol-filter table
// RUNNING-CONFIGURATION //
// Protocol Filter Table //
    index 1 <
        protocol-name: Apollo Domain
        protocol-number: 80:19
        filter-status: block
        row-status: notInService
    >
    index 2 <
        protocol-name: Apple Talk 1 and 2
        protocol-number: 80:9b
        filter-status: block
        row-status: notInService
    >
    index 3 <
        protocol-name: Apple Talk ARP 1 and 2
        protocol-number: 80:f3
        filter-status: block
        row-status: notInService
    >
    >
```

Access Control and HTTP, Telnet and TFTP Commands

```
System Name# show management access-control
// RUNNING-CONFIGURATION //
// Access Control Configuration //
    accesscontrol <
        http-access-control: enable
        httpsaccesscontrol: enable
        snmp-access-control: enable
        telnet-access-control: enable
        ssh-access-control: enable
        mgmt-access-status: disable
    >
// Management Access Table Configuration //
System Name# show management http
// RUNNING-CONFIGURATION //
// HTTP Configuration //
    http <
        password: *****
    >
System Name# show management telnet
// RUNNING-CONFIGURATION //
// Telnet Configuration //
    telnet <
        password: *****
    >
System Name# show management tftp
// RUNNING-CONFIGURATION //
// TFTP Configuration //
    tftp <
        server-ip: 169.254.128.133
        file-name: image.bin
        file-type: image
        operation-type: none
        operational-status: idle
    >
```

SNMP Read, Read-Write Password and Trap Host Table Command

```
System Name# show management snmp ?
Possible completions:
access-table
read-password
read-write-password
trap-host-table
System Name# show management snmp read-password
// RUNNING-CONFIGURATION //
// SNMP Configuration //
snmp <
read-password: *****
>
System Name# show management snmp read-write-password
// RUNNING-CONFIGURATION //
// SNMP Configuration //
snmp <
read-write-password: *****
>
System Name# show management snmp trap-host-table
// RUNNING-CONFIGURATION //
// SNMP Trap Host Table //
index 1 <
ip-address: 169.254.128.133
password: *****
>
System Name#
```

Country Code and Management Commands

```
System Name# show management system ?
Possible completions:
country-code
feature
information
inventory-mgmt
management
System Name# show management system country-code
// RUNNING-CONFIGURATION //
// System Configuration //
system <
country-code: NA
>
System Name# show management system feature
// RUNNING-CONFIGURATION //
// System Feature Configuration //
system-feature <
feature: 0
>
System Name# show management system management
// RUNNING-CONFIGURATION //
// System Management Configuration //
system-management <
Config-change-count: 1
Commit: 0
Restore: 0
Error messages: Access Table Status is not enabled
Reboot: 0
Factory-reset: 0
>
```

System Information Command

```
System Name# show management system information
// RUNNING-CONFIGURATION //
// System Information Configuration //
system <
description: System Description
OID: 1.3.6.1.4.1.841
uptime: 0-00:19:09.24
name: System Name
contact-mail: name@organization.com
phone-number: Contact Phone Number
location-name: System Location
gps-longitude: -121.8893
gps-latitude: 37.3321
gps-altitude: 10
productdescr: ORiNOCO AP-8000 @ WD v1.0.0 SN-08UC39110164 v1.0.0<1110
21>
>
```

System Inventory Management Command

```
System Name# show management system inventory-mgmt ?
Possible completions:
component-table
security-id
System Name# show management system inventory-mgmt component-table
// RUNNING-CONFIGURATION //
// System Inventory Management Table //
index 1 <
serial-number: BUILD-360
name: Wireless Card 1 -NIC <0x60>
component-id: 2300
component-variant: 1
release-version: 7
major-version: 0
minor-version: 0
>
index 2 <
serial-number: BUILD-360
name: Wireless Card 2 -NIC <0x60>
component-id: 2300
component-variant: 1
release-version: 7
major-version: 0
minor-version: 0
>
index 3 <
serial-number: 111021
name: AP Software Image
component-id: 2100
component-variant: 1
release-version: 1
major-version: 0
minor-version: 0
>
index 4 <
serial-number: 08UC39110164
name: Hardware Inventory
component-id: 2000
component-variant: 1
release-version: 1
major-version: 0
```

```
index 7 <
  serial-number: -NA-
  name: Config File
  component-id: 2201
  component-variant: 1
  release-version: 0
  major-version: 0
  minor-version: 0
}
index 8 <
  serial-number: -NA-
  name: License File
  component-id: 0
  component-variant: 0
  release-version: 0
  major-version: 0
  minor-version: 0
```

Event Log and ICMP Commands

```
System Name# show monitor event-log
// RUNNING-CONFIGURATION //
// EventLog Configuration //
  eventlog <
    priority: critical
    log-reset: 0
  }
System Name# show monitor icmp-statistics
// RUNNING-CONFIGURATION //
// ICMP Configuration //
  icmp <
    icmp-in-messages: 39
    icmp-in-errors: 3
    icmpindestinationunreachs: 33
    icmpintimeexcds: 33
    icmpinparm-probs: 0
    icmpin-srcquenchs: 0
    icmpinredirects: 0
    icmpin-echos: 2
    icmp-inechoreps: 1
    icmpintimestamps: 0
    icmpintimestamreps: 0
    icmp-inaddrmask: 0
    icmpinaddrmaskreps: 0
    icmpOutMsgs: 41
    icmpOutErrors: 0
    icmpOutDestUnreachs: 39
    icmpOutTimeExcds: 0
    icmpOutParmProbs: 0
    icmpOutSrcQuenchs: 0
    icmpOutRedirects: 0
    icmpOutEchos: 0
    icmpOutEchoReps: 2
    icmpOutTimestamps: 0
    icmpOutTimestampReps: 0
    icmpOutAddrMasks: 0
    icmpOutAddrMaskReps: 0
  }
}
```

IP ARP Statistics and SNTP Command

```
System Name# show monitor ip-arp-statistics
// RUNNING-CONFIGURATION //
// Ip Net to Media Table //
index 3 <
  phyaddress: 00:16:36:f0:22:fa
  netaddress: 172.18.18.85
  mediatype: dynamic
}
System Name# show monitor sntp
// RUNNING-CONFIGURATION //
// SNTP Configuration //
sntp <
  status: disable
  primary-server: time.nist.gov
  secondary-server:
  time-zone: dateline
  daylight-saving-time: unchanged
  current-time: 01-01-1970 2:41:17
}
System Name#
```

Syslog configuration and RADIUS Client Authentication Table Commands

```
System Name# show monitor syslog
// RUNNING-CONFIGURATION //
// SysLog Configuration //
syslog <
  status: enable
  priority: critical
  reset: 0
}
// Host Table Configuration //
index 1 <
  ip-address: 10.0.0.1
  port: 1812
  comment: Row1
  entry-status: active
}
System Name# show monitor radius client-auth-statistics
// radius client authentication Statistics //
index 0.1 <
  roundtriptime: 0-00:00:00.00
  requests: 0
  retransmissions: 0
  access-accepts: 0
  accessrejects: 0
  accesschallenges: 0
  responses: 0
  malformedresponses: 0
  badauthenticators: 0
  timeouts: 0
  unknowntypes: 0
  packetdropped: 0
}
System Name#
```

RADIUS Client Access Command

```
System Name# show monitor radius client-access-statistics
// radius client access Statistics //
  index 0.1 <
    roundtrip: 0-00:00:00.00
    requests: 1
    re-transmissions: 4
    responses: 0
    malformedresponses: 0
    timeouts: 4
    unknowntypes: 0
    packetdropped: 0
  >
  index 4.1 <
    roundtrip: 0-00:00:00.00
    requests: 1
    re-transmissions: 4
    responses: 0
    malformedresponses: 0
    timeouts: 4
    unknowntypes: 0
    packetdropped: 0
  >
System Name#
```

Interface Statistics Command

```
System Name# show monitor interface-statistics
// RUNNING-CONFIGURATION //
  if-number: 7
// Interface-Statistics //
  index 1 <
    descripton: eth0
    type: ethernet-csmacd
    mtu: 1500
    speed: 100000000
    physical-address: 00:20:a6:0b:a7:65
    admin-status: up
    operational-status: up
    last change: 0-00:04:52.00
    in-octets: 6914370
    in-unicast: 53705
    in-non-unicast: 0
    in-discards: 0
    in-errors: 0
    in-unknown-protos: 11150580
    out-octets: 11150580
    out-unicast-packets: 27871
    out-non-unicast-packets: 0
    out-discards: 0
    out-errors: 0
    outqlen: 0
    specific: 0.0
  >
  index 2 <
    descripton: lo
    type: softwareLoopback
    mtu: 16436
    speed: 0
    physical-address:
    admin-status: up
    operational-status: up
    last change: 0-00:03:05.00
    in-octets: 97055
    in-unicast: 448
    in-non-unicast: 0
    in-discards: 0
    in-errors: 0
    in-unknown-protos: 97055
    out-octets: 97055
    out-unicast-packets: 448
    out-non-unicast-packets: 0
    out-discards: 0
    out-errors: 0
    outqlen: 0
    specific: 0.0
  >
>
```

Wireless Station Statistics Command

```
System Name# show monitor wireless-station-statistics
// Wireless Station Statistics //
```

IP Address, Subnet Mask and Gateway Command

```
System Name# configure
System Name(config)# dev-configure
System Name(config-dev(config))# network
System Name(config-dev(config)-net)# index 1 ?
Possible completions:
<[Enter]>      Execute this command
address-type   Network IP Address Type
gateway        Network Gateway
ipaddress      Ip Address
mask           Subnet Mask
System Name(config-dev(config)-net)# index 1 ipaddress 10.0.0.1
Changes in IP Configuration Requires Reboot...
System Name(config-dev(config)-net)# index 1 mask 255.255.255.0
System Name(config-dev(config)-net)# index 1 gateway 10.0.0.10
System Name(config-dev(config)-net)# index 1 address-type static
Changes in IP Configuration Requires Reboot...
System Name(config-dev(config)-net)#
```

Scalar Objects Commands

```
System Name# configure
System Name(config)# dev-management
System Name(config-mgmt)# tftp
System Name(config-mgmt-tftp)# ?
Possible completions:
exit           Exit from configure mode
file-name      Tftp File name
file-type      Tftp file type
operation-type Tftp Operation Type
server-ip      Tftp Server IP address
System Name(config-mgmt-tftp)# file-name string
System Name(config-mgmt-tftp)# file-type config
System Name(config-mgmt-tftp)# server-ip 10.0.0.1
System Name(config-mgmt-tftp)# operation-type download
Changes in Operation Type to download only Requires Reboot...
```

Table Entries Commands

For any dynamic row creation, set first the entry status and then other elements. Finally set the Entry status.

Example:

Set entry status for protocol filter table index

```
Filter-status
Protocol-name
Protocol-number
Again entry-status
```

NOTE: Adding the table entries the user has to set "index 0 values entry status 4"

```
System Name(config-dev(config))# filtering
System Name(config-dev(config)-filter)# protocol-filter
System Name(config-dev(config)-filter-protocol)# protocol-table
System Name(config-dev(config)-filter-protocol-tbl)# index 0 ?
Possible completions:
<[Enter]>      Execute this command
filter-status  Ethernet Protocol Status
protocol-name  Ethernet Protocol Name
protocol-number Ethernet Protocol Number
row-status     Filter Table Row Status
System Name(config-dev(config)-filter-protocol-tbl)# index 0 row-status 4
System Name(config-dev(config)-filter-protocol-tbl)# index 0 filter-status block
System Name(config-dev(config)-filter-protocol-tbl)# index 0 protocol-name tcp
System Name(config-dev(config)-filter-protocol-tbl)# index 0 protocol-number 20:21
System Name(config-dev(config)-filter-protocol-tbl)# index 0 row-status 4
System Name(config-dev(config)-filter-protocol-tbl)#
```

Table Entry Deletion Command

```
System Name(config-dev(config)-filter-protocol-tbl)# index 1 row-status destroy
System Name(config-dev(config)-filter-protocol-tbl)#
```

Table Entry Edition Command

```
System Name(config-dev(config)-filter-protocol-tbl)# index 21 protocol-name string
System Name(config-dev(config)-filter-protocol-tbl)#
```

VAP Table Commands

```
System Name# configure
System Name(config)# dev-configure
System Name(config-dev(config))# interface
System Name(config-dev(config)-if)# wireless
System Name(config-dev(config)-if-wireless)# vap-table
System Name(config-dev(config)-if-wireless-vap(tbl))# index 1 ?
Possible completions:
<[Enter]>          Execute this command
second-index      Seconday Index
System Name(config-dev(config)-if-wireless-vap(tbl))# index 1 second-index 1 ?
Possible completions:
<[Enter]>          Execute this command
broadcast-ssid
fragmentation-threshold
mac-acl-status
qos-profile-name
radius-accounting-status
radius-macacl-status
radius-profile-name
security-profile-name
vap-ssid
vap-status
vap-type
vlan-id
vlan-priority
System Name(config-dev(config)-if-wireless-vap(tbl))# index 1 second-index 1 vap-type sta
System Name(config-dev(config)-if-wireless-vap(tbl))#
```


Troubleshooting

This chapter provides information on the following:

- [Troubleshooting Concepts](#)
- [Symptoms and Solutions](#)
- [Recovery Procedures](#)
- [Related Applications](#)

NOTE: This section helps you locate problems related to the AP device setup. For details about RADIUS, TFTP, serial communication programs (such as HyperTerminal), Telnet applications, or web browsers, please see the documentation that came with the respective application for assistance.

Troubleshooting Concepts

The following list identifies important troubleshooting concepts and topics. The most common initialization and installation problems relate to IP addressing. For example, you must have valid IP addresses for both the AP and the management computer to access the unit's HTTP interface.

- **IP Address management is fundamental.**
- **Factory default units are set for “Static” (DHCP) IP Address assignment.** The default IP address for the AP is **169.254.128.132** if your network does not have a DHCP server. If you connect the AP to a network with an active DHCP server, then use ScanTool to locate the IP address of your unit. If a DHCP server is not active on your subnet, then use ScanTool to assign a static IP address to the unit.
- **The Trivial File Transfer Protocol (TFTP) provides a means to download and upload files.** These files include the AP Image (executable program) and configuration files.
- **If the AP password is lost or forgotten, you will need to reset to default values.** The [Soft Reset to Factory Defaults](#) or [Hard Reset to Factory Defaults](#) procedures reset the configuration, but do not change the current AP Image.
- **The AP Supports a Command Line Interface (CLI).** If you have trouble in locating your AP in the network, connect to the unit directly using the serial interface and see [Using CLI to Manage the Access Point](#) for CLI command syntax and parameter names.
- **ScanTool does not work over routers.** You must be connected to the same subnet/physical LAN segment to use ScanTool. Note that ScanTool also works over the wireless interface; you can run it on a wireless client connected to the target AP or an AP connected to the same LAN segment/subnet.
- **If everything else fails.** Use Force Reload and load the image again from the bootloader.

Symptoms and Solutions

Connectivity Issues

Connectivity issues include any problem that prevents you from powering up or connecting to the AP.

AP Unit Will Not Boot - No LED Activity

1. Make sure your power source is operating.
2. Make sure all cables are connected to the AP correctly.
3. If you are using Gigabit Ethernet PoE, make sure you are using a Category 5/Category 6, foiled, twisted pair cable to power the AP.

Serial Link Does Not Work

1. Make sure you are using a standard, straight-through, 9-pin serial cable.
2. Double-check the physical network connections.
3. Make sure your PC terminal program (such as HyperTerminal) is active and configured to the following values:
 - Com Port: (COM1, COM2, etc. depending on your computer);
 - Baud rate: 115200; Data bits: 8; Stop bits: 1; Flow Control: None; Parity: None;
 - Line Feeds with Carriage Returns
(In HyperTerminal select: **File > Properties > Settings > ASCII Setup > Send Line Ends with Line Feeds**)

Ethernet Link Does Not Work

1. Double-check the physical network connections. Use a known-good unit to make sure the network connection is present. Once you have the AP IP address, you can use the “Ping” command over Ethernet to test the IP Address. If the AP responds to the Ping, then the Ethernet Interface is working properly.
2. By default, the Access Point will attempt to automatically detect the Ethernet settings. However, if you are having problems with the Ethernet link, manually configure the Access Point’s Ethernet settings. For example, if your switch operates at 100 Mbits/sec/Full Duplex, manually configure the Access Point to use these settings. If you cannot access the unit over Ethernet, then use the CLI interface over the serial port to configure the Ethernet port
3. Perform network infrastructure troubleshooting (check switches, routers, etc.).

Basic Software Setup and Configuration Problems

Lost AP, Telnet, or SNMP Password

1. Perform the [Soft Reset to Factory Defaults](#) in this guide. This procedure resets system and network parameters, but does not affect the AP Image. The default AP HTTP, Telnet, and SNMP usernames are “**admin**” and passwords are “**public**”.

Client Computer Cannot Connect

1. Client computers should have the same Network Name and security settings as the AP.
2. Network Names should be allocated and maintained by the Network Administrator.
3. See the documentation that came with your client card for additional troubleshooting suggestions.

AP Has Incorrect IP Address

1. Default IP Address Assignment mode is dynamic (DHCP). If you do not have a DHCP server on your network, the default IP Address is **169.254.128.132**. If you have more than one uninitialized AP connected to the network, they will all have the same default IP address and you will not be able to communicate with them (due to an IP address conflict). In this case, assign each AP a static IP address via the serial cable or turn off all units but one and change the IP address using ScanTool one at a time.

2. The AP only contacts a DHCP server during boot-up. If your network's DHCP server is not available while the AP is booting, the device will use the default IP address (**169.254.128.132**). Reboot the AP once your DHCP server is on-line again or use the ScanTool to find the Access Point's current IP address.
3. To find the unit's current IP address if using DHCP, open the IP Client Table in the DHCP Server and match the Access Point's IP address to its MAC address (found on the product label). Alternatively, use ScanTool to identify an Access Point's current IP address.
4. Once you have the current IP address, use the HTTP or CLI Interface to change the unit's IP settings, if necessary.
5. If you use static IP Address assignments, and cannot access the unit over Ethernet, use the [Initializing the IP Address using CLI](#) procedure. Once the IP Address is set, you can use the Ethernet Interface to complete configuration. If the AP contains the default or known IP and is not accessible, then you need to check the Management VLAN configuration.
6. Perform the [Soft Reset to Factory Defaults](#) in this guide. This will reset the unit to "DHCP" mode. If there is a DHCP Server on the network, the DHCP Server will assign an IP Address to the AP.

HTTP Interface or Telnet Interface Does Not Work

1. Make sure you are using a compatible browser:
 - Microsoft Internet Explorer 6 with Service Pack 1 or later
 - Netscape 7.1 or later
2. Make sure you have the proper IP address. Enter your Access Point's IP Address in the browser address bar, similar to this example:
http://192.168.1.100
When the **Enter Network Password** window appears, enter the **User Name** and enter the HTTP password in the **Password** field. The default HTTP username is **admin** and password is **public**.
3. Use the CLI over the serial port to check the IP Access Table, which can be restricting access to Telnet and HTTP.

HTML Help Files Do Not Appear

1. Verify that the HTML Help files are installed in the default directory:
C:/Program Files/Proxim Wireless/AP-8000/HTML.
If the Help files are not located in this folder, contact your network administrator to find out where the Help files are located on your server.
2. Copy the entire folder to your Web server.

Telnet CLI Does Not Work

1. Make sure you have the proper IP Address. Enter your AP IP address in the Telnet connection dialog, from a DOS prompt, type:
C:\> telnet <AP IP Address>
2. Use the CLI over the serial port to check the IP Access Table, which can be restricting access to Telnet and HTTP.

TFTP Server Does Not Work

1. Make sure the TFTP Server has been started.
2. Verify the IP address of the TFTP Server. The server may be local or remote, provided you can reach the device from that.
3. Configure the TFTP Server to "point" to the folder containing the file to be downloaded (or to the folder in which the file is to be uploaded).
4. Verify that you have entered the proper AP Image file name (including the file extension) and directory path (if needed).
5. If you have a problem uploading a file, verify that the TFTP server is configured to allow uploads (typically the default setting is to allow only downloads).

Client Connection Problems

Client Software Finds No Connection

Make sure you have configured your client software with the proper Network Name and Security settings. Network Names and WEP Keys are typically allocated and maintained by your network administrator.

Client PC Card Does Not Work

1. Make sure you are using the latest PC Card driver software.
2. Download and install the latest ORINOCO client software from <http://support.proxim.com>.

Intermittent Loss of Connection

1. Make sure you are within range of an active AP.
2. You can check the signal strength using the signal strength gauge on your client software.

Client Does Not Receive an IP Address - Cannot Connect to Internet

1. If the AP is configured as a DHCP server, open the Web-browser Interface and select the **Configure** button and then the **Network** tab to make sure the proper DHCP settings are being used.
2. If you are not using the DHCP server feature on the AP, then make sure that your local DHCP server is accessible from the Access Point's subnet.
3. If using Gigabit Ethernet PoE, make sure you are not using a crossover Ethernet cable between the AP and the hub.

VLAN Operation Issues

Verifying Proper Operation of the VLAN Feature

The correct VLAN configuration can be verified by "pinging" both wired and wireless hosts from both sides of the AP device and the network switch. Traffic can be "sniffed" on the wired (Ethernet), if configured. Bridge frames generated by wireless clients and viewed on one of the backbones should contain IEEE 802.1Q compliant VLAN headers or tags. The VLAN ID in the headers should correspond to one of the VLAN User IDs configured for the AP.

VLAN Workgroups

The correct VLAN assignment can be verified by pinging the AP to ensure connectivity, by pinging the switch to ensure VLAN properties, and by pinging hosts past the switch to confirm the switch is functional. Ultimately, traffic can be "sniffed" on the Ethernet using third-party packages. Most problems can be avoided by ensuring that 802.1Q compliant VLAN tags containing the proper VLAN ID have been inserted in the bridged frames. The VLAN ID in the header should correspond to the user's assigned network name.

What if network traffic is being directed to a nonexistent host?

- All sessions are disconnected, traffic is lost, and a [Forced Reload](#) is necessary.
- Workaround: you can configure the switch to mimic the nonexistent host.

I have just configured the Management ID and now I can't manage the AP?

- Check to ensure your password is correct. If your password is incorrect or all inbound packets do NOT have the correct tag, then a [Forced Reload](#) is necessary.

CAUTION: *The [Forced Reload](#) procedure disconnects all users and resets all values to factory defaults.*

Gigabit Ethernet PoE

The AP Does Not Work

1. Verify that you are using a standard UTP Category 5/Category 6 cable.
2. Try a different port on the same Gigabit Ethernet PoE hub (remember to move the input port accordingly) – if it works, there is probably a faulty port or bad RJ-45 port connection.
3. If possible, try to connect the AP to a different Gigabit Ethernet PoE hub.
4. Try using a different Ethernet cable – if it works, there is probably a faulty connection over the long cable, or a bad RJ-45 connection.
5. Check power plug and hub.
6. If the Ethernet link goes down, check the cable, cable type, switch, and hub.

There Is No Data Link

1. Verify that the indicator for the port is “on.”
2. Verify that the Gigabit Ethernet PoE hub is connected to the Ethernet network with a good connection.
3. Verify that the Ethernet cable is Category 5 or better and is less than 100 meters (approximately 325 feet) in length from the Ethernet source to the AP.
4. Try to connect a different device to the same port on the Gigabit Ethernet PoE hub – if it works and a link is established, there is probably a faulty data link in the AP.
5. Try to re-connect the AP to a different output port (remember to move the input port accordingly) – if it works, there is probably a faulty output or input port in the Gigabit Ethernet PoE hub or a bad RJ-45 connection.

“Overload” Indications

1. Verify that you are not using a cross-over cable between the Gigabit Ethernet PoE output port and the AP.
2. Verify that there is no short over any of the twisted pair cables.
3. Move the device into a different output port (remember to move the input port accordingly); if it works, there is probably a faulty port or bad RJ-45 connection.

Recovery Procedures

The most common installation problems relate to IP addressing. For example, without the TFTP server IP Address, you will not be able to download a new AP Image to the AP. IP Address management is fundamental. We suggest you to create a chart to document and validate the IP addresses for your system.

If the password is lost or forgotten, you will need to reset the AP to default values. The [Soft Reset to Factory Defaults](#) and [Hard Reset to Factory Defaults](#) procedures reset configuration settings, but do not change the current AP Image.

If the AP has a corrupted software image, follow the [Forced Reload](#) procedure to erase the current AP Image and download a new image.

Soft Reset to Factory Defaults

Use this procedure to reset the network configuration values, including the password, IP address, and subnet mask. The current AP Image is not deleted.

1. Click **Management Services > Factory Reset**.
2. Click **Reset to Factory Default**; the device is reset to its factory default state.
3. If not using DHCP, use the ScanTool or use CLI over a serial connection to set the IP address, subnet mask, and other IP parameters. See [Using CLI to Manage the Access Point](#) for CLI information.

If you do not have access to the HTTP or CLI interfaces, use the procedure described in [Hard Reset to Factory Defaults](#).

Hard Reset to Factory Defaults

If you cannot access the unit or you have lost its password, you can reset the unit to the factory default settings using the Reload button on the unit, as described below.

1. Using the end of a paper clip or pin, depress and hold the Reload button on the back of the unit for a minimum of 5 seconds but no more than 10 seconds. The configuration is deleted from the unit and the unit reboots, using a factory default configuration.

NOTE: You need to use a pin or the end of a paperclip to press the button.

CAUTION: If you hold the Reload button for longer than 20 seconds, you may go into Forced Reload mode, which erases the unit's embedded software. This software must be reloaded through an Ethernet connection with access to a TFTP server. See [Forced Reload](#) below for instructions.

2. If not using DHCP, use the ScanTool or use CLI over a serial connection to set the IP address, subnet mask, and other IP parameters. See [Using CLI to Manage the Access Point](#) for CLI information.

Forced Reload

With Forced Reload, you bring the unit into bootloader mode by erasing the embedded software. Use this procedure only as a last resort if the unit does not boot and the procedure did not help.

CAUTION: By completing this procedure, the embedded software in the AP will be erased. You will need to reload the software before the unit is operational.

To do a forced reload:

1. While the unit is running, use a pin or the end of a paperclip to press the **RESET** button.
The AP reboots and the indicators begin to flash.
2. Press and hold the **RELOAD** button for about 20 seconds until the **POWER LED** turns amber.
The AP deletes the current AP Image.
3. Follow one of the procedures below to load a new AP Image to the Access Point:
 - [Download a New Image Using ScanTool](#)

– [Download a New Image Using the Bootloader CLI](#)

Because the CLI option requires a physical connection to the unit's serial port, Proxim recommends the ScanTool option.

Download a New Image Using ScanTool

To download the AP Image, you will need an Ethernet connection to the computer on which the TFTP server resides and to a computer that is running ScanTool (this is either two separate computers connected to the same network or a single computer running both programs).

ScanTool detects if an Access Point does not have a valid software image installed. In this case, the **TFTP Server** and **Image File Name** parameters are enabled in the ScanTool's **Change** screen so you can download a new image to the unit. (These fields are grayed out if ScanTool does not detect a software image problem.)

Preparing to Download the AP Image

Before starting, you need to know the Access Point's IP address, subnet mask, the TFTP Server IP Address, and the AP Image file name. Make sure the TFTP server is running and configured to point to the folder containing the image to be downloaded.

Download Procedure

Follow these steps to use ScanTool to download a software image to an Access Point with a missing image:

1. Download the latest software from <http://support.proxim.com>.
1. Copy the latest software updates to your TFTP server.
2. Launch ScanTool.
3. Highlight the entry for the AP you want to update and click **Change**.
4. Set **IP Address Type** to **Static**.

NOTE: *You need to assign static IP information temporarily to the Access Point since its DHCP client functionality is not available when no image is installed on the device.*

5. Enter an unused IP address that is valid on your network in the **IP Address** field. You may need to contact your network administrator to get this address.
6. Enter the network's **Subnet Mask** in the field provided.
7. Enter the network's **Gateway IP Address**, if necessary. You may need to contact your network administrator to get this address. You should only need to enter the default gateway address (169.254.128.133) if the Access Point and the TFTP server are separated by a router.
8. Enter the IP address of your TFTP server in the field provided.
9. Enter the **Image File Name** (including the file extension). Enter the full directory path and file name. If the file is located in the default TFTP directory, you need to enter only the file name.
10. Click **OK**.
The Access Point will reboot and the download will begin automatically. You should see downloading activity begins after a few seconds within the TFTP server's status screen.
11. Click **OK** when prompted that the device has been updated successfully to return to the **Scan List** screen.
12. Click **Cancel** to close the ScanTool.
13. When the download process is complete, configure the AP.

Download a New Image Using the Bootloader CLI

To download the AP Image, you will need an Ethernet connection to the computer on which the TFTP server resides. This can be any computer on the LAN or connected to the AP with a cross-over Ethernet cable.

You must also connect the AP to a computer with a standard serial cable and use a terminal client, such as HyperTerminal. From the terminal, enter CLI Commands to set the IP address and download an AP Image.

Preparing to Download the AP Image

Before starting, you need to know the Access Point's IP address, subnet mask, the TFTP Server IP Address, and the AP Image file name. Make sure the TFTP server is running and configured to point to the folder containing the image to be downloaded.

Download Procedure

1. Download the latest software from <http://support.proxim.com>.
2. Copy the latest software updates to your TFTP server's default directory.
3. Use a straight-through serial cable to connect the Access Point's serial port to your computer's serial port.
4. Open your terminal emulation program (like HyperTerminal) and set the following connection properties:
 - Com Port: <COM1, COM2, etc., depending on your computer>
 - Baud rate: 115200
 - Data Bits: 8
 - Stop bits: 1
 - Flow Control: None
 - Parity: None

5. Under **File > Properties > Settings > ASCII Setup**, enable the **Send line ends with line feeds** option. HyperTerminal sends a line return at the end of each line of code.

6. Press the **RESET** button on the AP.

The terminal display shows Power On Self Tests (POST) activity. After approximately 30 seconds, a message indicates: **Sending Traps to SNMP manager periodically**. After this message appears, press the **ENTER** key repeatedly until the following prompt appears:

```
[Device name]>
```

7. Enter only the following statements:

```
[Device name]> show (to view configuration parameters and values)
[Device name]> set ipaddr <Access Point IP Address>
[Device name]> set serveripaddr <TFTP Server IP Address>
[Device name]> set filename <AP Image File Name, including file extension>
[Device name]> set gatewayip <Gateway Ip Address>
[Device name]> set netmask <Network Mask>
[Device name]> set ipaddrtype static
[Device name]> show (to confirm your new settings)
[Device name]> reboot
```

Example:

```
[Device name]> show
[Device name]> set ipaddr 169.254.128.132
[Device name]> set serverip 169.254.128.133
[Device name]> set filename apimage_proxim.sei
[Device name]> set gatewayip 169.254.128.1
[Device name]> set netmask 255.255.255.0
[Device name]> set ipaddrtype static
[Device name]> show
```



```
[Device name]> reboot
```

The AP will reboot and then download the image file. You should see downloading activity begins after a few seconds within the TFTP server's status screen.

8. When the download process is complete, configure the AP.

Setting IP Address using Serial Port

Use the following procedure to set an IP address over the serial port using the CLI. The network administrator typically provides the AP IP address.

Hardware and Software Requirements

- Standard straight-through serial data (RS-232) cable (not included with shipment).
- ASCII Terminal software, such as HyperTerminal.

Attaching the Serial Port Cable

1. Connect one end of the serial cable to the AP and the other end to a serial port on your computer.
2. Power on the computer and AP, if necessary.

Initializing the IP Address using CLI

After installing the serial port cable, you may use the CLI to communicate with the AP. CLI supports most generic terminal emulation programs, such as HyperTerminal (which is included with the Windows operating systems). In addition, many web sites offer shareware or commercial terminal programs you can download. Once the IP address has been assigned, you can use the HTTP interface or the CLI over Telnet to complete configuration.

Follow these steps to assign the AP an IP address:

1. Open your terminal emulation program (like HyperTerminal) and set the following connection properties:
 - Com Port: <COM1, COM2, etc., depending on your computer>
 - Baud rate: 115200
 - Data Bits: 8
 - Stop bits: 1
 - Flow Control: None
 - Parity: None
2. Under **File > Properties > Settings > ASCII Setup**, enable the **Send line ends with line feeds** option. HyperTerminal sends a line return at the end of each line of code.
3. Press the **RESET** button on the AP.

The terminal display shows Power On Self Tests (POST) activity, and then displays a CLI prompt, similar to the example below. This process may take up to 90 seconds.

```
[Device name]> Please enter password:
```
4. Enter the CLI password (default is **public**).

The terminal displays a welcome message and then the CLI Prompt:

```
[Device name]>
```
5. Enter **show ip**. Network parameters appear:
6. Change the IP address and other network values using **set** and **reboot** CLI commands, similar to the example below (use your own IP address and subnet mask). Note that IP Address Type is set to Dynamic by default. If you have a DHCP server on your network, you should not need to manually configure the Access Point's IP address; the Access Point will obtain an IP address from the network's DHCP server during boot-up.

After each entry the CLI reminds you to reboot; however wait to reboot until all commands have been entered.

```
[Device name]> set ipaddrtype static
[Device name]> set ipaddr <IP Address>
[Device name]> set ipsubmask <IP Subnet Mask>
[Device name]> set ipgw <Default Gateway IP Address>
[Device name]> show ip (to confirm your new settings)
[Device name]> reboot 0
```

7. After the AP reboots, verify the new IP address by reconnecting to the CLI and enter a **show ip** command. Alternatively, you can ping the AP from a network computer to confirm that the new IP address has taken effect.
8. When the proper IP address is set, use the HTTP interface or CLI over Telnet to configure the rest of the unit's operating parameters.

Related Applications

RADIUS Authentication Server

If you enabled RADIUS Authentication on the AP, make sure that your network's RADIUS servers are operational. Otherwise, clients will not be able to log in. There are several reasons the authentication server services might be unavailable, here are two typical things to check:

- Make sure you have the proper RADIUS authentication server information setup configured in the AP. Check the RADIUS Authentication Server's Shared Secret and Destination Port number (default is 1812; for RADIUS Accounting, the default is 1813).
- Make sure the RADIUS authentication server RAS setup matches the AP.

TFTP Server

The "Trivial File Transfer Protocol" (TFTP) server allows you to transfer files across a network. You can upload configuration files from the AP for backup or copying, and you can download configuration files or new software images. The TFTP software is located on the installation CD.

If a TFTP server is not configured and running, you will not be able to download and upload images and configuration files to/from the AP. Remember that the TFTP server does not have to be local, so long as you have a valid TFTP IP address. Note that you do not need a TFTP server running unless you want to transfer files to or from the AP.

After the TFTP server is installed:

- Check to see that TFTP is configured to point to the directory containing the AP Image.
- Make sure you have the proper TFTP server IP Address, the proper AP Image file name, and that the TFTP server is connected.
- Make sure the TFTP server is configured to both Transmit and Receive files (on the TFTP server's **Security** tab), with no automatic shutdown or time-out (on the **Auto Close** tab).



ASCII Character Chart

You can configure WEP Encryption Keys in either Hexadecimal or ASCII format. Hexadecimal digits are 0-9 and A-F (not case sensitive). ASCII characters are 0-9, A-F, a-f (case sensitive), and punctuation marks. Each ASCII character corresponds to two hexadecimal digits.

The table below lists the ASCII characters that you can use to configure WEP Encryption Keys. It also lists the Hexadecimal equivalent for each ASCII character.

ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent	ASCII Character	Hex Equivalent
!	21	9	39	Q	51	i	69
"	22	:	3A	R	52	j	6A
#	23	;	3B	S	53	k	6B
\$	24	<	3C	T	54	l	6C
%	25	=	3D	U	55	m	6D
&	26	>	3E	V	56	n	6E
'	27	?	3F	W	57	o	6F
(28	@	40	X	58	p	70
)	29	A	41	Y	59	q	71
*	2A	B	42	Z	5A	r	72
+	2B	C	43	[5B	s	73
,	2C	D	44	\	5C	t	74
-	2D	E	45]	5D	u	75
.	2E	F	46	^	5E	v	76
/	2F	G	47	_	5F	w	77
0	30	H	48	`	60	x	78
1	31	I	49	a	61	y	79
2	32	J	4A	b	62	z	7A
3	33	K	4B	c	63	{	7B
4	34	L	4C	d	64		7C
5	35	M	4D	e	65	}	7D
6	36	N	4E	f	66	~	7E
7	37	O	4F	g	67		
8	38	P	50	h	68		

B

Bootloader CLI

The Bootloader CLI is a minimal subset of the normal CLI used to perform initial configuration of the AP. This interface is only accessible via the serial interface if the AP does not contain a software image or a download image command over TFTP has failed.

The Bootloader CLI provides you with the ability to configure the initial setup parameters as well as download a software image to the device.

The Bootloader CLI supports the following functions:

- **factory_reset** : Restore the factory settings
- **help**: Print Online Help
- **reboot**: Reboot the device
- **set**: Set the parameters
- **show**: Show the parameters

The parameters supported by the Bootloader CLI (for viewing and modifying) are:

- **ipaddr**: IP Address
- **systemname**: System Name
- **gatewayip**: Gateway IP Address
- **serverip**: Server IP Address
- **ipaddrtype**: IP Address Type
- **netmask**: Net Mask
- **filename**: AP Image file name

If the Bootloader fails to load the image from flash, then it tries to get the image from the network. The default configuration of the bootloader parameters are as follows:

Parameter	Value
ipaddr	169.254.128.132
netmask	255.255.255.0
gatewayip	169.254.128.133
systemname	systemname
serverip	169.254.128.133
filename	imagename
ipaddrtype	dynamic

If you want to load the image from the network, you can either:

1. Configure the device with the Scantool or
2. Entering into bootloader CLI with the serial interface

If the ipaddrtype is set to dynamic, run the BOOTP Server also. The device will get the IP address and Boot filename from the BOOTP server. You need not to change any of the above parameters.

After BOOP is succeeded, the device will initiate a TFTP request with the filename it gets from BOOTP.

If the ipaddrtype is set to static then you need to run the TFTP Server. In this case the TFTP request will be initiated with the value taken from the parameter "filename". The TFTP request is sent to the IP address set to the parameter "serverip". In this case the TFTP Server should be reachable to the device.

NOTE: *If device fails in any of the above cases, it will bring up the Scantool Interface and wait for scan and change requests forever.*

If we want to access the device with Scantool, then the host running the scantool should also be in the same network as the device.

Because the scantool broadcast requests will be discarded by the routers if the device and the host running the scantool are in different network. This reveals that we can not reach the device with the scantool.

A device in bootloader can be recognized by looking at the system description. If the system description does not contain any build no in braces, conclude that the device is in bootloader mode.

For example:

- ORiNOCO AP-8000 is the name of the board.
- WD is the Regulatory Domain
- V1.0.0 is the Bootloader Version
- SN-08UC39110110 is the Serial number of the device




Figure B-1 ScanTool View of a Device in Bootloader Mode

C

Specifications

This chapter provides information on the following topics:

- [Software Specifications](#)
- [Hardware Specifications](#)
- [Available Channels](#)

Software Specifications

The table below lists the software features available on the AP-8000.

- [Number of Stations per BSS](#)
- [Management Functions](#)
- [Advanced Bridging Functions](#)
- [Medium Access Control \(MAC\) Functions](#)
- [Security Features](#)
- [Network Features](#)

Number of Stations per BSS

Number of stations supported per radio is 64.

Management Functions

Features	Supported by AP-8000 (Y/N)
Web User Interface	Y
Telnet/CLI	Y
SNMP Agent	Y
Serial CLI	Y
Secure Management	Y
SSh	Y

Advanced Bridging Functions

Feature	Supported by AP-8000 (Y/N)
IEEE 802.1d Bridging	Y
Roaming	Y
Protocol Filtering	Y
Multicast/Broadcast Storm Filtering	Y
TCP/UDP Port Filtering	Y
Blocking Intra BSS Clients	Y
Packet Forwarding	Y

Medium Access Control (MAC) Functions

Feature	Supported by AP-8000 (Y/N)
Automatic Channel Selection (ACS)	Y
Dynamic Frequency Selection (DFS)/Radar Detection (RD)*	Y
Wireless Service Shutdown	Y
802.11d Support	Y
Tx Power Control	Y
Wireless Multimedia Enhancements/Quality of Service (QoS)	Y
Broadcast Unique Beacon	Y

* DFS is required for 802.11a APs certified in the ETSI, TELEC, FCC, and IC regulatory domains and operating in the middle frequency band. When ACS is disabled, available channels are limited to those on the lower frequency band.

Security Features

Feature	Supported by AP-8000 (Y/N)
RADIUS Profiles per VLAN	Y
IEEE 802.11 WEP*	Y
MAC Access Control	Y
RADIUS MAC-based Access Control	Y
IEEE 802.1x Authentication†	Y
Wi-Fi Protected Access (WPA)/802.11i (WPA2)	Y

* Key lengths supported by 802.11a/4.9 GHz: 64-bit, 128-bit, and 152-bit.

Key lengths supported by 802.11b: 64-bit and 128-bit.

Key lengths supported by 802.11b/g: 64-bit, 128-bit, and 152-bit.

Network Features

Feature	Supported by AP-8000 (Y/N)
System Logging (Syslog)	Y
RADIUS Accounting Support*	Y
DHCP Client	Y
TCP/IP Protocol Support	Y

Hardware Specifications

Category	Specification
Radio	<ul style="list-style-type: none"> Dual Radio Access Point with integrated radios: 802.11a/b/g/n + 802.11a/b/g/n 3x3 MIMO
Wireless Protocol	<ul style="list-style-type: none"> 802.11n draft 2.0 802.11a 802.11b 802.11g
Frequency	<ul style="list-style-type: none"> 5.15-5.85GHz* 2.4-2.483 GHz* <p>* Subject to Individual Country Regulations</p>
Channel bandwidth	<ul style="list-style-type: none"> 20MHz and 40MHz for 802.11n 20MHz for 802.11a/b/g
RF Modulation	<ul style="list-style-type: none"> MSC0 - MCS15 for 802.11n (6.5Mbps -300Mbps) BPSK, QPSK, 16-QAM and 64-QAM for 802.11a and 802.11g (6Mbps - 54Mbps) DSSS for 802.11b (1Mbps -11Mbps)
Device Interface	Ethernet: Auto-sensing 10/100/1000BASE-T Ethernet Antenna Connector: 3RP-SMA connector per radio
Network Architecture Type	Infrastructure
Transmit Power	For 2.4 GHz: 19dBm* For 5 GHz : 17dBm* * Varies with modulation scheme
Receive Sensitivity	For 2.4 GHz and 5 GHz: -75dBm* * Varies with modulation scheme
Antennas	6Dual-Band reverse SMA connector Omni-Antenna with 3 dBi gain
Local Configuration Support	RS-232 Serial port, DB9 Female
Message Authentication	<ul style="list-style-type: none"> 802.11i AES message authentication with 128 bit keys TKIP with 128 bit Michael Message Integrity Check
Intrusion detection	Detect MIC intrusion attacks

Easy Troubleshooting	<ul style="list-style-type: none"> • Alarms • SNMP Traps • Bridge Statistics • wireless statistics • Wi-Fi station statistics per client per SSID • Learn table Statistics • ICMP statistics • IP ARP statistics • Radius statistics • Interface statistics
LEDs	Four indicators on the top panel indicate power, wireless traffic, Ethernet traffic, and error conditions
Certifications	Wi-Fi Certification - Enterprise 802.11 a/b/g/n
Dimensions	8.25"x12.00"x1.5"
Weight	1.8 lb
Environmental	<p>Operating</p> <ul style="list-style-type: none"> • 0 to 55°C • 5 to 95 percent (non-condensing) <p>Storage</p> <ul style="list-style-type: none"> • 20° to 75°C
Packaging Contents	<ul style="list-style-type: none"> • One AP-8000 • One 110/220V worldwide power adapter • One Wall/Ceiling mount kit • One cable security attachment • Six 2.4GHz/5GHz omni-directional antennas with reverse SMA connectors • One Quick Install Guide • One Documentation CD
MTBF	43,800 hrs
Warranty	One year parts/labor

Available Channels

Available channels vary based on radio, country, and frequency band. To verify which channels are available for your product:

Locate the product model number on the underside of your AP unit or on the unit's box

Country	Allowed Channels for 2.4 GHz	Allowed Channels for 5 GHz
Austria	1(2.412), 2 (2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467); 13 (2.472).	36(5.18), 40(5.2), 44(5.22), 48 (5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Belgium	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5 (2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)

Bulgaria	1(2.412), 2 (2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13 (2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 100(5.5), 104(5.52), 108(5.54), 112 (5.56), 116(5.58), 120(5.6), 124(5.62), 128(5.64), 132(5.66), 136 (5.68), 140(5.7)
Canada	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32), 100(5.5), 104(5.52), 108(5.54), 112(5.56), 116(5.58), 120(5.6), 124(5.62), 128(5.64), 132(5.66), 136(5.68), 140(5.7), 149(5.745), 153(5.765)
Cyprus	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Czech	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Denmark	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Estonia	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28),60(5.3), 64(5.32)
Finland	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13 (2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
France	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Germany	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Hungary	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10 (2.457), 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Ireland	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)

Italy	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Japan	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472), 14 (2.484)	36(5.18), 40(5.2), 44(5.22), 48(5.24)
Latvia	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Lithuania	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Luxemburg	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Malta	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Netherlands	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Poland	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Portugal	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Slovakia	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Slovenia	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Spain	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)

Sweden	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437); 7(2.442), 8(2.447); 9(2.452); 10(2.457); 11(2.462), 12(2.467), 13(2.472)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32)
Taiwan	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10 (2.457), 11(2.462)	56(5.28), 60(5.3), 64(5.32), 149(5.745), 153 (5.765), 157(5.785), 161(5.805)
US	1(2.412), 2(2.417), 3(2.422), 4(2.427), 5(2.432), 6(2.437), 7(2.442), 8(2.447), 9(2.452), 10(2.457), 11(2.462)	36(5.18), 40(5.2), 44(5.22), 48(5.24), 52(5.26), 56(5.28), 60(5.3), 64(5.32), 100(5.5), 104 (5.52), 108(5.54), 112 (5.56), 116 (5.58), 120(5.6), 124(5.62), 128 (5.64), 132(5.66), 136(5.68), 140(5.7), 149(5.745), 153 (5.765)

D

Technical Services and Support

Obtaining Technical Service and Support

If you are having trouble utilizing your Proxim product, please review this manual and the additional documentation provided with your product. If you require additional support and would like to use Proxim's free Technical Service to help resolve your issue, please be ready to provide the following information before you contact Proxim's Technical Services:

- **Product information:**
 - Part number of suspected faulty unit
 - Serial number of suspected faulty unit
- **Trouble/error information:**
 - Trouble/symptom being experienced
 - Activities completed to confirm fault
 - Network information (what kind of network are you using?)
 - Circumstances that preceded or led up to the error
 - Message or alarms viewed
 - Steps taken to reproduce the problem
- **Servpak information (if a Servpak customer):**
 - Servpak account number
- **Registration information:**
 - If the product is not registered, date when you purchased the product
 - If the product is not registered, location where you purchased the product

NOTE: *If you would like to register your product now, visit the Proxim eService Web Site at <http://support.proxim.com> and click on New Product Registration.*

Support Options

Proxim eService Web Site Support

The Proxim eService Web site is available 7x24x365 at <http://support.proxim.com>.

On the Proxim eService Web Site, you can access the following services:

- **New Product Registration:** Register your product to gain access to technical updates, software downloads, and free technical support for the first 90 days from receipt of hardware purchase.
- **Open a Ticket or RMA:** Open a ticket or RMA
- **Search Knowledgebase:** Locate white papers, software upgrades, and technical information.
- **ServPak Support:** Learn more about Proxim's ServPak global support service options .
- **Your Stuff:** Track status of your tickets or RMAs and receive product update notifications.
- **Provide Feedback:** Submit suggestions or other types of feedback.
- **Customer Survey:** Submit an On-Line Customer Survey response.

Telephone Support

Contact technical support via telephone as follows:

- **US and Canada:** 408-383-7700, 866-674-6626 (Toll Free)
Hours of Operations: 8.00AM-6.00PM Monday through Friday Pacific Time
- **APAC Countries:** +91-40-23115490
Hours of Operations: 9.00AM-6.00PM Monday through Friday IST time (UTC +5:30 hrs)
- **International:** 408-383-7700
Hours of Operations: 8.00AM-6.00PM Monday through Friday Pacific Time

ServPak Support

To provide even greater investment protection, Proxim Wireless offers a cost effective support program called ServPak. ServPak is a program of enhanced service support options that can be purchased as a bundle or individually, tailored to meet your specific needs. Whether your requirement is around the clock technical support or advance replacement service, we are confident that the level of support provided in every service in our portfolio will exceed your expectations.

- **Advanced Replacement of Hardware:** Can you afford to be down in the event of a hardware failure? Our guaranteed turnaround time for return to factory repair is 30 days or less. Those customers who purchase this service are entitled to advance replacement of refurbished or new hardware guaranteed to be shipped out by the Next Business Day. Hardware is shipped Monday – Friday, 8:00AM – 2:00PM (PST).
- **Extended Warranty:** Extend the life of your networking investment by adding 1, 2, or 3 years to your products standard warranty. This service coverage provides unlimited repair of your Proxim hardware for the life of the service contract. The cost of an extended warranty is far less than the cost of a repair providing a sensible return on your investment.
- **7x24x365 Technical Support:** This service provides unlimited, direct access to Proxim's world-class Tier 3 technical support engineers 24 hours a day, 7 days a week, 365 days a year including Holidays. Customers who purchase this service can rest assured that their call for technical assistance will be answered and a case opened immediately to document the problem, trouble shoot, identify the solution and resolve the incident in a timely manner or refer to an escalation manager for closure.

- **8x5 Technical Support:** This service provides unlimited, direct access to Proxim’s world-class technical support 8 hours a day, 5 days a week from 8:00AM - 5:00PM (Local Time). Technical Support is available at no charge for the first 30 days from the purchase date. Beyond this period, a ServPak support agreement will be required for technical support. Self-help will be made available by accessing Proxim’s extensive eService knowledgebase.
- **Software Maintenance:** It’s important to maintain and enhance security and performance of wireless equipment and Proxim makes this easy by providing a Software Maintenance program that enables customers to access new feature and functionality rich software upgrades and updates. Customers will also have full access to Proxim’s vast knowledgebase of technical bulletins, white papers and troubleshooting documents.
- **Priority Queuing Phone Support:** This service provides customers with a one hour response time for technical phone support. There is no waiting in line for those urgent calls for technical support.

ServPak Service	24x7Enhanced (Bundled Serv.)	8x5 Standard (Bundled Serv.)	Extended Warranty	Advance Hardware Replacement	Software Maintenance	24x7 Technical Support
Product Coverage Duration	Renewable Contracts	Renewable Contracts	Renewable Contracts	Renewable Contracts	No	Renewable Contracts
Software Coverage Duration	Renewable Contracts	Renewable Contracts	No	No	Renewable Contracts	No
Proxim TAC Support	Yes	Yes	No	No	No	Yes
Software Updates & Upgrades	Yes	Yes	No	No	Yes	No
Registered Access to Proxim.com	Yes	Yes	Yes	Yes	Yes	Yes
Registered Access to Knowledge Tool	Yes	Yes	Yes	Yes	Yes	Yes
Advance Replacement	Yes	No	No	Yes	No	No
Depot Repair	No	Yes	Yes	No	No	No

To purchase ServPak support services, please contact your authorized Proxim distributor. To receive more information or for questions on any of the available ServPak support options, please call Proxim Support at 408-383-7700 or send an email to servpak@proxim.com.



Statement of Warranty

Warranty Coverage

Proxim Wireless Corporation warrants that its Products are manufactured solely from new parts, conform substantially to specifications, and will be free of defects in material and workmanship for a Warranty Period of 1 year from the date of purchase.

Repair or Replacement

In the event a Product fails to perform in accordance with its specification during the Warranty Period, Proxim offers return-to-factory repair or replacement, with a thirty (30) business-day turnaround from the date of receipt of the defective Product at a Proxim Wireless Corporation Repair Center. When Proxim Wireless has reasonably determined that a returned Product is defective and is still under Warranty, Proxim Wireless shall, at its option, either: (a) repair the defective Product; (b) replace the defective Product with a refurbished Product that is equivalent to the original; or (c) where repair or replacement cannot be accomplished, refund the price paid for the defective Product. The Warranty Period for repaired or replacement Products shall be ninety (90) days or the remainder of the original Warranty Period, whichever is longer. This constitutes Buyer's sole and exclusive remedy and Proxim Wireless's sole and exclusive liability under this Warranty.

Limitations of Warranty

The express warranties set forth in this Agreement will not apply to defects in a Product caused; (i) through no fault of Proxim Wireless during shipment to or from Buyer, (ii) by the use of software other than that provided with or installed in the Product, (iii) by the use or operation of the Product in an application or environment other than that intended or recommended by Proxim Wireless, (iv) by modifications, alterations, or repairs made to the Product by any party other than Proxim Wireless or Proxim Wireless's authorized repair partners, (v) by the Product being subjected to unusual physical or electrical stress, or (vii) by failure of Buyer to comply with any of the return procedures specified in this Statement of Warranty.

Support Procedures

Buyer should return defective LAN1 Products within the first 30 days to the merchant from which the Products were purchased. Buyer can contact a Proxim Wireless Customer Service Center either by telephone or via web. Calls for support for Products that are near the end of their warranty period should be made not longer than seven (7) days after expiration of warranty. Repair of Products that are out of warranty will be subject to a repair fee. Contact information is shown below. Additional support information can be found at Proxim Wireless's web site at <http://support.proxim.com>.

- **US and Canada:** 408-383-7700, 866-674-6626 (Toll Free)

Hours of Operation: 8.00AM-6.00PM

- **APAC Countries:** +91 40 23115490

Hours of Operation: 9.00AM-6.00PM

- **International:** 408-383-7700

Hours of Operation: 8.00AM-6.00PM

When contacting the Customer Service for support, Buyer should be prepared to provide the Product description and serial number and a description of the problem. The serial number should be on the product.

In the event the Customer Service Center determines that the problem can be corrected with a software update, Buyer might be instructed to download the update from Proxim Wireless's web site or, if that's not possible, the update will be

sent to Buyer. In the event the Customer Service Center instructs Buyer to return the Product to Proxim Wireless for a repair or replacement, the Customer Service Center will provide Buyer a Return Material Authorization ("RMA") number and shipping instructions. Buyer must return the defective Product to Proxim Wireless, properly packaged to prevent damage, shipping prepaid, with the RMA number prominently displayed on the outside of the container.

Calls to the Customer Service Center for reasons other than Product failure will not be accepted unless Buyer has purchased a Proxim Wireless Service Contract or the call is made within the first thirty (30) days of the Product's invoice date. Calls that are outside of the 30-day free support time will be charged a fee of \$25.00 (US Dollars) per Support Call.

If Proxim Wireless reasonably determines that a returned Product is not defective or is not covered by the terms of this Warranty, Buyer shall be charged a service charge and return shipping charges.

Other Information

Search Knowledgebase

Proxim Wireless stores all resolved problems in a solution database at the following URL: <http://support.proxim.com>.

Ask a Question or Open an Issue

Submit a question or open an issue to Proxim Wireless technical support staff at the following URL:
<http://support.proxim.com/cgi-bin/proxim.cfg/php/enduser/ask.php>.

Other Adapter Cards

Proxim Wireless does not support internal mini-PCI devices that are built into laptop computers, even if identified as "ORiNOCO" devices. Customers having such devices should contact the laptop vendor's technical support for assistance.

For support for a PCMCIA card carrying a brand name other than Proxim, ORiNOCO, Lucent, Wavelan, or Skyline, Customer should contact the brand vendor's technical support for assistance.